## Selecting a Lead Laboratory National Center for Healthy Housing - Fact Sheet #4

## How do I select a laboratory to analyze lead samples?

## Who should use this fact sheet?

This fact sheet was developed for lead sampling technicians, risk assessors, and lead inspectors, as well as health and housing officials overseeing renovation programs. HUD recommends that qualified technicians be used to collect samples.

Why is selecting a qualified laboratory important? Results Can Vary. The results of lead testing are often used to show that a home is free of hazardous levels of lead in dust, soil or paint. Small mistakes in lab procedures can produce results that have different meanings. In some cases, lab mistakes may falsely show that a home is lead-safe or may falsely identify lead hazards. Two key ways to check a laboratory's quality are to:

1. Make sure the lab is part of the National Lead Laboratory Accreditation Program (NLLAP). NLLAP is a program designed to test a lab's ability to analyze dust wipes, soil and paint samples for lead. HUD regulations require the use of NLLAP-recognized laboratories when laboratory analysis of lead samples is required.

Small amounts of lead in dust can poison young children.

Dangerous levels of lead dust may remain after working with paint, even if a work site looks clean.

Workers may bring leadcontaminated dust home.

Cleaning protects children in homes where work is done, as well as children in the homes of workers.

Simple cleaning techniques reduce dust lead levels.

2. Check the accuracy and precision of the laboratory by sending them blind quality control samples. Many laboratories will provide these samples. This is an important step if you collect many samples, but not practical for homeowners and others submitting very few samples.

**Supplies and Services are Different**. Some laboratories work only with large industrial or commercial clients. Others provide help to those who need a few samples analyzed.

**Price is Only One Factor to Consider.** Laboratories that have higher prices may offer a better value if you consider the services that they provide and their attention to quality control.

The checklist on the next page outlines questions to ask labs to help determine if they have the services and capacity to meet your needs.

<ol> <li>1. Accreditation</li> <li>2. Types of Clients</li> <li>3. Samples Analyzed</li> </ol>	<ul> <li>Is the lab recognized by the EPA as accredited under the National Lead Laboratory Accreditation Program (NLLAP)? Only use labs with NLLAP accreditation.</li> <li>Some states also regulate lead laboratories.</li> <li>Are samples accepted from the general public PA vacuum all surfaces including the plastic, work clothes and work shoes. Include walls and ceilings.</li> <li>Is there a minimum number of samples?</li> <li>Are paint, dust, soil and/or water samples analyzed?</li> </ul>
	Are composite samples analyzed?
4. Cost and Turn-around Time	<ul> <li>What is the cost per sample for standard turn-around time?</li> <li>What is the standard turn-around time?</li> <li>Does the lab offer 24-hour turn-around?</li> <li>Are there volume discounts?</li> </ul>
5. Reporting	<ul> <li>♦ How are the results provided? U.S. mail, fax and/or e-mail?</li> <li>♦ What units are used for reporting each type of sample result? For lead dust, it is easiest if results are reported in micrograms per square foot (µg/ft2) and calculated using the measurements you provide. This saves time and reduces errors.</li> <li>♦ Are the results compared with appropriate federal, state or local standards to determine compliance?</li> </ul>
6. Client Support	<ul> <li>Are sample collection materials provided, such as wipes, gloves, templates, tubes for submitting samples, and forms?</li> <li>Are written sample collection directions provided?</li> <li>Will the lab offer assistance over the phone?</li> <li>Does the lab have a home sampling kit for lead?</li> </ul>
7. Quality Control	<ul> <li>Will the lab provide blind quality control samples to check the accuracy and precision of the laboratory's procedures? Click on Field Quality Control Samples to see a listing of labs that supply field QC samples.</li> </ul>

## **Additional Topic Resources**:

To obtain a current list of laboratories recognized by the EPA as accredited under the National Lead Laboratory Accreditation Program (NLLAP):

Call the National Information Center at 1-800-424-LEAD.

To learn about a specific laboratory's past performance or complaint history:

Contact the American Industrial Hygiene Association (AIHA) at 703-849-8888 or the American Association for Laboratory Accreditation (A2LA) at 301-644-3200. AIHA and A2LA are EPA-recognized accreditation organizations in the NLLAP audit process.

To obtain a current list of lead laboratories licensed by your state:
Call your state health department. Your state program contacts can be found at:
National Conference of State Legislatures
Lead Poisoning Prevention-State Contacts Directory

To view the EPA training module on selecting a laboratory:

EPA Lead Sampling Technician Training Course EPA 747-B-00-002 July 2000), Module 4: Selecting a Laboratory and Interpreting Results

Go to HUD Office of Lead Hazard Control or call the National Information Center at 1-800-424-LEAD.

This fact sheet has been funded by the Office of Healthy Homes and Lead Hazard Control at the U.S. Department of Housing and Urban Development.

For additional information, please visit www.nchh.org.

									Submittin	Lab Use-WO#									
															Acct #				
Project Name: Special Instructions [include requests for special reporting or data packages]												Phone #							
Project Locati	on:														FAX#				
Project Number:												Discourse terrial							
Purchase Ord	er No.:				ST	ATE W	HERE SA	AMPLES	WERE C	OLLECT	ED								
Turn Around Time Matrix / Sample Type (Select <u>ONE</u> )					ct ONE)	Į I			Tests / Ana	alytes (Sele	ct <u>ALL</u> that	Apply)			ORGANICS TESTS and other Analyses				
[ ] Same day* All samples on form should be of <u>s</u>			No.	As	bestos Air	/ Fiber Cou	nts As	ts Asbestos Bulk / Asb ID Metals-Total Conc.						NOTE: All samples for organics should be kept at 4°C					
[ ] 1 business day* <u>matrix type</u> . Use additional forms as			as needed.	W Glestyne	CM (NIOSH	5		[ ] PLM (EPA 600, 1982) [ ] Lead					rom collection until testing. Schedule rush analyses in						
[ ] 2 business days* [ ] Air [ ] Solid			[ ] TEM (AHERA)				[ ] PLM (EPA Point Count) [ ] RCRA Metals					advance. Indicate preservatives added & media type Indicate analysis method for organics tests.				97.670			
[ ] 3 business days*			otor		M (EPA Lev	verii)		[ ] PLM (Qualitative only)					Indicat	e anaiysis I	metnoa 1	or organic	s tests.		
[ ] STANDARD (5 bus. days) [ ] Bulk [ ] Wastewater					Missellana	oue Tests		**************************************		l J.	lotala Evtra		1						
[ ] Weekend*	lard Full TCLP (10d) [ ] Hi-Vol Filter (PM10) [ ] Water, Drink		873	Miscellaneous Tests				AELAP (EPA EM (Chatfiel	- 3		letals-Extra	ici	1						
[ ] Weekend*		arice	[ ] Total Dust (NIOSH 0500) [ ] Resp. Dust (NIOSH 0600)				LIVI (Criatilei	u)	- Made and description of the	] TCLP / Lead ] TCLP / RCRA Metals									
* not available for all tests [ ] Paint [ ] Wipe, Comp		Composite	[ ] Silica - FTIR (NIOSH 7602			200					CLP / Full (w/ organics)								
Schedule rush organics, multi-		<u>.</u>	[ ] Silica - XRD (NIOSH 7500)			35													
metals & weekend tests in advance. [] Soil []						USE	ED:												
		Organics					Wipes			Information for Air Samp									
0	Date	Time		Sample Idei			Wiped	Type <sup>1</sup>	767.5	me <sup>2</sup>	W. W	Rate	Total⁴	# con-					
Sample #	Sampled	Sampled	(e.g. Em	ployee, SS	N, Bldg, Ma	ateriai)	Area (π²)	A,B,P,E	Start	Stop	Start	Stop	Air Vol	tainers	-			<del></del>	
*																			
<u>u</u>																		<u> </u>	
8																			
															<b></b>			<u> </u>	
								5									-		
																		<u> </u>	
								,											
	Sample (	Collection 8	L & Custody I	nformation			/pe: A=area	<b>I</b> B=blank P=p	l ersonal E=e:	xcursion <sup>2</sup> Be	l eginning/End	of Sample Pe	riod <sup>3</sup> Pump	Calibration i	II n Liters/Minu	te <sup>4</sup> Volum	l ne in Liters [f	ime in min	<u>I</u> ∗flow in L/m
Sampled by	[NAME]				[SIGNA	ATURE]				IDA	TE/TIME]			-272	TT	Sample	return re	equested	N
Relinquished to lab by[NAME][SIGNATI					bysotos aranomatarina del control de la cont							[ ] Ambient temp [ ] Cool°C							
Received in lab by [NAME][SIGNATE]				8.041	8.770 ST6.57 ST6.57							[]pH[]CI[]R[]S							
[ ]FX [ ]DHL Unusual Sample	[]UPS [	JUSM []	10 02 9650	22 Sept.							Tet 21 Et 1 11A1)	<b>.</b>	Chair	n of Custods	L J ∕ document		828A (758)	1244 ZES 94	NV 501