

**10 CSR 10-5.060 Refuse Not To Be Burned  
in Fuel Burning Installations**

No person shall burn or cause or permit the burning of refuse in any installation which is designed for the primary purpose of burning fuel.

