

Installing the Turbine Emissions Analysis Tool v1.0

These instructions describe how to set up the Turbine Emissions Analysis Tool v1.0 on your computer. The software takes advantage of the Microsoft .NET Framework. Therefore, you will also need the .NET Framework version 1.1 installed on your computer for the Turbine Emissions Analysis Tool to operate correctly. The requirements for .NET and the Turbine software are summarized in the table below.

Processor	Intel Pentium Class, 90 Mhz or higher
Operating System	Microsoft Windows 98, NT 4.0, 2000, ME, or XP
RAM	32 MB (96 MB or higher recommended)
Hard Disk Space	<ul style="list-style-type: none"> • Space required to install .NET: 150 MB • Space required for .NET: 110 MB
Other	<ul style="list-style-type: none"> • Microsoft Internet Explorer 5.01 or later • Microsoft Windows Installer 2.0 or later

There are two files available for download, SystemCheck.exe and TurbineToolSetup100.exe. The SystemCheck.exe program will first check your computer for the operating system and whether or not the .NET Framework and required versions of Microsoft Internet Explorer and the Microsoft Windows Installer are installed on your machine. If necessary, you will need to obtain and install Microsoft Internet Explorer, version 5.01 or later, and the Microsoft Windows Installer, version 2.0 or later, to your machine before installing the Turbine Emissions Analysis Tool. The Turbine Emissions Analysis Tool will install the .NET Framework, version 1.1, if it is not already on the machine.

Installation Steps

- a. Optional -- Check to make sure your PC meets the hardware's requirements:
 - Download the file SystemCheck.exe from the CAMD website. Once the download is completed, double-click on the file to run the system check.

The SystemCheck.exe program will analyze your PC:

- A Red Box indicates your PC does not meet minimum requirements. Please call PQA for help with software installation.
- A Yellow Box indicates your PC meets minimum requirements.
- A Green Box indicates your PC meets recommended requirements.

b. Install Turbine Emission Analysis Tool software:

- Download the self-extracting TurbineToolSetup100.exe file from the CAMD website. Once the download is complete double-click on the file to begin the program installation.
- Follow the prompts for identifying subdirectories that the program will create. The default program directory is C:\ProgramFile\TurbineEmissionsAnalysisTool.
- Initiate the program by double-clicking on the new Turbine Emissions Analysis Tool icon from the appropriate Program Group off the Start Menu.

Screen Appearance

The Turbine Emissions Analysis Tool requires a minimum screen resolution of 1024 x 768, otherwise parts of some screens may not be visible. If you notice that parts of your screens seem "cut off," consult your Windows documentation for information on setting the screen resolution to 1024 x 768 pixels.

Installation Assistance

Contact Perrin Quarles Associates, Inc. at (434) 979-3700 or turbinetool@pqa.com.