>>>> This article, FR94, is divided into five files. This is File C: Technical Amendments of Appendix IX to Part 266, Section 4.0 through Appendix A.3 to Appendix IX to Part 266 - Statistics, <<<<

# SECTION 4.0 PROCEDURE FOR ESTIMATING THE TOXICITY EQUIVALENCY OF CHLORINATED DIBENZO-P-DIOXIN AND DIBENZOFURAN CONGENERS

PCDDs and PCDFs must be determined using the method given in section 3.4 of this document. In this method, individual congeners or homologues<sup>1</sup> are measured and then summed to yield a total PCDD/PCDF value. No toxicity factors are specified in the method to compute risks from such emissions.

<sup>1</sup>The term "congener" refers to any one particular member of the same chemical family; e.g., there are 75 congeners of chlorinated dibenzo-p-dioxins. The term "homologue" refers to a group of structurally related chemicals that have the same degree of chlorination. For example, there are eight homologues of CDs, monochlorinated through octachlorinated. Dibenzo-p-dioxins and dibenzofurans that are chlorinated at the 2,3,7, and 8 positions are denoted as "2378" congeners, except when 2,3,7,8-TCDD is uniquely referred to: e.g., 1,2,3,7,8-PeCDF and 2,3,4,7,8- PeCDF are both referred to as "2378-PeCDFs."

For the purpose of estimating risks posed by emissions from boilers and industrial furnaces, however, specific congeners and homologues must be measured using the specified method and then multiplied by the assigned toxicity equivalence factors (TEFs), using procedures described in "Interim Procedures for Estimating Risks Associated with Exposures to Mixtures of Chlorinated Dibenzo-p-Dioxins and Dibenzofurans (CDDs and CDFs) and 1989 Update," EPA/625/3-89/016, March 1989. The resulting 2,3,7,8-TCDD equivalents value is used in the subsequent risk calculations and modeling efforts as discussed in the BIF final rule.

The procedure for calculating the 2,3,7,8-TCDD equivalent is as follows:

- 1. Using method 23, determine the concentrations of 2,7,3,8-congeners of various PCDDs and PCDFs in the sample.
- 2. Multiply the congener concentrations in the sample by the TEF listed in Table 4.0-1 to express the congener concentrations in terms of 2,3,7,8-TCDD equivalent. Note that congeners not chlorinated at 2,3,7, and 8 positions have a zero toxicity factor in this table.
  - 3. Add the products obtained in step 2, to obtain the total 2,3,7,8-TCDD equivalent in the sample.

Sample calculations are provided in EPA document No. EPA/625/3-89/016, March 1989, which can be obtained from the EPA, ORD Publications Office, Cincinnati, Ohio (Phone no. 513-569-7562).

Table 4.0-1.-2,3,7,8-TCDD Toxicity Equivalence Factors (TEFs) $^1$ 

Compound	I-TEFs, 89
Mono-, Di-, and TriCDDs	0
2,3,7,8-TCDD	1
Other TCDDs	0
2,3,7,8-PeCDD	0.5
Other PeCDDs	0

2,3,7,8-HxCDD	0.1
Other HxCDDs	0
2,3,7,8-HpCDD	0.01
Other HpCDDs	0
OCDD	0.001
Mono-, Di-, and TriCDFs	0
2,3,7,8-TCDF	0.1
Other TCDFs	0
1,2,3,7,8-PeCDF	0.05
2,3,4,7,8-PeCDF	0.5
Other PeCDFs	0
2378-HxCDFs	0.1
Other HxCDFs	0
2378-HpCDFs	0.01
Other HpCDFs	0
OCDF	0.001

Reference: Adapted from NATO/CCMS, 1988a.

<sup>1</sup>Interim Procedures for Estimating Risks Associated with Exposures to Mixtures of Chlorinated Dibenzo-p-Dioxins and Dibenzofurans (CDDs and CDFs) 1989 Update EPA/625/3-89/016, March 1989.

## SECTION 5.0 HAZARDOUS WASTE COMBUSTION AIR QUALITY SCREENING PROCEDURE

The HWCAQSP is a combined calculation/reference table approach for conservatively estimating short-term and annual average facility impacts for stack emissions. The procedure is based on extensive short-term modeling of 11 generic source types and on a set of adjustment factors for estimating annual average concentrations from short-term concentrations. Facility impacts may be determined based on the selected worst-case stack or on multiple stacks, in which the impacts from each stack are estimated separately and then added to produce the total facility impact.

This procedure is most useful for facilities with multiple stacks, large source-to-property boundary distances, and complex terrain between 1 and 5 km from the facility. To ensure a sufficient degree of conservatism, the HWCAQSP may not be used if any of the five screening procedure limitations listed below are true:

- The facility is located in a narrow valley less than 1 km wide;
- The facility has a stack taller than 20 m and is located such that the terrain rises to the stack height within 1 km of the facility;
- The facility has a stack taller than 20 m and is located within 5 km of the shoreline of a large body of water;

- ullet The facility property line is within 200 m of the stack and the physical stack height is less than 10 m; or
  - On-site receptors are of concern, and stack height is less than 10 m.

If any of these criteria are met or the Director determines that this procedure is not appropriate, then detailed site-specific modeling or modeling using the "Screening Procedures for Estimating the Air Quality Impact of Stationary Sources," EPA -450/4-88-010, Office of Air Quality Planning and Standards, August 1988, is required. Detailed site-specific dispersion modeling must conform to the EPA "Guidance on Air Quality Models (Revised)", EPA 450/2-78-027R, Office of Air Quality Planning and Standards, Research Triangle Park, North Carolina, July 1986. This document provides guidance on both the proper selection and regulatory application of air quality models.

#### Introduction

The Hazardous Waste Combustion Air Quality Screening Procedure (HWCAQSP) (also referred to hereafter as "the screening procedure" or "the procedure") provides a quick, easy method for estimating maximum (hourly) and annual average ambient air impacts associated with the combustion of hazardous waste. The methodology is conservative in nature and estimates dispersion coefficients based on facility-specific information.

 $^1The$  term dispersion coefficient refers to the change in ambient air concentration  $(\mu g/m^3)$  resulting from a source with an emission rate of 1 g/sec.

The screening procedure can be used to determine emissions limits at sites where the nearest meteorological (STAR) station is not representative of the meteorology at the site. If the screen shows that emissions from the site are adequately protective, then the need to collect site-specific meteorological data can be eliminated.

The screening procedure is generally most helpful for facilities meeting one or more of the following conditions:

- ullet Multiple stacks with substantially different release specifications (e.g., stack heights differ by >50 percent, exit temperatures differ by >50  $^{\circ}$ K, or the exit flow rates differ by more than a factor of 2),
- ullet Terrain located between 1 km and 5 km from the site increases in elevation by more than the physical height of the shortest stack (i.e., the facility is located in complex terrain), or
- Significant distance between the facility's stacks and the site boundary [guidance on determining whether a distance is "significant" is provided in Step 6(B) of the procedure].

Steps 1 through 9 of the screening procedure present a simplified method for determining emissions based on the use of the "worst-case" stack. If the simplified method shows that desired feed rates result in emissions that exceed allowable limits for one or more pollutants, a refined analysis to examine the emissions from each stack can be conducted. This multiple-stack method is presented in Step 10.

The steps involved in screening methodology are as follows:

- Step 1. Define Source Characteristics
- Step 2. Determine the Applicability of the Screening Procedure
- Step 3. Select the Worst-Case Stack
- Step 4. Verify Good Engineering Practice (GEP) Criteria

Step 5. Determine the Effective Stack Height and Terrain-Adjusted Effective Stack Height  Step 6. Classify the Site as Urban or Rural  Step 7. Determine Maximum Dispersion Coefficients  Step 8. Estimate Maximum Ambient Air Concentrations  Step 9. Determine Compliance With Regulatory Limits  Step 10. Multiple Stack Method							
Step 1: Def:	ine Sour	ce Characteri	stics				
²Works addit:	heet sp	acks, copy th	a: <sup>2</sup> ed for three stack e form and revise				
Stack Data:		Stack No. 1	Stack No. 2	Stack No. 3			
Physical stac	k height						
Exhaust tempe	rature						
Flow rate (m <sup>3</sup> ,	/sec)						
projected war fill in the	der all idths of spaces	buildings wit the stack(s) below.	hin five building . For the building	g with the greates	st height,		
	uilding	width (m)			aximum		
			rise for the follo if the highest sta				
		( m )	( m	n)	( m )		
0-0.5	km		0-2.5 km	0-5 km			
Distance fro	om facil n (km)	ity to neares	t shoreline (km)				
Step 2: Dete	ermine t	he Applicabil	ity of the Screeni	ng Procedure			
Fill :	in the f	following data	:				
6					Yes No		
	_	valley < km in v		-			
	k height		he facility greater t stack? (Only applies				

Is the distance to the nearest shoreline <5 km? (Only applies to facilities with stacks  $\geq 20$  meters in height)

For the building listed in Step 1, is the closest property boundary <5 times the building height or <5 times the maximum projected building width? (Only applies to facilities with a stack height <2.5 times the building height)

If the answer is "no" to all the preceding questions, then the  ${\tt HWCAQSP}$  is acceptable. If the answer to any question is "yes", the procedure is not acceptable.

Step 3: Select the Worst-Case Stack

If the facility has several stacks, a worst-case stack must be chosen to conservatively represent release conditions at the facility. Follow the steps below to identify the worst-case stack.

Apply the following equation to each stack:

K = HVT

where:

K = an arbitrary parameter accounting for the relative influence of the stack height and plume rise.

H = Physical stack height (m)

 $V = Flow rate (m^3/sec)$ 

T = Exhaust temperature (°K)

Complete the following table to compute the "K" value for each stack:

Stack No.	Stack height (m)	х	Flow rate (m³/sec)	х	Exit temp (°K)	=	К
1 2 3		X X X		X X X		= = =	

Select the stack with the lowest "K" value. This is the worst-case stack that will be used for Steps 4 through 9.

Worst-Case Stack is identified as Stack No.

Step 4: Verify Good Engineering Practice (GEP) Criteria

Confirm that the selected worst-case stack meets Good Engineering Practice (GEP) criteria. The stack height to be used in the subsequent steps of this procedure must not be greater than the maximum GEP. Maximum and minimum GEP stack heights are defined as follows:

```
CEP (minimum) = H + (1.5 \times L)
GEP (maximum) = greater of 65 m or
H + (1.5 \times L)
```

where:

- H = height of the building selected in Step 1 measured from ground level elevation at the base of the stack
- L = the lesser dimension of the height or projected width of the building selected in Step 1

Record the following data for the worst-case stack:

```
Stack height (m) = _____
H(m) = ____
L(m) = ____
```

Then compute the following:

```
GEP (minimum) (m) = _____
GEP (maximum) (m) = _____
```

- If the physical height of the worst-case stack exceeds the maximum GEP, then use the maximum GEP stack height for the subsequent steps of this analysis;
- If the physical height of the worst-case stack is less than the minimum GEP, then use generic source number 11 as the selected source for further analysis and proceed directly to Step 6;
- If the physical height of the worst-case stack is between the minimum and maximum GEP, then use the actual physical stack height for the subsequent steps of this analysis.

Step 5: Determine the Effective Stack Height and the Terrain-Adjusted Effective Stack Height (TAESH)

The effective stack height is an important factor in dispersion modeling. The effective stack height is the physical height of the stack plus plume rise. As specified in Step 4, the stack height used to estimate the effective stack height must not exceed GEP requirements. Plume rise is a function of the stack exit gas temperature and flow rate.

In this analysis, the effective stack height is used to select the generic source that represents the dispersion characteristics of the facility. For facilities located in flat terrain and for all facilities with worst-case stacks less than or equal to 10 meters in height, generic source numbers are selected strictly on the basis of effective stack height. In all other cases, the effective stack height is further adjusted to take into account the terrain rise near the facility. This "terrain-adjusted effective stack height" (TAESH) is then used to select the generic source number that represents the dispersion characteristics of the facility. Follow the steps below to identify the effective stack height, the TAESH (where applicable), and the corresponding generic source number.

(A) Go to Table 5.0-1 and find the plume rise value corresponding to the stack temperature and exit flow rate for the worst-case stack determined in Step 3.

```
Plume rise =____(m)
```

(B) Add the plume rise to the GEP stack height of the worst-case stack determined in Steps 3 and 4.

(C) Go to the first column of Table 5.0-2 and identify the range of effective stack heights that includes the effective stack height estimated in Step 5(B). Record the generic source number that corresponds to this range.

Generic source number =

(D) If the source is located in flat terrain³, or if the generic source number identified in Step 5(C) above is 1 or 11 (regardless of terrain classification), use the generic source number determined in Step 5(C) and proceed directly to Step 6. Otherwise, continue to Step 5(E).

 $^3$ The terrain is considered flat and terrain adjustment factors are not used if the maximum terrain rise within 5 km of the facility (see Step 1) is less than 10 percent of the physical stack height of the worst-case stack.

(E) For those situations where the conditions in Step 5(D) do not apply, the effective stack height must be adjusted for terrain. The TAESH for each distance range is computed by subtracting the terrain rise within the distance range from the effective stack height.<sup>4</sup>

 $^4$ Refer to Step 1 for terrain adjustment data. Note that the distance from the source to the outer radii of each range is used. For example, for the range >0.5-2.5 km, the maximum terrain rise in the range 0.0-2.5 km is used.

Table 5.0-1.-Estimated Plume Rise (in Meters) Based on Stack Exit Flow Rate and Gas Temperature

Exhaust Temp	Exhaust Temperature (°K)										
Flow rate (m³/s)	<325	325- 349	350- 399	400- 449	450- 499	500- 599	600- 699	700- 799	800- 999	1000- 1499	>1499
<0.5	0	0	0	0	0	0	0	0	0	0	0
0.5-0.9	0	0	0	0	0	0	0	0	1	1	1
1.0-1.9	0	0	0	0	1	1	2	3	3	3	4
2.0-2.9	0	0	1	3	4	4	6	6	7	8	9
3.0-3.9	0	1	2	5	6	7	9	10	11	12	13
4.0-4.9	1	2	4	6	8	10	12	13	14	15	17
5.0-7.4	2	3	5	8	10	12	14	16	17	19	21
7.5-9.9	3	5	8	12	15	17	20	22	22	23	24
10.0-12.4	4	6	10	15	19	21	23	24	25	26	27
12.5-14.9	4	7	12	18	22	23	25	26	27	28	29
15.0-19.9	5	8	13	20	23	24	26	27	28	29	31
20.0-24.9	6	10	17	23	25	27	29	30	31	32	34
25.0-29.9	7	12	20	25	27	29	31	32	33	35	36
30.0-34.9	8	14	22	26	29	31	33	35	36	37	39
35.0-39.9	9	16	23	28	30	32	35	36	37	39	41
40.0-49.9	10	17	24	29	32	34	36	38	39	41	42
50.0-59.9	12	21	26	31	34	36	39	41	42	44	46
60.0-69.9	14	22	27	33	36	39	42	43	45	47	49
70.0-79.9	16	23	29	35	38	41	44	46	47	49	51
80.0-89.9	17	25	30	36	40	42	46	48	49	51	54
90.0-99.9	19	26	31	38	42	44	48	50	51	53	56

100.0-119.9	21	26	32	39	43	46	49	52	53	55	58
120.0-139.9	22	28	35	42	46	49	52	55	56	59	61
140.0-159.9	23	30	36	44	48	51	55	58	59	62	65
160.0-179.9	25	31	38	46	50	54	58	60	62	65	67
180.0-199.9	26	32	40	48	52	56	60	63	65	67	70
>199.9	26	33	41	49	54	58	62	65	67	69	73

Table 5.0-2-Selection of Generic Source Number

Effective stack height (m)	Generic source No.
<10.0 10.0-14.9 15.0-19.9 20.0-24.9 25.0-30.9 31.0-41.9 42.0-52.9 53.0-64.9 65.0-122.9 113.0+ Downwash	1 2 3 4 5 6 7 8 9

Table 5.0-3.-Classification of Land Use Types

Type <sup>1</sup>	Description	Urban or rural designation <sup>2</sup>
	Heavy Industrial	Urban
12	Light/Moderate Industrial	Urban
Cl	Commercial	Urban
R1	Common Residential (Normal Easements)	Rural
R2	Compact Residential (Single Family)	Urban
R3	Compact Residential (Multi- Family)	Rural
R4	Estate Residential (Multi- Acre Plots)	Rural
A1	Metropolitan Natural	Rural
A2	Agricultural	Rural
A3	Undeveloped (Grasses/Weeds)	Rural
A4	Undeveloped (Heavily Wooded)	Rural
A5	Water Surfaces	Rural

<sup>&</sup>lt;sup>1</sup>EPA, Guideline on Air Quality Models (Revised), EPA-450/2-78-027, Office of Air Quality Planning and Standards, Research Triangle Park, North Carolina, July, 1986.

<sup>2</sup>Auer, August H. Jr., "Correlation of Land Use and Cover with meteorological Anomalies," Journal of Applied Meteorology, pp. 636-643, 1978.

Distance range (km)	Effective stack-height (m) [see step 5(B)]	-	Maximum terrain-rise (m) (see step 1)	=	TAESH(m)
0.0-0.5 >0.5-2.5 >2.5-5.0				= = =	

If the terrain rise for any of the distance ranges is greater than the effective stack height, set the TAESH equal to zero and use generic source number 1 for that distance range.

Record the generic source numbers from Table 5.0-2 based on each of the TAESH values.

Distance range (km)	Generic source No. (after terrain adjustment)
0.0-0.5	

Step 6: Classify the Site as Urban or Rural

(A) Classify the land use near the facility as either urban or rural by determining the percentage of urban land use types (as defined in Table 3; for further guidance see the footnoted references) that fall within 3 km of the facility.  $^5$ 

The delineation of urban and rural areas, can be difficult for the residential-type areas listed in Table 5.0-3. The degree of resolution in Table 5.0-3 for residential areas often cannot be identified without conducting site area inspections. This process can require extensive analysis, which, for many applications, can be greatly streamlined without sacrificing confidence in selecting the appropriate urban or rural classification. The fundamental simplifying assumption is based on the premise that many applications will have clear-cut urban/rural designations, i.e., most will be in rural settings that can be definitively characterized through a review of aerial photographs, zoning maps, or U.S. Geological Survey topographical maps.

Method Used to Estimate Percent Urban Land Use:	Visual	Planimeter
Estimated Percentages	Urban	Rural

If the urban land use percentage is less than or equal to 30 percent based on a visual estimate, or 50 percent based on a planimeter, the local land use is considered rural. Otherwise, the local land use is considered urban.

Classification	Urban	Rural
(check		
applicable		
space).		

(B) Based on the TAESH and the urban/rural classification of surrounding land use, use the following table to determine the threshold distance between any stack and the nearest facility boundary.

	Distance (m)		
Terrain adjusted effecti stack height range (m)	ve Urban	Rural	
1-9.9	200	200	
10-14.9	200	250	
15-19.9	200	250	
20-24.9	200	350	
25-30.9	200	450	
31-41.9	200	550	
42-52.9	250	800	
53-64.9	300	1000	
65-112.9	400	1200	
113+	700	2500	

Record the following information:

Threshold distance from the table (m):

Minimum distance from any stack to property boundary (m):

If the minimum distance between any stack and the nearest facility boundary is greater than the threshold distance, the surrounding buffer distance is considered significant and the facility is likely to benefit from use of the HWCAQSP relative to the Tier I and II limits (see discussion of benefits from using HWCAQSP in Introduction section).

Step 7: Determine Maximum Dispersion Coefficients

(A) Determine maximum average hourly dispersion coefficients. Based on the results of Step 6(A), select either Table 5.0-4 (urban) or Table 5.0-5 (rural) to determine the maximum average hourly dispersion coefficient. For flat terrain [defined in Step 5(D)] and for all sites with generic source numbers 1 or 11, use Step 7(A) (1). For rolling or complex terrain (excluding generic sources numbers 1 and 11), use Step 7(A) (2).

<sup>6</sup>For the distance range 6 to 20 kilometers, generic source number 1 is used to conservatively represent the maximum dispersion coefficient.

(1) Search down the appropriate generic source number column [based on Step 5(C)], beginning at the minimum fenceline distance listed in Step 6(B). Record the maximum average hourly dispersion coefficient encountered.

 $^7$ Exclude all distances that are closer to the facility than the property boundary. For example, if the actual distance to the nearest property boundary is 265 meters, begin at the 300 meter distance in Tables 5.0-4 and 5.0-5.

Maximum Average Hourly Dispersion

Coefficient =  $(\mu/m^3/g/sec)$ 

(2) For each of the three distance-based generic source numbers listed in Step 5(E), search down the appropriate generic source number columns, beginning at the minimum fenceline distance listed in Step 6(B). Note that different columns may be used for each of the three distance ranges if there is a need for terrain adjustment. Record the maximum dispersion coefficient for each generic source number.

Distance range (km)	Generic source No. [from Step 5(E)]	Maximum dispersion coefficient (µg/m³/m/sec)
0.0-0.5		
>0.5-2.5		
>2.5-5.0		
>5.0-20.0		

Table 5.0-4.-ISCT Predicated Maximum Concentrations  $(\mu G/M^3)^a$  for Hazardous Waste Combustors Using Urban Conditions

Dis- tance (KM)	Gener- ic Source #1 (<10M)	Gener- ic Source #2 (10M)	Gener- ic Source #3 (15M)	Gener- ic Source #4 (20M)	Gener- ic Source #5 (25M)	Gener- ic Source #6 (31M)	Gener- ic Source #7 (42M)	Gener- ic Source #8 (53M)	Gener- ic Source #9 (65M)	Gener- ic Source #10 (113M)	Gener- ic Source #11 (Down- wash)
0.20 0.25 0.30 0.35 0.40 0.45 0.50 0.55 0.60 0.65 0.70 0.75 0.80 0.85 0.90	680.1 521.9 407.7 326.2 268.5 240.8 218.5 200.3 185.1 172.2 161.2 151.6 143.2 135.8 129.2 123.3 118.0	517.5 418.2 351.7 304.2 268.5 240.7 218.5 200.3 185.1 172.2 161.2 151.6 143.2 135.8 129.2 123.3 118.0	368.7 303.7 256.2 221.6 195.6 175.4 159.2 145.9 134.9 125.5 117.4 110.5 104.4 99.0 94.2 89.9 86.0	268.7 232.6 199.0 172.7 152.5 136.7 124.1 113.8 105.1 97.8 91.6 86.1 81.4 77.2 73.4 70.1 67.0	168.5 163.0 147.0 130.2 115.7 103.9 94.4 86.5 80.0 74.4 69.6 65.5 61.9 58.7 55.8 53.3 51.0	129.8 124.2 118.3 107.9 97.1 87.6 79.7 73.1 67.6 62.9 55.4 52.3 49.6 47.2 45.0 43.1	63.4 67.6 63.5 60.0 59.6 56.6 52.9 49.2 45.8 42.7 40.1 37.7 35.6 33.8 32.1 30.7 29.4	30.1 38.5 41.5 40.5 37.8 37.2 36.7 35.4 33.8 32.0 30.2 28.6 27.1 25.7 24.5 23.4 22.4	18.4 19.8 25.0 27.3 27.4 26.3 24.7 24.5 24.3 23.7 22.9 22.0 21.1 20.2 19.3 18.5 17.7	1.6 3.2 4.2 5.4 5.8 5.8 5.8 6.6 7.1 7.4 7.5 7.5 7.4 7.2 7.0 6.8 6.5	662.3 500.0 389.3 311.9 268.5 240.8 218.5 200.3 185.1 172.2 161.2 151.6 143.2 135.8 129.2 123.3 118.0

1.10	108.8	108.0	79.3	61.8	47.0	39.7	27.1	20.6	16.4	6.5	108.8
1.20	101.1	101.1	73.7	57.4	43.7	36.9	25.2	19.2	15.2	6.4	101.1
1.30	94.6	94.6	68.9	53.7	40.9	34.5	23.5	18.0	14.2	6.3	94.6
1.40	89.0	89.0	64.8	50.6	38.5	32.5	22.1	16.9	13.4	6.1	89.0
1.50	84.1	84.1	61.3	47.8	36.3	30.7	20.9	16.0	12.7	5.9	84.1
1.60	79.8	79.8	58.2	45.4	34.5	29.2	19.9	15.2	12.0	5.6	79.8
1.70	76.0	76.0	55.4	43.2	32.9	27.8	18.9	14.4	11.4	5.4	76.0
1.80	72.7	72.7	53.0	41.3	31.4	26.5	18.1	13.8	10.9	5.2	72.7
1.90	69.6	69.6	50.7	39.6	30.1	25.4	17.3	13.2	10.5	5.0	69.6
2.00	66.9	66.9	48.8	38.0	28.9	24.4	16.7	12.7	10.1	4.8	66.9
2.25	61.1	61.1	44.5	34.7	26.4	22.3	15.2	11.6	9.2	4.4	61.1
2.50	56.4	56.4	41.1	32.1	24.4	20.6	14.0	10.7	8.5	4.1	56.4
2.75	52.6	52.6	38.3	29.9	22.7	19.2	10.0	10.0	7.9	3.8	52.6
3.00	49.3	49.3	35.9	28.0	21.3	18.0	9.4	9.4	7.4	3.6	49.3
4.00	40.2	40.2	29.3	22.8	17.4	14.7	7.6	7.6	6.1	2.9	40.2
5.00	34.5	34.5	25.2	19.6	14.9	12.6	6.6	6.6	5.2	2.5	34.5
6.00	30.7	30.7	30.7	30.7	30.7	30.7	30.7	30.7	30.7	30.7	30.7
7.00	27.8	27.8	27.8	37.8	27.8	27.8	27.8	27.8	27.8	27.8	27.8
8.00	25.5	25.5	25.5	25.5	25.5	25.5	25.5	25.5	25.5	25.5	25.5
9.00	23.8	23.8	23.8	23.8	23.8	23.8	23.8	23.8	23.8	23.8	23.8
10.00	22.3	22.3	22.3	22.3	22.3	22.3	22.3	22.3	22.3	22.3	22.3
15.00	17.6	17.6	17.6	17.6	17.6	17.6	17.6	17.6	17.6	17.6	17.6
20.00	15.0	15.0	15.0	15.0	15.0	15.0	15.0	15.0	15.0	15.01	15.0

<sup>&</sup>lt;sup>a</sup>Based on a 1 Gram/Second Emission Rate

Table 5.0-5.-ISCT Predicated Maximum Concentrations  $(\mu G/M^3)^a$  for Hazardous Waste Combustors Using Urban Conditions

Dis- tance (KM)	Gener- ic Source #1 (<10M)	Gener- ic Source #2 (10M)	Gener- ic Source #3 (15M)	Gener- ic Source #4 (20M)	Gener- ic Source #5 (25M)	Gener- ic Source #6 (31M)	Gener- ic Source #7 (42M)	Gener- ic Source #8 (53M)	Gener- ic Source #9 (65M)	Gener- ic Source #10 (113M)	Gener- ic Source #11 (Down- wash)
0.20 0.25 0.30 0.35 0.40 0.45 0.50 0.55 0.60 0.65 0.70 0.75 0.80 0.85 0.90 0.95 1.00 1.10 1.20 1.30 1.40 1.50 1.60 1.70 1.80	1771.1 1310.6 1002.3 798.4 656.9 621.5 633.5 630.1 616.6 596.7 573.2 546.9 520.9 495.7 471.5 448.5 426.8 387.5 353.5 323.0 296.6 273.3 252.7 234.5 218.3	670.3 678.4 629.2 569.6 516.5 471.1 432.4 399.2 370.4 345.4 323.4 304.0 286.8 271.5 257.8 245.4 234.2 214.7 198.4 189.6 167.0 159.6 152.4	308.6 316.9 303.4 282.3 278.7 277.6 272.0 263.8 254.0 243.6 232.9 222.3 212.1 202.4 193.3 184.7 176.8 162.5 150.3 139.9 130.8 122.9 115.9 109.7	176.8 183.6 199.1 200.7 194.4 184.3 172.7 168.0 169.1 168.1 165.6 162.0 157.7 153.0 148.1 143.1 128.2 119.3 111.5 104.5 98.3 92.8 87.9 83.5	102.8 104.6 100.4 117.0 125.2 127.5 125.7 121.6 116.2 110.3 104.5 98.8 99.0 98.6 97.6 96.3 91.9 87.4 82.9 78.7 74.7 71.0 67.6 64.4	76.5 71.8 75.0 71.1 82.7 89.7 92.9 93.3 91.8 89.2 85.2 74.9 71.4 72.3 72.6 71.1 66.7 64.2 65.7 56.7 54.3	28.0 38.0 39.7 36.3 25.3 35.6 34.4 38.6 42.6 45.3 47.7 47.8 47.4 46.6 44.4 41.8 39.1 36.6 34.3 31.8 31.6 31.3	10.1 17.6 24.0 25.9 24.6 21.7 21.6 22.1 21.7 20.9 23.3 25.5 27.1 28.3 29.1 29.6 29.8 29.5 28.6 27.5 26.2 24.9 23.6 22.5 21.4	3.5 7.9 12.6 16.8 18.1 17.6 15.9 13.6 14.3 14.7 14.6 14.3 13.8 15.0 16.3 17.3 18.2 19.8 19.8 19.8 19.8 19.5 19.0 18.4 17.7	0.0 0.2 0.8 1.9 3.1 4.3 5.5 6.7 6.4 5.9 5.5 5.1 4.7 4.5 4.2 4.0 3.9 4.1 4.2 4.2 4.2 4.2 4.3 4.5	1350.8 1227.3 1119.3 1023.8 938.9 851.8 730.6 676.4 633.4 554.6 522.1 491.8 464.2 438.9 415.8 375.0 340.3 310.4 284.6 262.0 242.2 224.7 211.9

1.90	203.7	145.6	99.1	79.5	61.5	52.1	30.9	20.4	16.3	4.8	198.4
2.00	190.7	139.1	94.6	75.9	58.8	50.0	30.4	19.5	15.7	5.1	186.3
2.25	164.4	124.5	85.1	68.3	53.0	45.4	28.9	18.1	14.2	5.4	160.8
2.50	143.7	112.1	77.3	62.1	48.2	41.4	27.2	17.9	12.9	5.5	140.7
2.75	127.0	101.5	70.9	56.9	38.1	38.1	25.6	17.5	11.8	5.4	124.5
3.00	113.4	92.4	65.6	52.6	35.2	35.2	24.0	17.0	11.2	5.2	112.5
4.00	78.8	67.3	50.6	40.6	27.2	27.2	29.0	14.3	10.4	4.3	78.3
5.00	59.1	54.6	41.4	33.2	22.2	22.2	15.6	12.0	9.3	3.5	58.8
6.00	56.7	46.7	46.7	46.7	46.7	46.7	46.7	46.7	46.7	46.7	46.7
7.00	40.4	40.4	40.4	40.4	40.4	40.4	40.4	40.4	40.4	40.4	40.4
8.00	35.8	35.8	35.8	35.8	35.8	35.8	35.8	35.8	35.8	35.8	35.8
9.00	32.2	32.2	32.2	32.2	32.2	32.2	32.2	32.2	32.2	32.2	32.2
10.00	9.4	29.4	29.4	29.4	29.4	29.4	29.4	29.4	29.4	29.4	29.4
15.00	20.5	20.5	20.5	20.5	20.5	20.5	20.5	20.5	20.5	20.5	20.5
20.00	15.9	15.9	15.9	15.9	15.9	15.9	15.9	15.9	15.9	15.9	15.9

<sup>&</sup>lt;sup>a</sup>Based on a 1 Gram/Second Emission Rate

(B) Determine annual/hourly ratio for rural analysis. The maximum average annual dispersion coefficient is approximated by multiplying the maximum hourly dispersion coefficient (identified in Step 7(A) by the appropriate ratio selection from Table 5.0-6. The generic source number(s) [from Steps 5(C) or 5(E)], urban/rural designation (from Step 6), and the terrain type are used to select the appropriate scaling factor. Use the noncomplex terrain designation for all sources located in flat terrain, for all sources where the physical stack height of the worst-case stack is less than or equal to 10 m, for all sources where the worst-case stack is less than the minimum GEP, and for those sources where all of the TAESH values in Step 5(E) are greater than zero. Use the complex terrain designation in all other situations.

(C) Determine maximum average annual dispersion coefficient. The maximum average annual dispersion coefficient is determined by multiplying the maximum hourly dispersion coefficient (Step 7(A)) by its corresponding annual/hourly ratio (Step 7(B)).

Terrain	Distance from stack (m)	Generic source No.	Maximum hourly dispersion coefficient (µg/m³/g/sec)	Annual hourly ratio	Maximum annual dispersion coefficient (µg/m³/g/sec)¹
Flat	0-20.0 0-0.5 >0.5-2.5				
Rolling or Complex	>2.5-5.0 >5.0-20.0				

<sup>&</sup>lt;sup>1</sup>Maximum hourly dispersion coefficient times annual/hourly ratio.

Step 8: Estimate Maximum Ambient Air Concentrations-see procedures prescribed in subpart H of 40 CFR part 266.

Step 9: Determine Compliance with Regulatory Limits-see procedures prescribed in subpart H of 40 CFR part 266.

Step 10: Multiple Stack Method (Optional)

This option is a special case procedure that may be helpful when (1) the facility exceeded the regulatory limits for one or more pollutants, as

detailed in Step 9, and (2) the facility has multiple stacks with substantially different emission rates and effective release heights. Only those pollutants that fail the Step 9 screening limits need to be addressed in this exercise.

This procedure assesses the environmental impacts from each stack and then sums the results to estimate total impacts. This option is conceptually the same as the basic approach (Steps 1 through 9) and does not involve complex calculations. However, it is more time-consuming and is recommended only if the basic approach fails to meet the risk criteria. The procedure is outlined below.

(A) Compute effective stack heights for each stack.<sup>8</sup>
<sup>8</sup>Follow the procedure outlined in Step 4 of the basic screening procedure to determine the GEP for each stack. If a stack's physical height exceeds the maximum GEP, use the maximum GEP values. If a stack's physical height is less than the minimum GEP, use generic source number 11 in the subsequent steps of this analysis. Follow the procedure in Steps 5(A) and 5(B) to determine the effective height of each stack.

Stack No.	GEP stack height (m)	Flow rate (m³/sec)	Exit temp	Plume rise (m)	Effective stack height (m)
1					
<b>T</b>					
2					
3					

Add an additional page if more than three stacks are involved. Circle the maximum and minimum effective stack heights.

(B) Determine if this multiple-stack screening procedure will likely produce less conservative results than the procedure in Steps 1 through 9. To do this, compute the ratio of maximum-to-minimum effective stack height:

Maximum	Effective	Stack		
H€	eight			
	5		=	
				-

Minimum Effective Stack Height

Shortest Stack Height (m)

If the above ratio is greater than 1.25, proceed with the remaining steps. Otherwise, this option is less likely to significantly reduce the degree of conservatism in the screening method.

(C) Determine if terrain adjustment is needed and select generic source numbers. Select the shortest stack height and maximum terrain rise out to  $5~\rm km$  from Step 1 and determine if the facility is in flat terrain.

Shortest stack height (m) = \_\_\_\_

Maximum terrain rise in meters out to 5 km =

Terrain Rise (m) \_\_\_\_\_ X 100 = \_\_\_\_\_%

If the value above is greater than 10 percent, the terrain is considered nonflat; proceed to Step 10(D). If the ratio is less than or equal to 10 percent, the terrain is considered flat. Identify the generic source numbers based on effective stack heights computed in Step 10(A). Refer to Table 5.0-2 provided earlier to identify generic source numbers. Record the generic source numbers identified and proceed to Step 10(F).

	Stack No.		-
	1	2	3
Generic Source Numbers			

- (D) Compute the TAESH and select generic source numbers (four sources located in nonflat terrain).
- 1. Compute the TAESH for all remaining stacks using the following equation:

HE - TR = TAESH

where:

HE = effective stack height (m)

TR = maximum terrain rise for each distance range (m)

TAESH = terrain-adjusted effective stack height (m)

Use the Table Below To Calculate the TAESH for Each Stack9

	Stack No.														
	0-0.5			>0.5	>0.5-2.5				>2.5	>2.5-5.0					
Distance Range (km)	HE	_	TR	=	TAES H	НЕ	_	TR	=	TAES H	HE	_	TR	=	TAES H
1 2 3		- - -		= = =			- - -		= = =			- - -		= = =	

 $^9$ Refer to Step 1 for terrain adjustment data. Note that the distance from the source to the outer radii of each range is used. For example, for the range >0.5-2.5 km, the maximum terrain rise in the range 0.0-2.5 km is used.

For those stacks where the terrain rise within a distance range is greater than the effective stack height (i.e., HE-TR is less than zero), the TAESH for that distance range is set equal to zero, and generic source number 1 should be used for that distance range for all subsequent distance ranges. Additionally, for all stacks with a physical stack height of less than or equal to 10 meters, use generic source number 1 for all distance ranges. For the remaining stacks, proceed to Step 10(D)(2).

 $^{10}\mathrm{This}$  applies to all stacks less than or equal to 10 meters regardless of the terrain classification.

2. For the remaining stacks, refer to Table 5.0-2 and, for each distance range, identify the generic source number that includes the TAESH. Use the values obtained from Steps 10(D)(1) and 10(D)(2) to complete the following summary worksheet;

GENERIC SOURCE NUMBER AFTER TERRAIN ADJUSTED (IF NECESSARY)

Stack No.	0-0.5 km	>0.5-2.5 km	>2.5-5.0 km
1 2 3			

- (E) Identify maximum average hourly dispersion coefficients. Based on the land use classification of the site (e.g., urban or rural), use either Table 5.0-4 or Table 5.0-5 to determine the appropriate dispersion coefficient for each distance range for each stack. Begin at the minimum fenceline distance indicated in Step 7(B) and record on Worksheet 5.0-1 the dispersion coefficient for each stack/distance range. For stacks located in facilities in flat terrain, the generic source numbers were computed in Step 10(C). For stacks located in facilities in rolling and complex terrain, the generic source numbers were computed in Step 10(D). For flat terrain applications and for stacks with a physical height of less than or equal to 10 meters, only one generic source number is used per stack for all distance ranges. For other situations up to three generic source numbers may be needed per stack (i.e., a unique generic source number per distance range). In Tables 5.0-4 and 5.0-5, the dispersion coefficients for distances of 6 km to 20 km are the same for all generic source numbers in order to conservatively represent terrain beyond 5 km (past the limits of the terrain analysis).
- >>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<
- (F) Estimate maximum hourly ambient air concentrations. In this step, pollutant-specific emission rates are multiplied by appropriate dispersion coefficients to estimate ambient air concentrations. For each stack, emissions are multiplied by the dispersion coefficient selected in Step 10(E) and summed across all stacks to estimate ambient air concentrations at various distances from the facility. From these summed concentrations, the maximum hourly ambient air concentration is selected. First, select the maximum emission rate of the pollutant. Record these data in the spaces provided below.

<sup>11</sup>Recall that it is recommended that this analysis be performed for only one or two pollutants. The pollutants chosen for this analysis should be those that show the most significant exceedances of the risk threshold.

<sup>12</sup>Refer to Step 8 of the basic screening procedure. At this point in the screening procedure, annual emissions are used to represent hourly

average emission rates. These values will be adjusted by the annual/hourly ratio to estimate annual average concentrations.

Maximum Annual Emission Rates (g/sec)

Pollutant	Stack 1	Stack 2	Stack 3

Complete a separate copy of Worksheet 5.0-2 for each pollutant and select the highest hourly concentration from the summation column at the far right of the worksheet. Record the maximum hourly air concentration for each pollutant analyzed (add additional lines if needed):

Pollutant Maximum hourly air concentration

>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<<  $\,$ 

(G) Determine the complex/noncomplex designation for each stack. For each stack, subtract the maximum terrain rise within 5 km of the site from the physical stack height and designate the stack as either complex or noncomplex. If the stack height minus the maximum terrain rise (within 5 km) is greater than zero or if the stack is less than 10 meters in physical height, then assign the stack a noncomplex designation. If the stack height minus the maximum terrain rise (within 5 km) is less than or equal to zero, then assign the stack a complex designation.

Perform the following computation for each stack and record the information in the spaces provided. Check in the spaces provided whether the stack designation is complex or noncomplex.

Stack No.	Stack height (m)		Maximum terrain rise (m)			Complex	Noncomple x
1 2 3		- - -		= = =	(m) (m) (m)		

(H) Identify annual/hourly ratios. Extract the annual/hourly ratios for each stack by referring to Table 5.0-6. Generic source numbers (from Steps 10(C) or 10(D), urban/rural designation (from Step 6)), and complex or noncomplex terrain designations (from Step 10(G)) are used to select the

appropriate scaling factor needed to convert hourly maximum concentrations to estimates of annual average concentrations.

Complete the following table: 13

<sup>13</sup>If any stack (excluding generic stack number 1 and 11) in Step 10(D) shows a negative terrain adjusted stack height, use the complex terrain annual/hourly ratios.

6)	Generic sour	cce No. steps	10 (C or D)	Annual/hour	ly ratio (from	n table 5.0-
Stack No.	Distance ran	nges (km)		Distance ra	nges (km)	
	0-0.5	>0.5-2.5	>2.5-5.0	0-0.5	>0.5-2.5	>2.5-5.0
1 2 3						

(I) Select the highest annual/hourly ratio among all of the stacks, $^{14}$  and then estimate the maximum annual average ambient air concentrations for each pollutant by completing the following table, where:

<sup>14</sup>As an option, the user can identify the stack with the highest ratio for each distance range (rather than the absolute highest). In this case, extra sheets would be needed to show estimated annual average concentrations from each stack by multiplying emission rate times maximum hourly dispersion coefficient times maximum annual/hourly ratio for applicable distance range. Then sum across all stacks for each downwind distance.

- C = Maximum total hourly ambient air concentration  $(\mu g/m^3)$  for pollutant "N" from Step 10(F),
- $C_a$  = Maximum annual average air concentration for pollutant "N" ( $\mu g/m^3$ ),
- R = Annual/hourly ratio.

Table 5.0-6.-95th Percentile of Annual/Hourly Ratios

Noncomplex	Complex
Terrain	Terrain

Source	Urban	Rural	Source	Urban	Rural
1	0.019	0.014	1	0.020	0.053
2	0.033	0.019	2	0.020	0.053
3	0.031	0.018	3	0.030	0.057
4	0.029	0.017	4	0.051	0.047
5	0.028	0.017	5	0.067	0.039
6	0.028	0.017	6	0.059	0.034
7	0.031	0.015	7	0.036	0.031
8	0.030	0.013	8	0.026	0.024
9	0.029	0.011	9	0.026	0.024

11	0.018	0.015	11	0.020	0.053			
	Pollutant		$C_a (\mu g/m^3) X R = C_a (\mu g/m^3)$					
				X		=		
				x	- =			

0.029 0.008 10 0.017 0.013

 $(\mathtt{J})$  Use the maximum annual average concentrations from Step 10(I) to determine compliance with regulatory requirements.

SECTION 6.0-SIMPLIFIED LAND USE CLASSIFICATION PROCEDURE FOR COMPLIANCE WITH TIER I AND TIER II LIMITS

#### 6.1 Introduction

10

This section provides a simplified procedure to classify areas in the vicinity of boilers and industrial furnace sites as urban or rural in order to set risk-based emission limits under subpart H of 40 CFR part 266. Urban/rural classification is needed because dispersion rates differ between urban and rural areas and thus, the risk per unit emission rate differs accordingly. The combination of greater surface roughness (more buildings/structures to generate turbulent mixing) and the greater amount of heat released from the surface in an urban area (generates buoyancy-induced mixing) produces greater rates of dispersion. The emission limit tables in the regulation, therefore, distinguish between urban and rural areas.

EPA guidance (EPA 1986) provides two alternative procedures to determine whether the character of an area is predominantly urban or rural. One procedure is based on land use typing and the other is based on population density. Both procedures require consideration of characteristics within a 3-km radius from a source, in this case the facility stack(s). The land use typing method is preferred because it more directly relates to the surface characteristics that affect dispersion rates. The remainder of this discussion is, therefore, focused on the land use method.

While the land use method is more direct, it can also be labor-intensive to apply. For this discussion, the land use method has been simplified so that it is consistent with EPA guidance (EPA 1986; Auer 3978), while streamlining the process for the majority of applications so that a clear-cut decision can be made without the need for detailed analysis. Table 6.0-1 summarizes the simplified approach for classifying areas as urban or rural. As shown, the applicant always has the option of applying standard (i.e., more detailed) analyses to more accurately distinguish between urban and rural areas. However, the procedure presented here allows for simplified determinations, where appropriate, to expedite the permitting process.

Table 6.0-1.-Classification of Land Use Types

Type<sup>1</sup> Description Urban or rural

I1	Heavy Industrial	Urban.
I2	Light/Moderate Industrial	Urban.
C1	Commercial	Urban.
R1	Common Residential (Normal	Rural.
	Easements)	
R2	Compact Residential (Single	Urban.
	Family)	
R3	Compact Residential (Multi-	Urban.
	Family)	
R4	Estate Residential (Multi-	Rural.
	Acre Plots)	
A1	Metropolitan Natural	Rural.
A2	Agricultural	Rural.
A3	Undeveloped (Grasses/Weeds)	Rural.
A4	Undeveloped (Heavily Wooded)	Rural.
A5	Water Surfaces	Rural.

<sup>1</sup>EPA, Guideline on Air Quality Models (Revised), EPA-450/2-78-027, Office of Air Quality Planning and Standards, Research Triangle Park, North Carolina, July, 1986.

<sup>2</sup>Auer, August H. Jr., "Correlation of Land Use and Cover with Meteorological Anomalies," Journal of Applied Meteorology, pp. 636-643, 1978.

# 6.2 Simplified Land Use Process

The land use approach considers four primary land use types: industrial (I), commercial (C), residential (R), and agricultural (A). Within These primary classes, subclasses are identified, as shown in table 6.0-1. The goal is to estimate the percentage of the area within a 3-km radius that is urban type and the percentage that is rural type. Industrial and commercial areas are classified as urban; agricultural areas are classified as rural.

The delineation of urban and rural areas, however, can be more difficult for the residential type areas shown in table 6.0-1. The degree of resolution shown in table 6.0-1 for residential areas often cannot be identified without conducting site area inspections and/or referring to zoning maps. This process can require extensive analysis, which, for many applications, can be greatly streamlined without sacrificing confidence in selecting the appropriate urban or rural classification.

The fundamental simplifying assumption is based on the premise that many applications will have clear-cut urban/rural designations, i.e., most will be in rural settings that can be definitively characterized through a brief review of topographical maps. The color coding on USGS topographical maps provides the most effective means of simplifying the typing scheme. The suggested typing designations for the color codes found on topographical maps are as follows:

Green Wooded areas (rural).

White White areas generally will be treated as rural. This code applies to areas that are unwooded and do not have densely packed structures which would require the pink code (house omission tint). Parks, industrial areas, and unforested rural land will appear as white on the topographical maps. Of these categories, only the industrial areas could potentially be classified as urban based on EPA 1986 or Auer 1978. Industrial areas can be easily identified in most cases by the characteristics shown in Figure 6.0-1. For this simplified procedure, white areas that have an industrial classification will be treated as urban areas.

>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<

#### SECTION 7.0 STATISTICAL METHODOLOGY FOR BEVILL RESIDUE DETERMINATIONS

This section describes the statistical comparison of waste-derived residue to normal residue for use in determining eligibility for the Bevill exemption under 40 CFR 266.112.

# 7.1 Comparison of Waste-derived Residue with Normal Residue

To meet the special criteria under § 266.112(b)(1), waste-derived residue must not contain appendix VIII, Part 261, constituents (toxic constituents) at concentrations significantly higher than in residue generated without burning or processing hazardous waste. Concentrations of toxic constituents in normal residue are determined based on analysis of a minimum of 10 composite samples. (Note that "normal" residue refers to residue generated by a facility when operating without burning hazardous waste.) The 95th percent confidence interval about the mean of the normal residue concentrations must be used in the comparison of waste-derived residue with normal residue; the confidence interval is determined as described in section 7.2 below. The concentration of a toxic constituent in the waste-derived residue is not considered to be significantly higher than in the normal residue if the concentration in the waste-derived residue does not exceed the upper 95th percent confidence interval about the mean that was established for the normal residue. Concentrations of toxic constituents in waste-derived residue are determined based on analysis of samples taken over a compositing period of not more than 24 hours.

7.2. Calculation of the 95th Percent Confidence Interval About the Mean for Toxic Constituents in Normal Residue

The 95th percent confidence interval about the mean is calculated for a set of values using a "t" distribution. In use of the "t" distribution, it is assumed that the values are normally distributed; the "t" distribution is applicable for use with small sample sets (i.e. approximately 10-30 samples). The 95th percent confidence interval about the mean is determined using the following equation:

95th percent confidence interval = 1 X t  $\propto$  2 (s/ $\sqrt{n}$ ) where X = mean of the normal residue concentrations,

>>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<<

```
\propto = the level of significance = 0.05, s = standard deviation of the normal residue concentrations,
```

>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<<

and

n = sample size.

The values of the "t" distribution at the  $\propto$  2 level of significance and n - 1 degrees of freedom are given in table 7.0-1.

For example, a normal residue test results in 10 samples with the following analysis results for toxic compound A:

Sample No.	Concentration of compound A (ppm)	
1	10	
2	10	
3	15	
4	10	
5	7	
6	12	
7	10	
8	16	
9	15	
10	10	

The mean and standard deviation of these measurements, calculated using equations above, are 11.5 and 2.9 respectively. Assuming that the values are normally distributed, the upper 95th percent confidence interval value about the mean is given by:

Table 7.0-1.-t Distribution Values

Degrees of freedom (n-1)	Percentage point of t distribution ∝ / 2 = 0.025	
1	12.706	
2	4.303	
3	3.182	
4	2.776	
5 6	2.571	
б	2.447	
7	2.365	
8	2.306	
9	2.262	
10	2.228	
11	2.201	
12	2.179	
13	2.160	
14	2.145	
15	2.131	
16	2.120	
17	2.110	
18	2.101	
19	2.093	
20	2.086	
21	2.080	
22	2.074	
23	2.069	
24	2.064	
25	2.060	
26	2.056	
27	2.052	
28	2.048	
29	2.045	

95th percent confidence interval value = 11.5 + 2.262 X (2.9 $\sqrt{10}$ ) = 13.6 ppm.

Thus, if the concentration of compound A in the waste-derived residue is below 13.6 ppm, then the waste-derived residue is eligible for the Bevill exemption for toxic compound A.

## 7.3 Normal Distribution Assumption

As noted in section 7.2 above, this statistical approach (use of the 95th percent confidence interval about the mean) for calculation of the concentration in normal residue is based on the assumption that the concentration data are distributed normally. The Agency is aware that concentration data of this type may not be distributed normally, particularly when concentrations are near the detection limits. There are a number of procedures that can be used to test the distribution of a data set. For example, the Shapiro-Wilk test, examination of a histogram or plot of the data on normal probability paper, and examination of the coefficient of skewness are methods that may be applicable, depending on the nature of the data (Reference 1 and 2).

If the concentration data are not adequately represented by a normal distribution, the data may be transformed to attain a near normal distribution. The Agency has found that concentration data, especially when near detection levels, often exhibit a lognormal distribution. The assumption of a lognormal distribution has been used in various programs at EPA, such as in the Office of Solid Waste Land Disposal Restrictions program for determination of BDAT treatment standards. The transformed data may be tested for normality using the procedures identified above. If the transformed data are better represented by a normal distribution than the untransformed data, the transformed data should be used in determining the 95th percent confidence interval using the procedures in section 7.2 above.

In all cases where the applicant for the Bevill exemption wishes to use other than an assumption of normally distributed data, or believes that use of an alternate statistical approach is appropriate to the specific data set, the applicant must provide supporting rationale and demonstrate to the Director or permitting authority that the data treatment is based upon sound statistical practice.

# 7.4 Nondetect Values

The Agency is developing guidance regarding the treatment of nondetect values (data where the concentration of the constituent being measured is below the lowest concentration for which the analytical method is valid) in carrying out the statistical determinations described above. Until the guidance information is available, facilities may present their own approach to the handling of nondetect data points, but must provide supporting rationale in the operating record for consideration by the Director or permitting authority.

# 7.5 References

- 1. Shapiro, S.S. and Wilk, M.B. (1965), "An Analysis of Variance Test for Normality (complete samples)," Biometrika, 591-611.
- 2. Bhattacharyya, G.K. and R.A. Johnson (1977), Statistical Concepts and Methods, John Wiley and Sons, New York.

SECTION 8.0 PROCEDURES FOR DETERMINING DEFAULT VALUES FOR AIR POLLUTION CONTROL SYSTEM REMOVAL EFFICIENCIES

During interim status, owners or operators of boilers and industrial furnaces burning hazardous waste must submit documentation to EPA that certifies that emissions of HCl,  $\rm Cl_2$ , metals, and particulate matter (PM) are not likely to exceed allowable emission rates. See certification of precompliance under 40 CFR 266.103(b). This documentation also establishes interim status feed rate and operating limits for the facility. For the initial certification, estimates of emissions and system removal efficiencies (SREs) can be made to establish the operating limits. Subsequently, owners or operators must use emissions testing to demonstrate that emissions do not exceed allowable levels, and to establish operating limits. See 40 CFR 266.103(c). However, initial estimates of emissions for certification of precompliance can be based on estimated or established SREs.

The SRE combines the effect of partitioning of the chorine, metals, or PM and the air pollution control system removal efficiency (APCS RE) for these pollutants. The SRE is defined as:

SRE = (species input-species emitted) / species input

The SRE can be calculated from the partitioning factor (PF) and APCS RE by the following formula:

SRE = 1-[(PF/100) X (1-APCS RE/100)]

where:

PF = percentage of the pollutant partitioned to the combustion gas

Estimates of the PF and/or the APCS RE can be based on either EPA's default values or engineering judgement. EPA's `default values for the APCS RE for metals, HCl,  $Cl_2$ , and PM are described in this section. EPA's default values for partitioning of these pollutants are described in section 9.0.

Guidelines for the use of engineering judgement to estimate APCS REs or PFs are described in section 9.4.

# 8.1 APCS RE Default Values for Metals

EPA's default assumptions for APCS RE for metals are shown in Table 8.1-1. The default values in the table are conservative estimates of the removal efficiencies for metals in BIFs, depending on the volatility of the metal and the type of APCS.

The volatility of a metal depends on the temperature, the thermal input, the chlorine content of the waste, and the identity and concentration of the metal. Metals that do not vaporize at combustion zone temperatures are classified as "nonvolatile". Such metals typically enter the APCS in the form of large particles that are removed relatively easily. Metals that vaporize in the combustion zone and condense before entering the APCS are classified as "volatile". Such metals typically enter the APCS in the form of very fine, submicron particles that are rather inefficiently removed in many APCSs. Metals that vaporize in the combustion zone and do not condense before entering the APCS are classified as "very volatile". Such metals enter the APCS in the form of a vapor that is very inefficiently removed in many APCSs.

Typically, BIFs have combustion zone temperatures high enough to vaporize any hazardous metal at concentrations sufficient to exceed risk-based emission limits. For this reason, the default assumption is that there are no nonvolatile metals. Tables 8.1-2 and 8.1-3 are used to determine whether metals are classified as "volatile" or "very volatile" depending on the

temperature entering the APCS, the thermal input, and whether the waste is chlorinated or nonchlorinated.

Table 8.1-1.-Air Pollution Control Systems (APCS) and Their Conservatively Estimated Efficiencies for Controlling Toxic Metals (%)

	Metal Volatility	Metal Volatility				
APCS	Nonvolatile	Volatile	Very Volatile			
WS VS-20 VS-60 ESP-1 ESP-2 ESP-4 WESP FF SD/FF DS/FF	40 80 87 90 92 95 90 97 95	30 75 75 75 80 80 85 80 90 90	20 20 40 0 0 0 40 0 0 0 0			

WS = Wet Scrubber including: Sieve Tray Tower, Packed Tower, Bubble Cap Tower VS-20 = Venturi Scrubber, ca. 20-30 in W.G.)p

VS.60 =Venturi Scrubber, ca. >60 in W.G. )p

ESP-1= Electrostatic Precipitator; 1 stage ESP-2 =Electrostatic Precipitator; 2 stage

Electrostatic Precipitator; 4 stage ESP-4 =

IWS = Ionizing Wet Scrubber

DS = Dry Scrubber FF = Fabric Filter (Baghouse) SD = Spray Dryer (Wet/Dry Scrubber)

WESP = Wet Electrostatic Precipitator

Table 8.1-2.-Temperature (F) Entering APCS Above Which Metals Are Classified as Very Volatile in Combustion of Nonchlorinated Wastes

Metal		Thermal Input (MMBtu/hr	·)¹			
Name	Symbol	1	10	100	1000	10000
Arsenic Cadmium Chromium Beryllium Antimony	As Cd Cr Be Sb	320 1040 2000 1680 680	280 940 1760 1440 600	240 860 1580 1240 540	200 780 1420 1080 480	160 720 1380 980 420

Barium	Ва	2240	1820	1540	1360	1240
Lead	Pb	1280	1180	1080	1000	920
Mercury	Hg	340	300	260	220	180
Silver	Ag	1820	1640	1480	1340	1220
Thallium	Tl	900	800	700	620	540

<sup>1</sup>Interpolation of thermal input is not allowed. If a BIF fires between two ranges, the APCS temperature under the higher thermal input must be used. Example: For a BIF firing 10-100 MMBtu/hr, Mercury is considered very volatile at APCS temperatures above 260 F and volatile at APCS temperatures of 260 F and below.

Table 8.1-3.-Temperature (F) Entering APCS Above Which Metals Are Classified as Very Volatile In Combustion of Chlorinated Wastes

Metal		Thermal Input (MMBtu/h:	r) <sup>1</sup>			
Name	Symbol	1	10	100	1000	10000
Arsenic	As	320	280	240	200	160
Cadmium	Cd	1040	940	860	780	720
Chromium	Cr	>140	>140	>140	>140	>140
Beryllium	Ве	1680	1440	1240	1080	980
Antimony	Sb	680	600	540	480	420
Barium	Ва	2060	1840	1680	1540	1420
Lead	Pb	>140	>140	>140	>140	>140
Mercury	Hg	340	300	260	220	180
Silver	Ag	1080	940	840	740	660
Thallium	Tl	900	800	700	620	540

<sup>1</sup>Interpolation of thermal input is not allowed. If a BIF fires between two ranges, the APCS temperature under the higher thermal input must be used. Example: For a BIF firing 10-100 MMBtu/hr, Mercury is considered very volatile at APCS temperatures above 260 F and volatile at APCS temperatures of 260 F and below.

A waste is considered chlorinated if chlorine is present in concentrations greater than 0.1 percent by weight. In the EPA guidance document "Guidance for Metals and Hydrogen Chloride Controls for Hazardous Waste Incinerators, Volume IV of the Hazardous Waste Incineration Guidance Series,"(1) one percent is used for the chlorinated/nonchlorinated cutoff. However, best engineering judgement, based on examination of pilot-scale data reported by Carroll et al. (2) on the effects of waste chlorine content on metals emissions, suggests that the 1 percent cutoff may not be sufficiently conservative.

Tables 8.1-2 and 8.1-3 were compiled based on equilibrium calculations. Metals are classified as very volatile at all temperatures above the temperature at which the vapor pressure of the metal is greater than 10 percent of the vapor pressure that results in emissions exceeding the most conservative risk-based emissions limits.

## 8.2 APCS RE Default Values for HCl and Cl<sub>2</sub>

Default assumptions for APCS RE for HCl in BIFs are shown in Table 8.2-1. This table is identical to the column for other BIFs except that cement

kilns have a minimum HCl removal efficiency of 83 percent. Because of the alkaline nature of the raw materials in cement kilns, most of the chlorine is converted to chloride salts. Thus, the minimum APCS RE for HCl for cement kilns is independent of the APCS train.

Removal efficiency of  ${\rm Cl_2}$  for most types of APCS is generally minimal. Therefore, the default assumption for APCS RE for  ${\rm Cl_2}$  for all APCSs is 0 percent. This is applicable to all BIFs, including cement kilns.

#### 8.3 APCS RE Default Values for Ash

Default assumptions for APCS RE for PM are also shown in Table 8.1-4. These figures are conservative estimates of PM removal efficiencies for different types of APCSs. They are identical to the figures in the Nonvolatile APCS RE column for hazardous metals presented in Table 8.1-1 because the same collection mechanisms and collection efficiencies that apply to nonvolatile metals also apply to PM.

Table 8.2-1.-Air Pollution Control Systems (APCS) and Their conservatively Estimated Efficiencies for Removing Hydrogen Chloride (HCl) and Particulate Matter (PM) (%)

	HC1					
APCD	Cement kilns	Other BIFs	PM			
	97	97	40			
VS-20	97	97	80			
VS-60	98	98	87			
ESP-1	83	0	90			
ESP-2	83	0	92			
ESP-4	83	0	95			
WESP	83	70	90			
FF	83	0	90			
SD/FF	98	98	97			
DS/FF	98	98	95			
WS/IWS	99	99	95			
IWS	99	99	90			

- WS = Wet Scrubber including: Sieve Tray Tower, Packed Tower, Bubble Cap Tower
- PS = Proprietary Wet Scrubber Design (A number of proprietary wet scrubbers have come on the market in recent years that are highly efficient on both particulates and corrosive gases. Two such units are offered by Calvert Environmental Equipment Co. and by Hydro-Sonic Systems, Inc.).
- VS-20 = Venturi Scrubber, ca. 20-30 in W.G. )p
  VS-60 = Venturi Scrubber, ca. >60 in W.G. )p
  ESP-1 = Electrostatic Precipitator; 1 stage
- ESP-2 = Electrostatic Precipitator; 2 stage
  ESP-4 = Electrostatic Precipitator; 4 stage
- IWS = Ionizing Wet Scrubber
- DS = Dry Scrubber
- FF = Fabric Filter (Baghouse)
- SD = Spray Dryer (Wet/Dry Scrubber)

## 8.4 References

- 1. U.S. Environmental Protection Agency. "Guidance on Metals and Hydrogen Chloride Controls for Hazardous Waste Incinerators," Office of Solid Waste, Washington, D.C., August 1989.
- 2. Carroll, G.J., R.C. Thurnau, R.E. Maurnighan, L.R. Waterland, J.W. Lee, and D.J. Fournier. The Partitioning of Metals in Rotary Kiln Incineration. Proceedings of the Third International Conference on New Frontiers for Hazardous Waste Management. NTIS Document No. EPA/600/9-89/072, p. 555 (1989).

SECTION 9.0 PROCEDURES FOR DETERMINING DEFAULT VALUES FOR PARTITIONING OF METALS, ASH, AND TOTAL CHLORIDE/CHLORINE

Pollutant partitioning factor estimates can come from two sources: default assumptions or engineering judgement. EPA's default assumptions are discussed below for metals, HCl,  $Cl_2$ , and PM. The default assumptions are used to conservatively predict the partitioning factor for several types of BIFs. Engineering judgement-based partitioning factor estimates are discussed in section 9.4.

# 9.1 Partitioning Default Value for Metals

To be conservative, the Agency is assuming that 100 percent of each metal in each feed stream is partitioned to the combustion gas. Owners/operators may use this default value or a supportable, site-specific value developed following the general guidelines provided in section 9.4.

# 9.2 Special Procedures for Chlorine, HCl, and Cl<sub>2</sub>

The Agency has established the special procedures presented below for chlorine because the emission limits are based on the pollutants HCl and  ${\rm Cl_2}$  formed from chlorine fed to the combustor. Therefore, the owner/operator must estimate the controlled emission rate of both HCl and  ${\rm Cl_2}$  and show that they do not exceed allowable levels.

- 1. The default partitioning value for the fraction of chlorine in the total feed streams that is partitioned to combustion gas is 100 percent. Owners/operators may use this default value or a supportable, site-specific value developed following the general guidelines provided in section 9.4.
- 2. To determine the partitioning of chlorine in the combustion gas to HCl versus  $Cl_2$ , either use the default values below or use supportable sitespecific values developed following the general guidelines provided in section 9.4.
- ullet For BIFs excluding halogen acid furnaces (HAFs), with a total feed stream chlorine/hydrogen ratio  ${\scriptstyle \geq}0.95$ , the default partitioning factor is 20 percent Cl<sub>2</sub>, 80 percent HCl.
- $\bullet$  For HAFs and for BIFs with a total feed stream chlorine/hydrogen ratio >0.95, the default partitioning factor is 100 percent Cl $_2$ .
- 3. To determine the uncontrolled (i.e., prior to acid gas APCS) emission rate of HCl and  $\text{Cl}_2$ , multiply the feed rate of chlorine times the partitioning factor for each pollutant. Then, for HCl, convert the chorine emission rate to HCl by multiplying it by the ratio of the molecular weight of Cl to the molecular weight of HCl (i.e., 35.5/36.5). No conversion is needed for  $\text{Cl}_2$ .

# 9.3 Special Procedures for Ash

This section: (1) Explains why ash feed rate limits are not applicable to cement and light-weight aggregate kilns; (2) presents the default partitioning values for ash; and (3) explains how to convert the 0.08 gr/dscf, corrected to 7%  $O_2$ , PM emission limit to a PM emission rate.

Waiver for Cement and Light-Weight Aggregate Kilns. For cement kilns and light-weight aggregate kilns, raw material feed streams contain the vast majority of the ash input, and a significant amount of the ash in the feed stream is entrained into the kiln exhaust gas. For these devices, the ash content of the hazardous waste stream is expected to have a negligible effect on total ash emissions. For this reason, there is no ash feed rate compliance limit for cement kilns or light-weight aggregate kilns. Nonetheless, cement kilns and light-weight aggregate kilns are required to initially certify that PM emissions are not likely to exceed the PM limit, and subsequently, certify through compliance testing that the PM limit is not exceeded.

Default Partitioning Value for Ash. The default assumption for partitioning of ash depends on the feed stream firing system. There are two methods by which materials may be fired into BIFs: Suspension-firing and bed-firing.

The suspension category includes atomized and lanced pumpable liquids and suspension-fired pulverized solids. The default partitioning assumption for materials fired by these systems is that 100 percent of the ash partitions to the combustion gas.

The bed-fired category consists principally of stoker boilers and raw materials (and in some cases containerized hazardous waste) fed into cement and light-weight aggregate kilns. The default partitioning assumption for materials fired on a bed is that 5 percent of the ash partitions to the combustion gas.

Converting the PM Concentration-Based Standard to a PM Mass Emission Rate. The emission limit for BIFs is 0.08 gr/dscf, corrected to 7%  $0_2$ , unless a more stringent standard applies [e.g., a New Source Performance Standard (NSPS) or a State standard implemented under the State Implementation Plan (SIP)]. To convert the 0.08 gr/dscf standard to a PM mass emission rate:

- 1. Determine the flue gas  $\theta_2$  concentration (percent by volume, dry) and flue gas flow rate (dry standard cubic feet per minute); and
- 2. Calculate the allowable PM mass emission rate by multiplying the concentration-based PM emission standard times the flue gas flow rate times a dilution correction factor equal to  $[(21-0_2 \text{ concentration from step } 1)/(21-7)]$ .
- 9.4 Use of Engineering Judgement To Estimate Partitioning and APCS RE Values

Engineering judgement may be used in place of EPA's conservative default assumptions to estimate partitioning and APCS RE values provided that the engineering judgement is defensible and properly documented. To properly document engineering judgement, the owner/operator must keep a written record of all assumptions and calculations necessary to justify the APCS RE used. The owner/operator must provide this record to the Director upon request and must be prepared to defend the assumptions and calculations used.

If the engineering judgement is based on emissions testing, the testing will often document the emission rate of a pollutant relative to the feed rate of that pollutant rather than the partitioning factor or APCS RE.

Examples of situations where the use of engineering judgement may be supportable to estimate a partitioning factor, APCS RE, or SRE include:

- Using emissions testing data from the facility to support an SRE, even though the testing may not meet full QA/QC procedures (e.g., triplicate test runs). The closer the test results conform with full QA/QC procedures and the closer the operating conditions during the test conform with the established operating conditions for the facility, the more supportable the engineering judgement will be.
- Applying emissions testing data documenting an SRE for one metal, including nonhazardous surrogate metals to another less volatile metal.
- $\bullet$  Applying emissions testing data documenting an SRE from one facility to a similar facility.
  - Using APCS vendor guarantees of removal efficiency.

#### 9.5 Restrictions on Use of Test Data

The measurement of an SRE or an APCS RE may be limited by the detection limits of the measurement technique. If the emission of a pollutant is undetectable, then the calculation of SRE or APCS RE should be based on the lower limit of detectability. An SRE or APCS RE of 100 percent is not acceptable.

Further, mass balance data of facility inputs, emissions, and products/residues may not be used to support a partitioning factor, given the inherent uncertainties of such procedures. Partitioning factors other than the default values may be supported based on engineering judgement, considering, for example, process chemistry. Emissions test data may be used to support an engineering judgement-based SRE, which includes both partitioning and APCS RE.

# 9.5 References

1. Barton, R.G., W.D. Clark, and W.R. Seeker. (1990) "Fate of Metals in Waste Combustion Systems". Combustion Science and Technology. 74, 1-6, p. 327

SECTION 10.0 ALTERNATIVE METHODOLOGY FOR IMPLEMENTING METALS CONTROLS

# 10.1 Applicability

This method for controlling metals emissions applies to cement kilns and other industrial furnaces operating under interim status that recycle emission control residue back into the furnace.

# 10.2 Introduction

Under this method, cement kilns and other industrial furnaces that recycle emission control residue back into the furnace must comply with a kiln dust concentration limit (i.e., a collected particulate matter (PM) limit) for each metal, as well as limits on the maximum feedrates of each of the metals in: (1) pumpable hazardous waste; and (2) all hazardous waste.

The following subsections describe how this method for controlling metals emissions is to be implemented:

• Subsection 10.3 discusses the basis of the method and the assumptions upon which it is founded;

- ullet Subsection 10.4 provides an overview of the implementation of the method;
- Subsection 10.5 is a step-by-step procedure for implementation of the method;
- ullet Subsection 10.6 dascribes the compliance procedures for this method; and
- $\bullet$  Appendix A describes the statistical calculations and tests to be used in the method.

#### 10.3 Basis

The viability of this method depends on three fundamental assumptions:

- (1) Variations in the ratio of the metal concentration in the emitted particulate to the metal concentration in the collected kiln dust (referred to as the enrichment factor or EF) for any given metal at any given facility will fall within a normal distribution that can be experimentally determined.
- (2) The metal concentrations in the collected kiln dust can be accurately and representatively measured (using procedures specified in "Test Methods for Evaluating Solid Waste, Physical/Chemical Methods" (SW-846), incorporated by reference in 40 CFR 260.11).
- (3) The facility will remain in compliance with the applicable particulate matter (PM) emission standard.

Given these assumptions. metal emissions can be related to the measured concentrations in the collected kiln dust by the following equation:

>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<<

### Where:

ME is the metal emitted; PME is the particulate matter emitted; DMC is the metal concentration in the collected kiln dust; and EF is the enrichment factor, which is the ratio of the metal concentration in the emitted particulate matter to the metal concentration in the collected kiln dust.

This equation can be rearranged to calculate a maximum allowable dust metal concentration limit (DMCL) by assuming worst-case conditions that: metal emissions are at the Tier III (or Tier II) limit (see 40 CFR 266.106), and that particulate emissions are at the particulate matter limit (PML):

>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<

The enrichment factor used in the above equation must be determined experimentally from a minimum of 10 tests in which metal concentrations are measured in kiln dust and stack samples taken simultaneously. This approach provides a range of enrichment factors that can be inserted into a statistical distribution (t-distribution) to determine  $\mathrm{EF}_{95k}$  and  $\mathrm{EF}_{99k}$ .  $\mathrm{EF}_{95k}$  is the value at which there is a 95% confidence level that the enrichment factor is below this value at any given time. Similarly,  $\mathrm{EF}_{99k}$  is the value at which there is a 99% confidence level that the enrichment factor is below this value at any given time.  $\mathrm{EF}_{95k}$  is used to calculate the "violation" dust metal concentration limit (DMCL<sub>v</sub>):

>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<

If the kiln dust metal concentration is just above this "violation" limit, and the PM emissions are at the PM emissions limit, there is a 5% chance that the metal emissions are above the Tier III limit. In such a case, the facility would be in violation of the metals standard.

To provide a margin of safety, a second, more conservative kiln dust metal concentration limit is also used. This "conservative" dust metal concentration limit (DMCL $_{\rm c}$ ) is calculated using a "safe" enrichment factor (SEF). If EF $_{99\$}$  is greater than two times the value of EF $_{95\$}$ , the "safe" enrichment factor can be calculated using Equation 4a:

 $SEF > 2 EF_{95\%}$  (4a)

If  $EF_{99\$}$  is not greater than two times the value of  $EF_{95\$}$ , the "safe" enrichment factor can be calculated using Equation 4b:

 $SEF > EF_{99\%}$  (4b)

In cases where the enrichment factor cannot be determined because the kiln dust metal concentration is nondetectable, the "safe" enrichment factor is as follows:

SEF = 100 (4c)

For all cases, the "conservative" dust metal concentration limit is calculated using the following equation:

>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<<

If the kiln dust metal concentration at a facility is just above the "conservative" limit based on that "safe" enrichment factor provided in Equation 4a, and the PM emissions are at the PM emissions limit, there is a 5% chance that the metal emissions are above one-half the Tier III limit. If the kiln dust metal concentration at the facility is just above the "conservative" limit based on the "safe" enrichment factor provided in Equation 4b, and the PM emissions are at the PM emissions limit, there is a 1% chance that the metal emissions are above the Tier III limit. In either case, the facility would be unacceptably close to a violation. If this situation occurs more than 5% of the time, the facility would be required to rerun the series of 10 tests to determine the enrichment factor. To avoid this expense, the facility would be advised to reduce its metals feedrates or to take other appropriate measures to maintain its kiln dust metal concentrations in compliance with the "conservative" dust metal concentration limits.

In cases where the enrichment factor cannot be determined because the kiln dust metal concentration is nondetectable, and thus no  $EF_{95\$}$  exists, the "violation" dust metal concentration limit is set at ten times the "conservative" limit:

 $DMCL_v = 10 \times DMCL_c$  (6)

10.4 Overview

The flowchart for implementing the method is shown in Figure 10.4-1. The general procedure is as follows:

- Follow the certification of precompliance procedures described in subsection 10.6 (to comply with 40 CFR 266.103(b)).
- For each metal of concern, perform a series of tests to establish the relationship (enrichment factor) between the concentration of emitted metal and the metal concentration in the collected kiln dust.
- Use the demonstrated enrichment factor, in combination with the Tier III (or Tier II) metal emission limit and the most stringent applicable particulate emission limit, to calculate the "violation" and "conservative" dust metal concentration limits. Include this information with the certification of compliance under 40 CFR 266.103(c).
- >>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<<
- Perform daily and/or weekly monitoring of the cement kiln dust metal concentration to ensure (with appropriate QA/QC) that the metal concentration does not exceed either limit.
- If the cement kiln dust metal concentration exceeds the "conservative" limit more than 5% of the time (i.e., more than three failures in last 60 tests), the series of tests to determine the enrichment factor must be repeated.
- If the cement kiln dust metal concentration exceeds the "violation" limit, a violation has occurred.
- Perform quarterly tests to verify that the enrichment factor has not increased significantly. If the enrichment factor has increased, the series of tests to determine the enrichment factor must be repeated.

# 10.5 Implementation Procedures

A step-by-step description for implementing the method is provided below:

- (1) Prepare initial limits and test plans.
- ullet Determine the Tier III metal emission limit. The Tier II metal emission limit may also be used (see 40 CFR 266.106).
- Determine the applicable PM emission standard. This standard is the most stringent particulate emission standard that applies to the facility. A facility may elect to restrict itself to an even more stringent self-imposed PM emission standard, particularly if the facility finds that it is easier to control particulate emissions than to reduce the kiln dust concentration of a certain metal (i.e., lead).
- Determine which metals need to be monitored (i.e., all hazardous metals for which Tier III emission limits are lower than PM emission limits-assuming PM is pure metal).
  - Follow the compliance procedures described in Subsection 10.6.
- Follow the guidelines described in SW-846 for preparing test plans and waste analysis plans for the following tests:
- Compliance tests to determine limits on metal feedrates in pumpable hazardous wastes and in all hazardous wastes (as well as to determine other compliance parameters);

- Initial tests to determine enrichment factors;
- Quarterly tests to verify enrichment factors;
- Analysis of hazardous waste feedstreams; and
- Daily and/or weekly monitoring of kiln dust for continuing compliance.
  - (2) Conduct tests to determine the enrichment factor.
- These tests must be conducted within a 14-day period. No more than two tests may be conducted in any single day. If the tests are not completed within a 14-day period, they must be repeated.
  - Simultaneous stack samples and kiln dust samples must be taken.
- Stack sampling must be conducted with the multiple metals train according to procedures provided in section 10.3 of this Methods Manual.
- Kiln dust sampling must be conducted as follows:
- Follow the sampling and analytical procedures described in SW-846 and the waste analysis plan as they pertain to the condition and accessibility of the dust.
- Samples should be representative of the last ESP or Fabric Filter in the APCS series.
- The feedrates of hazardous metals in all pumpable hazardous waste streams and in all hazardous waste streams must be monitored during these tests. It is recommended (but not required) that the feedrates of hazardous metals in all feedstreams also be monitored.
- $\bullet$  At least ten single (noncomposited) runs are required during the tests.
- The facility must follow a normal schedule of kiln dust recharging for all of the tests.
- Three of the first five tests must be compliance tests in conformance with 40 CFR 266.103(c); i.e., they must be used to determine maximum allowable feedrates of metals in pumpable hazardous wastes. and in all hazardous wastes, as well as to determine other compliance limits (see 40 CFR 266.103(c)(1)).
- The remaindar of the tests need not be conducted under full compliance test conditions; however, the facility must operate at its compliance test production rate, and it must burn hazardous waste during these tests such that the feedrate of each metal for pumpable and total hazardous wastes is at least 25% of the feedrate during compliance testing. If these criteria, and those discussed below, are not met for any parameter during a test, then either the test is not valid for determining enrichment factors under this method, or the compliance limits for that parameter must be established based on these test conditions rather than on the compliance test conditions.
  - Verify that compliance emission limits are not exceeded.
- Metal emissions must not exceed Tier III (or Tier II) limits.

- PM emissions must not exceed the most stringent of applicable PM standards (or an optional self-imposed particulate standard).
- The facility must generate normal, marketable product using normal raw materials and fuels under normal operating conditions (for parameters other than those specified under this method) when these tests are conducted.
  - Chromium must be treated as a special case:
- The enrichment factor for total chromium is calculated in the same way as the enrichment factor for other metals (i.e., the enrichment factor is the ratio of the concentration of total chromium in the emitted particulate matter to the concentration of total chromium in the collected kiln dust).
- The enrichment factor for hexavalent chromium (if measured) is defined as the ratio of the concentration of hexavalent chromium in the emitted particulate matter to the concentration of total chromium in the collected kiln dust.
- (3) Use the enrichment factors measured in Step 2 to determine  $EF_{95\$},$   $EF_{99\$},$  and SEF.
- $\bullet$  Calculate  $EF_{95\$}$  and  $EF_{99\$}$  according to the t-distribution as described in Appendix A
  - Calculate SEF by
- Equation 4a if  $EF_{95\$}$  is determinable and if  $EF_{99\$}$  is greater than two times  $EF_{95\$}$ ,
- Equation 4b if  $EF_{95\$}$  is determinable and if  $EF_{99\$}$  is not greater than two times  $EF_{95\$}$ .
- Equation 4c if EF<sub>95%</sub> is not determinable.

The facility may choose to set an even more conservative SEF to give itself a larger margin of safety between the point where corrective action is necessary and the point where a violation occurs.

- (4) Prepare certification of compliance.
- $\bullet$  Calculate the "conservative" dust metal concentration limit (DMCL $_{\!\scriptscriptstyle c})$  using Equation 5.
- Chromium is treated as a special case. The "conservative" kiln dust chromium concentration limit is set for total chromium, not for hexavalent chromium. The limit for total chromium must be calculated using the Tier III (or Tier II) metal limit for hexavalent chromium.
- If the stack samples described in Step 2 were analyzed for hexavalent chromium, the SEF based on the hexavalent chromium enrichment factors (as defined in Step 2) must be used in this calculation.
- If the stack samples were not analyzed for hexavalent chromium, then the SEF based on the total chromium enrichment factor must be used in this calculation.
- $\bullet$  Calculate the "violation" dust metal concentration limit (DMCL $_{\!_{v}})$  using Equation 3 if EF $_{95\$}$  is determinable, or using Equation 6 if EF $_{95\$}$  is not determinable.

- Chromium is treated as a special case. The "violation" kiln dust chromium concentration limit is set for total chromium, not for hexavalent chromium. The limit for total chromium must be calculated using the Tier III (or Tier II) metal limit for hexavalent chromium.
- If the stack samples taken in Step 2 were analyzed for hexavalent chromium, the  $EF_{95\$}$  based on the hexavalent chromium enrichment factor (as defined in Step 2) should be used in this calculation.
- If the stack samples were not analyzed for hexavalent chromium, the  ${\rm EF}_{95\$}$  based on the total chromium enrichment factor must be used in this calculation.
  - Submit certification of compliance.
- ullet Steps 2-4 must be repeated for recertification, which is required once every 3 years (see § 266.103(d)).
- (5) Monitor metal concentrations in kiln dust for continuing compliance, and maintain compliance with all compliance limits for the duration of interim status.
- Metals to be monitored during compliance testing are classified as either "critical" or "noncritical" metals.
- All metals must initially be classified as "critical" metals and be monitored on a daily basis.
- A "critical" metal may be reclassified as a "noncritical" metal if its concentration in the kiln dust remains below 10% of its "conservative" kiln dust metal concentration limit for 30 consecutive daily samples. "Noncritical" metals must be monitored on a weekly basis.
- A "noncritical" metal must be reclassified as a "critical" metal if its concentration in the kiln dust is above 10% of its "conservative" kiln dust metal concentration limit for any single daily or weekly sample.
- ullet Noncompliance with the sampling and analysis schedule prescribed by this method is a violation of the metals controls under § 266.103.
- $\bullet$  Follow the sampling, compositing, and analytical procedures described in this method and in SW-846 as they pertain to the condition and accessibility of the kiln dust.
- Follow the same procedures and sample at the same locations as were used for kiln dust samples collected to determine the enrichment factors (as discussed in Step 2).
- $\bullet$  Samples must be collected at least once every 8 hours, and a daily composite must be prepared according to SW-846 procedures.
- At least one composite sample is required. This sample is referred to as the "required" sample.
- For QA/QC purposes, a facility may elect to collect two or more additional samples. These samples are referred to as the "spare" samples. These additional samples must be collected over the same time period and according to the same procedures as those used for the "required" sample.
- Samples for "critical" metals must be daily composites.

- Samples for "noncritical" metals must be weekly composites. These samples can be composites of the original 8-hour samples, or they can be composites of daily composite samples.
- ullet Analyze the "required" sample to determine the concentration of each metal.
- This analysis must be completed within 48 hours of the close of the sampling period. Failure to meet this schedule is a violation of the metals standards of § 266.103.
- If the "conservative" kiln dust metal concentration limit is exceeded for any metal, refer to Step 8.
- If the "conservative" kiln dust metal concentration limit is not exceeded, continue with the daily or weekly monitoring (Step 5) for the duration of interim status.
- ullet Conduct quarterly enrichment factor verification tests, as described in Step 6.
  - (6) Conduct quarterly enrichment factor verification tests.
- After certification of compliance with the metals standards, a facility must conduct quarterly enrichment factor verification tests every three months for the duration of interim status. The first quarterly test must be completed within three months of certification (or recertification). Each subsequent quarterly test must be completed within three months of the preceding quarterly test. Failure to meet this schedule is a violation.
  - Simultaneous stack samples and kiln dust samples must be collected.
- Follow the same procedures and sample at the same locations as were used for kiln dust samples and stack samples collected to determine the enrichment factors (as discussed in Step 2).
- At least three single (noncomposited) runs are required. These tests need not be conducted under the operating conditions of the initial compliance test; however, the facility must operate under the following conditions:
- It must operate at compliance test production rate.
- It must burn hazardous waste during the test, and for the 2-day period immediately preceding the test, such that the feedrate of each metal for pumpable and total hazardous wastes consist of at least 25% of the operating limits established during the compliance test.
- It must remain in compliance with all compliance parameters (see § 266.103(c)(1)).
- It must follow a normal schedule of kiln dust recharging.
- It must generate normal marketable product from normal raw materials during the tests.
- (7) Conduct a statistical test to determine if the enrichment factors measured in the quarterly verification tests have increased significantly from the enrichment factors determined in the tests conducted in Step 2. The enrichment factors have increased significantly if all three of the following criteria are met:

- By applying the t-test described in appendix A, it is determined that the enrichment factors measured in the quarterly tests are not taken from the same population as the enrichment factors measured in the Step 2 tests;
- ullet The EF<sub>95%</sub> calculated for the combined data sets (i.e., the quarterly test data and the original Step 2 test data) according to the t-distribution (described in appendix A) is more than 10% higher than the EF<sub>95%</sub> based on the enrichment factors previously measured in Step 2; and
- ullet The highest measured kiln dust metal concentration recorded in the previous quarter is more than 10% of the "violation" kiln dust concentration limit that would be calculated from the combined EF<sub>958</sub>.
- If the enrichment factors have increased significantly, the tests to determine the enrichment factors must be repeated (refer to Step 11). If the enrichment factors have not increased significantly, continue to use the kiln dust metal concentration limits based on the enrichment factors previously measured in Step 2, and continue with the daily and/or weekly monitoring described in Step 5.
- (8) If the "conservative" kiln dust metal concentration limit was exceeded for any metal in any single analysis of the "required" kiln dust sample, the "spare" samples corresponding to the same period may be analyzed to determine if the exceedance was due to a sampling or analysis error.
  - If no "spare" samples were taken, refer to Step 9.
- If the average of all the samples for a given day (or week, as applicable) (including the "required" sample and the "spare" samples) does not exceed the "conservative" kiln dust metal concentration limit, no corrective measures are necessary; continue with the daily and/or weekly monitoring as described in Step 5.
- If the average of all the samples for a given day (or week, as applicable) exceeds the "conservative" kiln dust metal concentration limit, but the average of the "spare" samples is below the "conservative" kiln dust metal concentration limit, apply the Q-test, described in appendix A, to determine whether the "required" sample concentration can be judged as an outlier.
- If the "required" sample concentration is judged an outlier, no corrective measures are necessary; continue with the daily and/or weekly monitoring described in Step 5.
- If the "required" sample concentration is not judged an outlier, refer to Step 9.
- (9) Determine if the "violation" kiln dust metal concentration has been exceeded based on either the average of all the samples collected during the 24-hour period in question, or if discarding an outlier can be statistically justified by the Q-test described in appendix A, on the average of the remaining samples.
- If the "violation" kiln dust metal concentration limit has been exceeded, a violation of the metals controls under § 266.103(c) has occurred. Notify the Director that a violation has occurred. Hazardous waste may be burned for testing purposes for up to 720 operating hours to support a revised certification of compliance. Note that the Director may grant an extension of the hours of hazardous waste burning under § 266.103(c)(7) if additional burning time is needed to support a revised certification for reasons beyond the control of the owner or operator. Until a revised certification of

compliance is submitted to the Director, the feedrate of the metals in violation in total and pumpable hazardous waste feeds is limited to 50% of the previous compliance test limits.

- If the "violation" kiln dust metal concentration has not been exceeded:
- If the exceedance occurred in a daily composite sample, refer to Step 10.
- If the exceedance occurred in a weekly composite sample, refer to Step 11.
- (10) Determine if the "conservative" kiln dust metal concentration limit has been exceeded more than three times in the last 60 days.
- ullet If not, log this exceedance and continue with the daily and/or weekly monitoring (Step 5).
- ullet If so, the tests to determine the enrichment factors must be repeated (refer to Step 11).
  - This determination is made separately for each metal; For example,
- Three exceedances for each of the ten hazardous metals are allowed within any 60-day period.
- Four exceedances of any single metal in any 60-day period is not allowed.
- This determination should be made daily, beginning on the first day of daily monitoring. For example, if four exceedances of any single metal occur in the first four days of daily monitoring, do not wait until the end of the 60-day period; refer immediately to Step 11.
- (11) The tests to determine the enrichment factor must be repeated if: (1) More than three exceedances of the "conservative" kiln dust metal concentration limit occur within any 60 consecutive daily samples; (2) an excursion of the "conservative" kiln dust metal concentration limit occurs in any weekly sample; or (3) a quarterly test indicates that the enrichment factors have increased significantly.
- $\bullet$  The facility must notify the Director if these tests must be repeated.
- The facility has up to 720 hazardous-waste-burning hours to redetermine the enrichment factors for the metal or metals in question and to recertify (beginning with a return to Step 2). During this period, the facility must reduce the feed rate of the metal in violation by 50%. If the facility has not completed the recertification process within this period, it must stop burning or obtain an extension. Hazardous waste burning may resume only when the recertification process (ending with Step 4) has been completed.
- Meanwhile, the facility must continue with daily kiln dust metals monitoring (Step 5) and must remain in compliance with the "violation" kiln dust metal concentration limits (Step 9).

## 10.6 Precompliance Procedures

Cement kilns and other industrial furnaces that recycle emission control residue back into the furnace must comply with the same certification

schedules and procedures (with the few exceptions described below) that apply to other boilers and industrial furnaces. These schedules and procedures, as set forth in § 266.103, require no later than the effective date of the rule, each facility submit a certification which establishes precompliance limits for a number of compliance parameters (see § 266.103(b)(3)), and that each facility immediately begin to operate under these limits.

These precompliance limits must ensure that interim status emissions limits for hazardous metals, particulate matter, HCl, and  ${\rm Cl}_2$  are not likely to be exceeded. Determination of the values of the precompliance limits must be made based on either (1) conservative default assumptions provided in this Methods Manual, or (2) engineering judgement.

The flowchart for implementing the precompliance procedures is shown in Figure 10.6-1. The step-by-step precompliance implementation procedure is described below. The precompliance implementation procedures and numbering scheme are similar to those used for the compliance procedures described in Subsection 10.5.

- (1) Prepare initial limits and test plans.
- Determine the Tier III metal emission limit. The Tier II metal emission limit may also be used (see 40 CFR 266.106).
- Determine the applicable PM emission standard. This standard is the most stringent particulate emission standard that applies to the facility. A facility may elect to restrict itself to an even more stringent self-imposed PM emission standard, particularly if the facility finds that it is easier to control particulate emissions than to reduce the kiln dust concentration of a certain metal (i.e., lead).
- Determine which metals need to be monitored (i.e., all hazardous metals for which Tier III emission limits are lower than PM emission limits, assuming PM is pure metal).
- ullet Follow the procedures described in SW-846 for preparing waste analysis plans for the following tasks:
- Analysis of hazardous waste feedstreams.
- Daily and/or weekly monitoring of kiln dust concentrations for continuing compliance.
- (2) Determine the "safe" enrichment factor for precompliance. In this context, the "safe" enrichment factor is a conservatively high estimate of the enrichment factor (the ratio of the emitted metal concentration to the metal concentration in the collected kiln dust). The "safe" enrichment factor must be calculated from either conservative default values, or engineering judgement.

>>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point.  $<\!<\!<$ 

- $\bullet$  Conservative default values for the "safe" enrichment factor are as follows:
- SEF = 10 for all hazardous metals except mercury. SEF = 10 for antimony, arsenic, barium, beryllium, cadmium, chromium, lead, silver, and thallium.
- SEF = 100 for mercury.

• Engineering judgement may be used in place of conservative default assumptions provided that the engineering judgement is defensible and properly documented. The facility must keep a written record of all assumptions and calculations necessary to justify the SEF. The facility must provide this record to EPA upon request and must be prepared to defend these assumptions and calculations.

Examples of situations where the use of engineering judgement is appropriate include:

- Use of data from precompliance tests;
- Use of data from previous compliance tests; and
- Use of data from similar facilities.
  - (3) This step does not apply to precompliance procedures.
  - (4) Prepare certification of precompliance.
- $\bullet$  Calculate the "conservative" dust metal concentration limit (DMCL $_{\! \rm c})$  using Equation 5.
- Submit certification of precompliance. This certification must include precompliance limits for all compliance parameters that apply to other boilers and industrial furnaces (i.e., those that do not recycle emission control residue back into the furnace) as listed in § 266.103(b)(3), except that it is not necessary to set precompliance limits on maximum feedrate of each hazardous metal in all combined feedstreams.
- Furnaces that recycle collected PM back into the furnace (and that elect to comply with this method (see § 266.103(c)(3)(ii)) are subject to a special precompliance parameter, however. They must establish precompliance limits on the maximum concentration of each hazardous metal in collected kiln dust. (which must be set according to the procedures described above).
- (5) Monitor metal concentration in kiln dust for continuing compliance, and maintain compliance with all precompliance limits until certification of compliance has been submitted.
- Metals to be monitored during precompliance testing are classified as either "critical" or "noncritical" metals.
- All metals must initially be classified as "critical" metals and be monitored on a daily basis.
- A "critical" metal may be reclassified as a "noncritical" metal if its concentration in the kiln dust remains below 10% of its "conservative" kiln dust metal concentration limit for 30 consecutive daily samples. "Noncritical" metals must be monitored on a weekly basis, at a minimum.
- A "noncritical" metal must be reclassified as a "critical" metal if its concentration in the kiln dust is above 10% of its "conservative" kiln dust metal concentration limit for any single daily or weekly sample.
- It is a violation if the facility fails to analyze the kiln dust for any "critical" metal on any single day or for any "noncritical" metal during any single week, when hazardous waste is burned.

- ullet Follow the sampling, compositing, and analytical procedures described in this method and in SW-846 as they pertain to the condition and accessibility of the kiln dust.
- $\bullet$  Samples must be collected at least once every 8 hours, and a daily composite prepared according to SW-846 procedures.
- At least one composite sample is required. This sample is referred to as the "required" sample.
- For QA/QC purposes, a facility may elect to collect two or more additional samples. These samples are referred to as the "spare" samples. These additional samples must be collected over the same time period and according to the same procedures as those used for the "required" sample.
- Samples for "critical" metals must be daily composites.
- Samples for "noncritical" metals must be weekly composites, at a minimum. These samples can be composites of the original 8-hour samples, or they can be composites of daily composite samples.
- $\bullet$  Analyze the "required" sample to determine the concentration of each metal.
- This analysis must be completed within 48 hours of the close of the sampling period. Failure to meet this schedule is a violation.
- If the "conservative" kiln dust metal concentration limit is exceeded for any metal, refer to Step 8.
- If the "conservative" kiln dust metal concentration limit is not exceeded, continue with the daily and/or weekly monitoring (Step 5) for the duration of interim status.
  - (6) This step does not apply to precompliance procedures.
  - (7) This step does not apply to precompliance procedures.
- (8) If the "conservative" kiln dust metal concentration limit was exceeded for any metal in any single analysis of the "required" kiln dust sample, the "spare" samples corresponding to the same period may be analyzed to determine if the exceedance is due to a sampling or analysis error.
  - If no "spare" samples were taken, refer to Step 9.
- If the average of all the samples for a given day (or week, as applicable) (including the "required" sample and the "spare" samples) does not exceed the "conservative" kiln dust metal concentration limit, no corrective measures are necessary; continue with the daily and/or weekly monitoring as described in Step 5.
- If the average of all the samples for a given day (or week, as applicable) exceeds the "conservative" kiln dust metal concentration limit. but the average of the "spare" samples is below the "conservative" kiln dust metal concentration limit, apply the Q-test, described in appendix A, to determine whether the "required" sample concentration can be judged as an outlier.
- If the "required" sample concentration is judged an outlier. no corrective measures are necessary; continue with the daily and/or weekly monitoring described in Step 5.

- If the "required" sample concentration is not judged an outlier, refer to Step 10.
  - (9) This step does not apply to precompliance procedures.
- (10) Determine if the "conservative" kiln dust metal concentration limit has been exceeded more than three times in the last 60 days.
- ullet If not, log this exceedance and continue with the daily and/or weekly monitoring (Step 5).
- ullet If so, the tests to determine the enrichment factors must be repeated (refer to Step 11).
  - This determination is made separately for each metal; for example
- Three exceedances for each of the ten hazardous metals are allowed within any 60-day period.
- Four exceedances of any single metal in any 60-day period is not allowed.
- This determination should be made daily, beginning on the first day of daily monitoring. For example, if four exceedances of any single metal occur in the first four days of daily monitoring, do not wait until the end of the 60-day period; refer immediately to Step 11.
- (11) A revised certification of precompliance must be submitted to the Director (or certification of compliance must be submitted) if: (1) More than three exceedances of the "conservative" kiln dust metal concentration limit occur within any 60 consecutive daily samples; or (2) an exceedance of the "conservative" kiln dust metal concentration limit occurs in any weekly sample.
- $\bullet$  The facility must notify the Director if a revised certification of precompliance must be submitted.
- The facility has up to 720 waste-burning hours to submit a certification of compliance or a revised certification of precompliance. During this period, the feed rate of the metal in violation must be reduced by 50%. In the case of a revised certification of precompliance, engineering judgement must be used to ensure that the "conservative" kiln dust metal concentration will not be exceeded. Examples of how this goal might be accomplished include:
- Changing equipment or operating procedures to reduce the kiln dust metal concentration;
- Changing equipment or operating procedures, or using more detailed engineering judgement, to decrease the estimated SEF and thus increase the "conservative" kiln dust metal concentration limit;
- Increasing the "conservative" kiln dust metal concentration limit by imposing a stricter PM emissions standard; or
- Increasing the "conservative" kiln dust metal concentration limit by performing a more detailed risk assessment to increase the metal emission limits.
- Meanwhile, the facility must continue with daily kiln dust metals monitoring (Step 5).

Appendix A to Appendix IX to Part 266-Statistics

#### A.1 Determination of Enrichment Factor

After at least 10 initial emissions tests are performed, an enrichment factor for each metal must be determined. At the 95% confidence level, the enrichment factor,  $\mathrm{EF}_{95\$}$ s, is based on the test results and is statistically determined so there is only a 5% chance that the enrichment factor at any given time will be larger than  $\mathrm{EF}_{95\$}$ . Similarly, at the 99% confidence level, the enrichment factor,  $\mathrm{EF}_{99\$}$ , is statistically determined so there is only a 1% chance that the enrichment factor at any given time will be larger than  $\mathrm{EF}_{99\$}$ .

For a large number of samples (n > 30),  $EF_{95\$}$  is based on a normal distribution, and is equal to:

$$EF_{95\%} = EF + z_c \mathbf{F} \tag{1}$$

where:

>>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<<

For a 95% confidence level,  $z_c$  is equal to 1.645.

For a small number of samples (n < 30),  $EF_{95\$}$  is based on the t -distribution and is equal to:

$$EF_{95\%} = EF + t_c S$$
 (4)

where the standard deviation, S, is defined as:

>>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<<

 $\rm t_c$  is a function of the number of samples and the confidence level that is desired. It increases in value as the sample size decreases and the confidence level increases. The 95% confidence level is used in this method to calculate the "violation" kiln dust metal concentration limit; and the 99% confidence level is sometimes used to calculate the "conservative" kiln dust metal concentration limit. Values of  $\rm t_c$  are shown in table A-1 for various degrees of freedom (degrees of freedom = sample size-1) at the 95% and 99% confidence levels. As the sample size approaches infinity, the normal distribution is approached.

# A.2 Comparison of Enrichment Factor Groups

To determine if the enrichment factors measured in the quarterly tests are significantly different from the enrichment factors determined in the initial Step 2 tests, the t-test is used. In this test, the value  $t_{meas}$ :

>>> See the accompanying hardcopy volume for non-machine-readable data that appears at this point. <<<<

Table A-1.-T-Distribution

$$\mathbf{F}_{t} = \frac{(n_{1} - 1)S_{1}^{2} + (n_{2} - 1)S_{2}}{n_{1} + n_{2} - 2}$$
 (7)

is compared to  $t_{\rm crit}$  at the desired confidence level. The 95% confidence level is used in this method. Values of  $t_{\rm crit}$  are shown in table A-1 for various degrees of freedom (degrees of freedom  $n_1$  +  $n_2$  - 2) at the 95% and 99% confidence levels. If  $t_{\rm meas}$  is greater then  $t_{\rm crit}$ , it can be concluded with 95% confidence that the two groups are not from the same population.

# A.3 Rejection of Data

If the concentration of any hazardous metal in the "required" kiln dust sample exceeds the kiln dust metal concentration limit, the "spare" samples are analyzed. If the average of the combined "required" and "spare" values is still above the limit, a statistical test is used to decide if the upper value can be rejected.

The "Q-test" is used to determine if a data point can be rejected. The difference between the questionable result and its neighbor is divided by the spread of the entire data set. The resulting ratio,  $Q_{\text{meas}}$ , is then compared with rejection values that are critical for a particular degree of confidence, where  $Q_{\text{meas}}$  is:

$$\mathbf{F}_{\text{meas}} = \underline{\qquad \qquad \qquad } \\ \mathbf{DMC}_{\text{highest}} - \mathbf{DMC}_{\text{next}} \\ \mathbf{DMC}_{\text{highest}} - \mathbf{DMC}_{\text{lowest}} \\ \end{aligned} \tag{8}$$

The 90% confidence level for data rejection is used in this method. Table A-2 provides the values of  $Q_{\rm crit}$  at the 90% confidence level. If  $Q_{\rm meas}$  is larger than

 $Q_{\text{crit}},$  the data point can be discarded. Only one data point from a sample group can be rejected using this method.

Table A-2.-Critical Values for Use in the Q-Test

n	$Q_{\mathtt{crit}}$	
3 4 5 6 7 8 9	0.94 0.76 0.64 0.56 0.51 0.47 0.44	

>>>> End of File FR94C. This article is continued in File FR94D. <<<<