

# **ULTRA-LOW SULFUR DIESEL IMPLEMENTATION WORKSHOP**

**A Quality System for Fuels Laboratories**

**Richard Chapman  
BP Global Fuels Technology**

**November 15-16, 2004**



# Five Primary Activities for Effective Laboratory Quality Assurance Programs

- 1. Monitor test method precision and stability through QC sample testing**
- 2. Monitor test method accuracy**
- 3. Periodically evaluate System Performance (i.e., precision, bias)**
- 4. Proficiency Testing (e.g., ASTM crosscheck program)**
- 5. Validation or verification (section 7.7 in D 6299)**



# ASTM Standard Practices & Guides

- **D 6299: Standard Practice for  
Applying Statistical Quality Assurance  
Techniques to Evaluate Analytical  
Measurement System Performance**
- **D 6792: Standard Guide for  
A Quality System in Petroleum Products and  
Lubricants Testing Laboratories**



# Summary of ASTM D 6299 Practice

- 1. QC samples and check standards are regularly analyzed by the measurement system. Control charts and other statistical techniques are presented to screen, plot, and interpret test results in accordance with industry-accepted practices to ascertain the in-statistical-control status of the measurement system.**



# Summary of ASTM D 6299 Practice -

continued

- 2. Statistical estimates of the measurement system precision and bias are calculated and periodically updated using accrued data.**
- 3. As part of a separate validation audit, QC samples and check standards may be submitted blind or double-blind and randomly to the measurement system.**



# ASTM D 6299 Analysis Process

- **Convert results to pre-treated data**
- **Visually look for “bad” data**
- **Plot and look for unusual patterns**
- **Test data for normality**
- **Set up and use control charts**
- **Evaluate precision**
- **Evaluate bias**
- **Verify lab performance**



# ASTM D 6299 Run Charts

- A run chart is a plot of results in chronological order that can be used to screen data for unusual patterns:
  - continuous trending in either direction
  - unusual clustering
  - cycles



# Use Control Charts

- Set up I and MR charts
  - I = individual observation
  - MR = moving range (plot of sequential range of two values)
- The moving range chart provides information independent of the average value.
- An MR chart can go out of control even though the I chart is in control.
- We don't need a control chart if we don't take action based on the chart.





# ASTM D 6792 Scope

- **The D 6792 Guide covers the establishment and maintenance of the essentials of a quality system in laboratories engaged in the analysis of petroleum products and lubricants.**
- **The D 6792 Guide is designed to be used in conjunction with Practice ASTM D 6299.**
- **D 6792 contains a checklist for investigating the root cause of unsatisfactory analytical performance.**



# ASTM D 6792 Checklist

- **An extensive, user-friendly Laboratory Quality System assessment checklist is being balloted as an appendix to D 6792.**

- 1. Quality Assurance System**
- 2. Test Methods**
- 3. Sample Management**
- 4. Calibration**
- 5. Maintenance**
- 6. Quality Control Program**
- 7. Bias Management and Proficiency Evaluations**
- 8. Data Management**
- 9. Training**
- 10. Assessments**
- 11. Corrective and Preventive Actions**
- 12. Customer Interactions**
- 13. Continuous Improvement**



# Laboratory Quality System Assessment Checklist (being balloted)

Laboratory: \_\_\_\_\_

Date: \_\_\_\_\_

	Requirements	Yes/No	Assessor Comments
<b>1.0</b>	<b>QUALITY ASSURANCE SYSTEM (QAS)</b>		
1.1	A quality system is established and maintained. (5.1)	<input type="checkbox"/> Yes <input type="checkbox"/> No	
1.2	The quality system includes stated objectives in the following areas: (5.1) <ul style="list-style-type: none"> <li>• Laboratory's adherence to test method requirements</li> <li>• Calibration and maintenance practices</li> <li>• Quality control program.</li> <li>• Continuous improvement goals</li> <li>• Meeting customer requirements</li> </ul>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
1.3	The quality system has documented processes for: (5.4) <ul style="list-style-type: none"> <li>• Sample management</li> <li>• Data and record management</li> <li>• Producing accurate, reliable, and properly represented test results</li> <li>• Audits and proficiency testing</li> <li>• Corrective and preventive action</li> <li>• Ensuring that procured services and materials meet the contracted requirements</li> <li>• Ensuring that personnel are adequately trained to obtain quality results.</li> </ul>	<input type="checkbox"/> Yes <input type="checkbox"/> No	
1.4	Management has appointed a representative to implement and maintain the quality system in the laboratory. (5.2)	<input type="checkbox"/> Yes <input type="checkbox"/> No	
1.5	Laboratory management reviews the adequacy of the quality system and the activities of the laboratory for consistency with the stated quality objectives at least annually. (5.3)	<input type="checkbox"/> Yes <input type="checkbox"/> No	

