



Flammability Evaluation

R134a, HFO1234yf and CO2

Content



1. Ignition Test (PAG Oils)
2. Flammability Comparison for PAG Oils in Furnace
3. Flammability Evaluation for Oil & Refrigerant Mixture on Hot Surface
 - ① Oil & R134a Mixture on Hot Surface
 - ② Oil & HFO1234yf Mixture on Hot Surface
 - ③ Oil & CO2 Mixture on Hot Surface
4. Conclusion

1. Ignition Tests for PAG oils




TOTAL



Oil Type Ignition	ISUPAG 56SG	FD46XG
Flash Point, °C ASTM D92	245	215
Auto-ignition, °C ASTM D2155	385	382

Flash Point



2. Flammability Comparison for PAG Oils in Furnace



5g of two different PAG oil was placed in a furnace. Temperature was increased until the oils ignite.




* ISUPAG 56SG ignites at 427°C, 10°C higher than FD46XG.

2. Flammability Comparison for PAG Oils in Furnace




TOTAL




3. Flammability Evaluation for Oil&R134a Mixture on Hot Surface




TOTAL




5KW, 220v
Heating Element




Metal plate was placed over the heating element, **T/C** was attached to the metal plate



Temperature Control Device



Max Temp



Max Temp
(Scanned)



HYUNDAI · KIA MOTORS
Hyundai · Kia America Technical Center, Inc.



3. Flammability Evaluation for Oil&R134a Mixture on Hot Surface



FD46XG+ R134a flammability test on 505°C hot surface



Autoclave used to discharge refrigerant and oil mixture.



PAG oil ignites



ISUPAG ignites, but does not propagate or spread to refrigerant
Flame lasted < 1 sec

3. Flammability Evaluation for Oil&R134a Mixture on Hot Surface



ISUPAG 56SG + R134a flammability test onh 505°C hot surface



Autoclave used to discharge refrigerant and oil mixture.



PAG oil ignites



PAG ignites, but does not propagate or spread to refrigerant
Flame lasted < 1 sec

3. Flammability Evaluation for Oil&HFO1234yf Mixture on Hot Surface



FD46XG+ HFO1234yf flammability test on 505°C hot surface



Autoclave used to discharge refrigerant and oil mixture.



PAG oil ignites



PAG ignites, but does not propagate or spread to refrigerant
Flame lasted ~ 1 sec



3. Flammability Evaluation for Oil&HFO1234yf Mixture on Hot Surface



ISUPAG 56SG + HFO1234yf flammability test on 505°C hot surface



Autoclave used to discharge refrigerant and oil mixture.



ISUPAG ignites, but does not propagate or spread to refrigerant
Flame lasted < 1 sec



ISUPAG ignites, but does not propagate or spread to refrigerant
Flame lasted ~ 1 sec



3. Flammability Evaluation for Oil&CO2 Mixture on Hot Surface



CO2 with various oil flammability test on 505°C hot surface



FD46XG:



ISUPAG56SG









Reniso ACC4

4. Conclusion



Flammability Result

Oil \ Refrigerant		R134a	HFO1234yf	CO2
	ISUPAG AG 56 SG			
	FD46XG			

For both R134a and HFO1234yf, mixture of oil and refrigerant ignited when discharged onto the hot surface. However, there was no case in which the flame has propagated or spread to refrigerant.