

Blood Lead Reduction for Lead Recycling

**Workers, their families and
the plant's neighbors**

**Capacity Building Workshop on Spent Lead Acid
Batteries and Electronic Waste**

4 December, 2007

Tijuana, Mexico

Recycling Batteries & E-Waste USEPA
December, 2007

by
Daniel P. Askin
President & Technical Director
ESCA Tech, Inc.
Manufacturers of D-Lead®
Milwaukee, WI USA

Reducing Blood Lead Levels

- **Limit Dose**
 - **Inhalation**
 - **Ingestion**
 - **Skin Absorption**
- **Maximize Excretion**

Reducing Blood Lead Levels

- **Limit Absorption by reducing**
 - 1. Dose (entry into body)**
 - 2. Amount absorbed after entry into body**

Reducing Blood Lead Levels

- Personal Hygiene
 - Housekeeping
- Personal Protective Equipment
 - Control Airborne Dust

Maximum Tolerable Lead Dose

World Health Organization (WHO) recommendation:

– “Provisional Tolerable Weekly Intake” (PTWI)

0,025 mg/kg bw

(milligrams per kilogram of body weight)

– For a 100 kg person this is 2,5 milligrams per week

Maximum 24 Hour Lead Dose

An aspirin weighs 100,000 mcg

$$350 \text{ mcg} = 1/300$$

Maximum daily dose:

100 kg person - 350 mcg

50 kg person - 175 mcg

20 kg child - 70 mcg



Maximum Daily Dose – Arsenic and Cadmium

Arsenic

- PTWI* is 0,015 mg / kg bw
- For 100 kg person
 - 1,5 mg / weekor
 - 215 mcg / day

Cadmium

- PTWI* is 0,007 mcg / kg bw
- For 100 kg person
 - 0,7 mg / weekor
 - 70 mcg / day

* Provisional Tolerable Weekly Intake

Recycling Batteries & E-Waste USEPA
December, 2007



Excretion of Lead

- If absorption is less than tolerable dose, lead is removed from body storage and excreted.
- If absorption is greater than tolerable dose, lead is placed in storage.
- It takes 2 to 3 times as long (or longer) for the blood lead to come down.

The body excretes lead by every means possible


- Urine
- Feces
- Sweat
- Saliva
- Mucus
- Shed skin cells
- Hair
- Finger and Toe Nails

How Lead Enters the Body

- Inhalation
 - Surface area of Lungs is 100 m²
- Ingestion
 - Surface area of digestive system is 10 m²
- Skin Absorption
 - Surface area of skin is 2 m²


Measuring the Results – Blood Lead and Blood Cadmium

- Frequency depends on level but normally no more than 1 per month
- Sample Room and supplies must be exceptionally clean
- Blind duplicate sample – 1 per 50




Inhalation, Ingestion & Skin Absorption

**All 3 routes
contribute to
dose and body
burden**




Inhalation, Ingestion & Skin Absorption

- Inhalation is efficient – the lungs are designed to transfer material from the air into the blood.




Inhalation, Ingestion & Skin Absorption

- Pb is absorbed quickly and efficiently in an empty stomach




Inhalation, Ingestion & Skin Absorption

- Lead and Arsenic on Skin is ingested and inhaled
- Water soluble lead enters through sweat ducts and hair follicles.
- Sweat is acidic and can dissolve lead.



Inhalation Efficiency is Size Dependent

- 0.3 - 10 micron particles are efficiently deposited in the lungs.
 - Absorption time is 36 to 72 hours to dissolve and move into the blood.
-
- > 10 micron particles are removed by nasal hair, mucus and cilia, some is cleared by coughing and sneezing
 - most is ingested.



Cilia in throat

Lead and other Metal Fumes

- **< 0.3 micron remain suspended in the tidal air and are immediately exhaled**
 - (unless trapped by mucus and cilia and ingested)
- **Freshly generated lead fume (evaporated lead) 0.3 to 1 micron**
 - Fresh lead fumes have a greater impact on blood lead than other lead compounds
 - The lungs maximum retention efficiency is in this size range.

Reducing Inhaled Lead

- Control Airborne Lead
 - Identify and Rank Sources
 - Eliminate / Enclose / Ventilate
 - Ventilation
 - Capture Efficiency
 - Filter Efficiency
 - Control Fugitive Sources

Identify & Rank Sources



Start with:

- Visible dust
- Lead fume

Identify & Rank Sources

For each source

- Identify and rank dust quantity, duration and timing.
- Where does it go?
- Estimate cost to control
- Calculate \$/KG emission reduction



Fugitive Emissions

- Spray storage piles with water mist or -
- A light spray of Paper Mache over stock piles reduces wind driven dust



Mix 50 kg of waste paper pulp with 15,000 liters of water.

Fugitive Emissions

- Green Screens –
 - Plant vegetation for wind breaks to trap dust leaving site




Housekeeping

All Surfaces as clean as practical

- ✓ Plant – in and out
- ✓ Locker Room
- ✓ LUNCH ROOM !



Central Vacuum System



Respiratory Protection

- Respiratory protection is effective in reducing inhalation dose
- P-100 (HEPA) (purple) filters remove all metal dusts and fumes as well as acid mists (they do not remove acid gases).
- Medical evaluation to determine ability to work in a respirator



Respirators

- Respirators are only effective when they are
 - WORN and sealed to the skin
 - NO facial hair, clean shaven every day
 - FIT TESTED – no face seal leakage



Ingestion


Personal Hygiene is key!

- *If air leads are high*
 - *Personal hygiene will reduce blood lead levels*
- *If air leads are low*
 - *Personal hygiene will reduce blood lead levels further*



PROPER GLOVE HANDLING

1



2



3



4





WASH STATION





Large sink for elbow room



Use lots of water

Wash hands thoroughly



Wash arms



Then face & neck.



A close-up photograph of a person wearing a white lab coat, rinsing their right arm under a chrome faucet. Water is spraying from the faucet onto the arm, which is covered in a thick, orange-colored substance. The background is a white sink. The text "Rinse thoroughly to remove soap, dirt and metal dust" is overlaid on the bottom left of the image.

**Rinse thoroughly to remove
soap, dirt and metal dust**

**Use towels to dry hands, arms,
face and neck.**



Lead Dust is difficult to clean

- Lead is **HEAVY**
- Lead is **sticky and a cement**
- Lead is **difficult to wet**
- Lead forms **soap scum (bathtub ring)**
- Lead **smears**
- Lead dust is **not abrasive**
- Lead dust holds a **large static charge**
- Lead is **small and gets trapped in porous surfaces**

Lead on Skin

- Lead sticks to the skin
- Soluble lead and metals migrate through the skin
- Sweat and saliva are acidic and dissolve lead
- Lead in sweat can exceed 75 mg/liter (excretion path)
- Lead resides in skin pores, sweat glands, sweat ducts and hair follicles



Personal Hygiene Program

- Use effective Lead Removing Skin Cleaners
- Test Hands regularly for lead
- Teach wash and shower technique
- Shower after every shift



Personal Hygiene Program

- Observe personal hygiene habits and re-train
 - Biting nails
 - Hands to nose and mouth



Personal Hygiene Program

- Lunch, locker and break rooms clean
 - Construct with Non-porous materials
 - Frequent cleaning schedule



Wood is porous

Respirator Laundry




Test Respirator Cleaning

Personal Hygiene Practices

- Smoking, eating and drinking is strictly forbidden in process areas except in lunchroom.
- Clean properly (wash hands, arms, face, mouth; shoes), even for short breaks
- All workers trained to take a proper shower at the end of each shift.
- No consumables (cigarettes, chewing tobacco, gum, candy, etc.) or personal items (i.e., wallets, keys, cell phones, etc.) in the plant.
- Working dress (even socks & underwear) should be changed as often as necessary.
- Workers should wear a dust cap as part of the working dress (to prevent hair from being a hidden source for lead dust).
- Workers should vacuum clean clothes and clean their shoes before leaving the lead area.
- Workers should not wipe away sweat with hands or arms, supply workers with single use (disposable) perspiration towels.

Hygiene Facilities



Leave Lead at Work

- All work clothes
- Work shoes
- Socks, underwear
- Provide “Overbags” for employees to keep personal items while on site – especially for contractors



Leave Lead at Work

Shoe Cleaners

- All work clothes
- Work shoes
- Socks
- Underwear?



Why is Lead Toxic?

- Calcium and Lead are similar
 - Body confuses Pb^{++} with Ca^{++}
 - When lead is present at high levels, then body uses lead in critical functions instead of calcium.

Nutrition is Important

- Diet can make large differences in lead absorption and retention
 - Lead is absorbed 4-10 X higher when the stomach is empty
 - Coming to work fed reduces the absorption of ingested lead
 - Some fiber, such as kelp, psyllium, fruit and vegetable fiber all reduce absorption

Nutrition is Important

- Eat a good meal before coming to work
- High fiber diet reduces absorption and storage of lead
- Take a basic multivitamin
- Calcium with Vitamin D reduces absorption
- All the major nutrient minerals - Zinc, iron, calcium - greatly reduce the absorption and bone uptake of ingested lead

Reducing Blood Lead Levels

- Personal Hygiene
 - Housekeeping
- Personal Protective Equipment
 - Control Airborne Dust

Gracias

ESCA Tech, Inc.

cservice@esca-tech.com www.esca-tech.com

D-Lead[®] is distributed in Mexico by:

Sarax S.A. de C.V.

sarax@sarax.com.mx 81 8333-33-35

Sonora Naturals, S.A. de C.V.

www.sonnat.com.mx 66 2215-09-00