

Asbestos Settled Dust Sampling Methods

Basic Descriptions

- Microvacuum
 - ASTM 5755
 - Low-suction vacuum
 - Captures dust and fibers on filter cassette
 - Preserves dust matrix



Basic Descriptions

- Wipe sampling
 - ASTM D 6480
 - Moist fabric (e.g., handi-wipe)
 - Extracts dust and fibers from surface
 - Dissolves dust matrix



Method Comparison for Asbestos and Other Fibers

Microvacuum

- More equipment intensive
- Equally applicable on hard and porous surfaces
- Preserves dust matrix
- ASTM experience standard for interpretation of results for asbestos

Wipe

- Easy
- Generally more efficient on hard surfaces, but not well suited for porous surfaces
- Destroys dust matrix
- No recognized interpretation of results for asbestos or other fibers

Analysis of Collected Samples

- Dust (microvacuum or wipe)
 - TEM – PCMe analysis (asbestos fibers $>5\text{ }\mu\text{m}$)
 - TEM – AHERA analysis (asbestos fibers $>0.5\text{ }\mu\text{m}$)
 - TEM – Non-asbestos fibers ($>0.5\text{ }\mu\text{m}$)
 - PCM – NIOSH 7400 (all fibers $>5\text{ }\mu\text{m}$)
- No standards for interpreting results from settled dust, but they are available for air
- All of the analytical measures mentioned above are available from the WTC studies conducted by EPA via air sampling

Point of Clarification

- Standard exists for measuring amount of asbestos (by mass) in building materials, as per NESHAPS (i.e., 1% rule), EPA/600R-93/116
- This rule is not very useful to manage asbestos contaminated dust in indoor environments
- EPA utilized 1% rule for rough characterization of bulk dust/debris post-collapse, but it was not used to guide either outdoor or indoor dust/debris removal

Asbestos in Air Sampling and Analysis

Detection Limit (Sensitivity)

- Dictated by volume of air sampled and filter area analyzed
- Detection limit established at .0005 f/cc
- Rule of thumb for detection limit = 1/3 of benchmark
- Constraints
 - Sample volume- overloads, volume flow, sampling duration
 - Microscopy – limited number of trained microscopists, increased sensitivity requires additional analysts and time

Fiber counting methods

- TEM – PCMe (asbestos fibers $> 5\mu\text{m}$)
- TEM – AHERA (asbestos fibers $> .5\mu\text{m}$)
- TEM – (non asbestos fiber $> .5\mu\text{m}$)
- PCM – (All fibers $> 5 \mu\text{m}$)

Definition of Exceedance

- .0009 f/cc PCMe health based benchmark
- 3 to 5+ samples per apartment
- 1 sample per room with minimum of 3 for studio apartments
- Clearance criteria – no exceedances

Duplicate and Replicate Sampling

AHERA Method

- 1 in 25 reread by second analyst (replicate)
- 1 in 50 repeated by same analyst (duplicate)
- Round robin and standard blanks to total of 10%
- Results do not pass internal QA if AHERA and NYSDOH standards not met

Confidence in sampling results

- Intrinsic variability and detection limit affect confidence in results
- Multiple samples increase effective filter area read per apartment thus increasing confidence

| Structures | Samples | 95% UCL (f/cc) |
|------------|---------|----------------|
| 1 | 1 | .0027 |
| 1 | 2 | .0013 |
| 1 | 3 | .0009 |
| 1 | 4 | .0007 |

95% UCL of asbestos concentration (PCMe) for cleared apartments

| Samples/apt | # apts | # detections | 95% UCL (f/cc) |
|-------------|--------|---------------|----------------|
| 3 | 441 | 0 (419 apts) | .0006 |
| 3 | | 1 (18 apts) | .0009 |
| 3 | | 2 (4 apts) | .0012 |
| 4 | 253 | 0 (244 apt) | .0004 |
| 4 | | 1 (9 apts) | .0007 |
| 5 | 2381 | 0 (2224 apts) | .0003 |
| 5 | | 1 (139 apts) | .0005 |
| 5 | | 2 (16 apts) | .0007 |
| 5 | | 4 (2 apts) | .0011 |
| 6 or more | 922 | <4 (921 apts) | <.0009 |
| | | 4 (1 apt) | .001 |

Relationship between short and long fibers

| | Asbestos - TEM $\geq 5\mu$ (PCMe) | Asbestos - TEM $> 0.5\mu$ (AHERA) | Total Non- Asbestos Fibers (TEM) | Fibers – NIOSH 7400 (PCM) |
|-------------------------|---|---|--|------------------------------------|
| Common Areas | 161 | 453 | 27957 | 64383 |
| Apts | | | | |
| A | 105 | 344 | 21417 | 59716 |
| B | 267 | 849 | 31448 | 77084 |
| C | 371 | 1213 | 20997 | 55169 |
| D | 59 | 199 | 21994 | 93598 |
| Apt Total | 802 | 2605 | 95856 | 285566 |

Background values for Asbestos

test-only data (LM-Pre), clean and test data (LM-Post),
upper Manhattan data (UM)
residential data (Residence) and the data from all buildings (All) from HEI

