
Monitoring Changes for OTC Sources

Theresa Alexander

US EPA, Clean Air Markets Division (CAMD)

October, 2001



OTC NOx Budget Monitoring

- ◆ Currently OTC NOx Budget sources use two guidance documents and individual state rules to monitor NOx mass.
 - Guidance for Implementation of Emission Monitoring Requirements for the NOx Budget Program
 - NOx Budget Program Monitoring Certification and Reporting Instructions (EDR 2.0)

Subpart H Monitoring

- ◆ Subpart H is similar, but not the same as OTC monitoring requirements
- ◆ Subpart H monitoring requirements are in Part 75 of the CFR.
- ◆ Reporting under Subpart H is in EDR 2.1.

Subpart H Monitoring

- ◆ Additional tools are available to ease your transition
 - OTC Sources under the Federal NO_x Budget Trading Program: Guidance on Changing Monitoring Methods and Upgrading Monitoring Plans to EDR v2.1
 - Monitor Certification Guidelines for the NO_x SIP Call and Section 126 Trading Programs
 - CAMD representative

Certification Applications for OTC Monitoring Systems

- ◆ States may waive formal application process for existing, certified OTC monitoring systems that meet, by the compliance date:
 - The QA requirements of § 75.74(c), and
 - If applicable, the Part 75 fuel flowmeter accuracy and/or appendix E test requirements
- ◆ Still must report the results of all QA tests in the appropriate quarterly report

Certification Applications for OTC Monitoring Systems (cont.)

- ◆ New monitoring systems must undergo all of the required certification tests by the compliance date

Subpart H Monitoring

- ◆ NO_x
 - NO_x emission rate CEMS
 - NO_x concentration CEMS with Stack flow monitor
 - Appendix E correlation curves (peaking units)
- ◆ Heat Input
 - Stack flow monitor & diluent CEMS
 - Appendix D, hourly fuel flow (oil & gas units)
- ◆ LME offers small sources a non-CEMS alternative

OTC to Subpart H CEMS Monitoring Differences

- ◆ Relative Accuracy for NO_x CEMS
 - OTC allows relative accuracy of 20% for non Acid Rain Program sources.
 - Subpart H requires relative accuracy of 7.5% for annual testing frequency and 10% for semi-annual testing frequency.

OTC CEMS Monitoring

- ◆ Low emitter alternative specifications for NO_x RATA's under OTC
 - An average rate of < 0.200 lb/mmBtu if the reference method average is within ± 0.04 lb/mmBtu of the CEMS average.

Subpart H CEMS Monitoring

- ◆ Low emitter alternative specs for NO_x emission rate RATA's under Subpart H
 - average NO_x emission rate < 0.200 lb/mmBtu during RATA
 - » CEMS mean value is within ± 0.015 lb/mmBtu of the reference mean value for annual frequency
 - » use ± 0.020 lb/mmBtu for semi-annual frequency
 - Max BAF of 1.111

OTC CEMS Monitoring

- ◆ Low emitter alternative specs for NO_x concentration RATA's under Subpart H
 - average NO_x concentration <250 ppm during RATA
 - » the mean value of CEMS is within +/- 12 ppm of the reference method mean value for annual frequency
 - » use +/- 15 ppm for semi-annual frequency
 - BAF max of 1.111

OTC to Subpart H CEMS Monitoring Differences

- ◆ Relative Accuracy for moisture systems.
 - OTC allows 15% RA with alternative of 1% moisture
 - Subpart H allows 7.5% RA with alternative spec of 1.0% moisture for annual frequency
 - Subpart H allows 10% RA with alternative of 1.5% moisture for semi-annual frequency.

OTC to Subpart H CEMS Monitoring Differences

- ◆ Different monitoring options for moisture under Subpart H.
 - Under OTC defaults are allowed for oil and gas only but no values are given
 - Under Subpart H defaults are allowed for coal and wood but not for oil and gas.

Part 75 Testing Requirements

- ◆ DAHS Verification required
 - Formula and missing data routine verifications
 - Also required when changing from EDR 2.0 to EDR 2.1
 - Refer to Policy Question 14.96

OTC to Subpart H CEMS Monitoring Differences

- ◆ Additional certification testing requirements
 - 3-point linearity check (not a 2-point CGA)
 - Cycle time test
 - 7 day calibration error
 - Bias tests for NO_x and flow required
 - Fuel flowmeter accuracy test and Appendix E testing, if applicable

OTC to Subpart H CEMS Monitoring Differences

- ◆ Subpart H allows a 2 load quality assurance RATA.
 - » Requires historical load analysis to determine two most frequently used loads.

OTC to Subpart H CEMS Monitoring Differences

- ◆ Single Load Flow RATA
 - Different criteria for application to base load units
 - » Operation at a single load $> 90\%$ for OTC
 - » Operation at a single load $> 85\%$ for Subpart H

OTC to Subpart H CEMS Monitoring Differences

- ◆ Flow to Load or Gross Heat Rate check required under Subpart H.
 - Data analysis of flow and unit load or gross heat rate as flow monitor QA.
 - Complex situations may be exempted from test.

OTC to Subpart H CEMS Monitoring Differences

- ◆ Quarterly linearity test
 - Subpart H allows a linearity exemption for monitors with spans of less than or equal to 30 p.p.m.
 - OTC allows 72 hour unit or stack operating grace period.
 - Subpart H allows 168 hour unit or stack operating grace period.

OTC to Subpart H CEMS Monitoring Differences

- ◆ Daily Calibration Error Test
 - Calibration gases must conform to latest EPA protocol (Appendix A § 5.1.4).
 - Subpart H allows the use of mid range calibration gases in place of the high range calibration gases (Appendix A § 6.3.1).

OTC CEMS Monitoring

- ◆ NO_x MPC, span and range under OTC for uncontrolled units
 - Determine MPC
 - Determine High Range Span
 - Determine Analyzer Range
 - Only required to use dual range if it is required for another state or federal program.

OTC CEMS Monitoring

- ◆ NO_x MPC, span and range for units with controls.
 - Determine Low Range Span
 - Determine Analyzer Range (20% - 80%)
 - Required to install dual range if low range is exceeded more than 72 hours in ozone season.

OTC CEMS Monitoring

- ◆ NO_x MPC, MEC, span and range under Subpart H for any unit
 - Determine MPC
 - Determine Span from MPC
 - Determine high range
 - Determine MEC (if applicable)
 - Compare MEC to high range
 - Dual range if $\text{MEC} < 20\%$ of high range

OTC to Subpart H CEMS Reporting Differences

- ◆ Annual Span and Range Evaluation
 - Not required under OTC
 - Required under Subpart H
- ◆ Used to determine if span and range are appropriate
- ◆ Requirement to change span and range if majority of emissions not within 20%-80% range of monitor.

OTC to Subpart H CEMS Monitoring Differences

- ◆ The provisions for a default high range analyzer are different under Subpart H.
 - Under OTC a 72 hour limit on use of a default high range during uncontrolled operation is allowed during the ozone season. (MPC)
 - Under Subpart H unlimited use of a default high range is allowed when using 200% of MPC.

OTC to Subpart H Monitoring Differences

- ◆ Conditionally Valid Data
 - May not allowed under OTC
 - May be used under Subpart H (§75.20(b)(3) but only for a certain number of hours
 - » for data collected prior to certification
 - » for data collected during recertification and QA testing periods

OTC to Subpart H Monitoring Differences

- ◆ Use of Max Heat Input in lieu of monitoring for any size unit
 - Allowed under OTC
 - Not allowed under Subpart H

OTC to Subpart H Monitoring Differences

- ◆ Ozone Season Only NO_x Mass Reporting for CEMS.
 - Not allowed under OTC
 - Allowed under Subpart H, if state agrees
 - Different reporting and QA schedules for partial year reporters.

Subpart H Missing Data

- ◆ For SIP Call or Section 126 sources that report NO_x mass only during the ozone season, use the standard Part 75 missing data procedures, but include only ozone season data in the lookback periods

OTC to Subpart H App D&E Monitoring Differences

- ◆ Fuel flowmeter calibrations
 - Under OTC, every 4 QA operating quarters and at least every 2 years.
 - Under Subpart H, every 4 QA operating quarters or at least every 20 calendar quarters, and
 - » for orifice-type fuel flowmeter, a visual inspection of orifice plate every three years.

OTC to Subpart H App D&E Reporting Differences

- ◆ Fuel flow-to-load option
 - Not allowed under OTC
 - Under Subpart H a source may perform a data analysis to allow extensions of fuel flowmeter QA testing up to 20 calendar quarters (Appendix A §7.8)

OTC to Subpart H App D&E Reporting Differences

- ◆ Fuel sampling options for fuel GCV and heat input for units using appendix D fuel flowmeters to determine heat input:
 - OTC requires monthly samples of fuel for GCV and density, if necessary.
 - Subpart H allows tank sampling for GCV and density under many conditions.

OTC to Subpart H LME Reporting Differences

- ◆ Changes to default methodologies under OTC for Low Mass Emitters
 - Applicability is different
 - Monitoring is different
 - Watch for potential rule changes in this section.

OTC to Subpart H LME Reporting Differences

- ◆ Applicability

- Peaking unit or any unit with HI less than 250 mmBtu/hr under OTC
- Mass emission limit under Subpart H
 - » Less than 25 tons of NO_x during ozone season
 - » Less than 50 tons of NO_x annually
 - » Must be met using 3 previous years historical HI data and default emission rate

OTC to Subpart H LME Reporting Differences

- ◆ LME Monitoring
 - 1.15 multiplier applied to the results of the Appendix E testing for fuel-and-unit specific NO_x emission rate under Subpart H
 - Minor differences in apportioning Heat Input under Subpart H
 - MDC software can be used to generate the entire EDR for LME units under Subpart H