

## Table of Contents

### Chapter 6.0


|   |           |
|---|-----------|
| <b>CASTNet Base Program .....</b>                 | <b>77</b> |
| <b>Quality Assurance .....</b>                    | <b>77</b> |
| <b>Network Precision .....</b>                    | <b>78</b> |
| <i>Field Data .....</i>                           | <i>78</i> |
| <i>Laboratory Analysis of Field Samples .....</i> | <i>78</i> |
| <i>Analytical Precision .....</i>                 | <i>78</i> |
| <b>Network Accuracy .....</b>                     | <b>79</b> |
| <i>Field Data .....</i>                           | <i>79</i> |
| <i>Laboratory Data .....</i>                      | <i>79</i> |
| <b>Analysis of Filter Blanks .....</b>            | <b>79</b> |
| <b>CASTNet Visibility Program .....</b>           | <b>79</b> |
| <i>Accuracy .....</i>                             | <i>79</i> |
| <i>Precision .....</i>                            | <i>80</i> |
| <b>Data Completeness .....</b>                    | <b>81</b> |



## Chapter 6.0

### Quality Assurance

---



#### CASTNet Base Program

CASTNet DQO have been formulated to provide data of known and documented quality for the continuous field data and the integrated samples, including exposed filters and precipitation. The DQO have been formulated in terms of precision and accuracy. The precision and accuracy objectives for the CASTNet field and laboratory measurements are listed in Tables 6-1 and 6-2.

Precision is a measure of the mutual agreement among individual measurements of the same property, usually under prescribed similar conditions. The primary assessment of overall precision was made using collocated (i.e., duplicate) sets of equipment at selected sites. Direct field measurements and laboratory measurements of field samples were compared in the same way. In addition, all laboratory measurements required two assessments of analytical precision: one to

assess sample-to-sample precision within a single analytical data batch, and one to assess batch-to-batch precision. Batch-to-batch precision was estimated only for filter pack analyses and was discontinued after the third quarter of 1998. Precipitation samples were analyzed for numerous parameters and were therefore not suitable for batch-to-batch replication.

The overall precision of meteorological variables and  $O_3$  was assessed quarterly by calculating the difference between simultaneous measurements (i.e., hourly averages) taken by separate instruments at collocated sites. Collocated sites have been selected to be representative of the observed range of pollutant concentrations and environmental conditions that exist within the network. Ashland, ME (ASH135) and Mackville, KY (MCK131) currently operate collocated dry deposition systems. These two sites are the ninth and tenth sites that have operated collocated systems over the history of the network. Concentrations measured at ASH135 are relatively low compared to other eastern sites but are reasonably

representative of the entire network. MCK131 measures moderately high concentrations. ALH157 operated a collocated precipitation sampling system during 1998. This is the second site with a collocated precipitation system. SIK570 operated a collocated aerosol sampling system. Sikes is the second visibility site with a collocated system.

The overall precision of atmospheric concentration and wet deposition data was assessed quarterly by calculating the absolute relative percent difference (ARPD) of values for simultaneous samples at collocated sites and averaging these values. Two collocated sites have been found to provide sufficient information to assess whether precision estimates continue to meet CASTNet objectives.

Analytical precision within sample batches was assessed by replicating 5% of the samples within an analysis (in-run replicates). Replicated samples were selected randomly.

Analytical precision from batch to batch for dry deposition anions and  $\text{NH}_4^+$  was estimated by analyzing selected samples in two separate batches. Five percent of each batch was selected at random and reanalyzed in a subsequent batch (blind replicates). Although no precision objectives were established for this analysis, comparisons allowed an estimate of batch-to-batch analytical precision. Batch-to-batch replication was discontinued because of the difficulty in interpreting results with respect to in-run replication. In batch-to-batch replication, samples were reanalyzed anywhere from 2 weeks to 2 to 3 months after initial analysis.

The accuracy of field measurements was determined by challenging instruments with standards that were traceable to the NIST. Continuing accuracy was verified during quarterly calibrations during the first half of 1998 and semi-annual calibrations thereafter by ESE personnel and during annual audits by an independent QA auditor. Data accuracy objectives for field measurements are listed in Table 6-1.

In practice, separate DQO are used for field calibrations and for data validation. Table 6-3 provides calibration acceptance (accuracy) criteria for field measurements. For example, an  $\text{O}_3$  instrument is adjusted if any calibration result (any point) is outside the  $\pm 5$  percent DQO. On the other hand,  $\text{O}_3$  data are considered valid if results are within  $\pm 10$  percent (Table 6-1).

The accuracy of laboratory measurements was determined by analyzing an independently prepared reference sample in each batch and calculating the percent recovery relative to the target (theoretical) value. The percent recovery was required to meet or exceed the acceptance criteria listed in Table 6-2. When possible, the reference was traceable to NIST, obtained directly from NIST (when available), or ordered from other laboratories. Unknown reference samples containing  $\text{SO}_4^{2-}$  and  $\text{NO}_3^-$  on filter media were also provided by the EPA Project QA Officer.

Unknown reference samples provided by EPA were extracted using CASTNet procedures and analyzed at the beginning and end of each IC analytical run.

## Network Precision

### Field Data

Precision statistics generated via collocated sampling efforts for 1998 are presented in Table 6-4. Precision estimates in ARPD for all meteorological parameters (except for temperature and delta temperature) and  $\text{O}_3$  ranged from 0.19 for flow to 81.61 for wetness. All measurements, except precipitation, meet precision criteria. Acceptance criteria for wetness sensors are undefined because the sensors are difficult to align with high precision within one hour of one another. Temperature and delta temperature results are presented as the quarterly average absolute differences (as shown in Table 6-4) because percent differences for these two parameters are not representative of sensor precision. Precision results as ARPD for precipitation often exceeded acceptance criteria as differences in very small volumes of hourly rainfall yield large ARPDs.

### Laboratory Analysis of Field Samples

Precision results by site via collocated sampling for filter pack data for 1998 are presented in Table 6-5. Precision estimates in ARPD for all analytes for the two collocated sites ranged from 1.35 for  $\text{SO}_4^{2-}$  to 21.22 for  $\text{HNO}_3$ . The greater exceedances from acceptance criteria were for  $\text{NO}_3^-$  for MCK131, and all analytes except  $\text{SO}_4^{2-}$  for ASH135. Concentrations for all analytes for ASH135 are extremely low in comparison to other eastern sites, and the  $\text{NO}_3^-$  concentrations for MCK131 are very low as well.

Precision results by site via collocated sampling at ALH157 for wet deposition data for 1998 are presented in Table 6-6. Precision estimates in ARPD for all analytes ranged from 4.12 for precipitation to 49.56 for  $\text{Ca}^{2+}$ . The high values for the cations (except  $\text{H}^+$ ) were the result of differences between extremely low concentrations. With a few exceptions, all ARPDs above 20.0 are from concentrations less than 1.0 mg/L.

### Analytical Precision

Precision results for filter pack data obtained from analysis of blind and in-run replicates are presented in Table 6-7. The percent differences for in-run replicates ranged from 0.56 for Teflon®- $\text{SO}_4^{2-}$  to 8.42 for nylon- $\text{SO}_4^{2-}$ . The percent differences for blind replicates ranged from 1.21 for Teflon®- $\text{SO}_4^{2-}$  to 12.97 for nylon- $\text{SO}_4^{2-}$ . In all but one case, in-run replicates exhibited greater precision than blind replicate results. This result was not unexpected since the blind replicates were analyzed up to 2 or 3 months after analysis of the original sample. At this point, the sample holding times exceeded recommended check limits. It is suspected that this might have been a factor in the decrease in precision in blind replicate analysis in comparison to in-run replicate analysis. In addition,

the IC columns could be in slightly different conditions depending on the age of the columns with respect to the original analysis. Because of these reasons, analysis of blind replicates was discontinued as stated previously.

Results of precision estimates for wet deposition sampling by replicate analysis are presented in Table 6-8. The percent differences ranged from 0.07 for  $\text{NO}_2$  to 28.9 for  $\text{H}^+$ . All wet deposition precision results, except for  $\text{H}^+$  and  $\text{Cl}^-$ , were within acceptance criteria.

## Network Accuracy

### *Field Data*

Results of accuracy as determined by instrument response relative to independent transfer standards are presented in Table 6-9. The data in Table 6-9 represent all calibrations for all sites in 1998. The table summarizes by quarter the number of instances for each parameter that data acceptance criteria (Table 6-1) were not met. For each exceedance, all pertinent information was reviewed; and data were either adjusted according to the calibration results or invalidated. Data were invalidated only if adjustment was impossible due to the nature of the failure. After second quarter 1998, quarterly calibrations were discontinued and replaced with semi-annual calibrations. This procedural change is reflected in the presentation of results in Table 6-9.

### *Laboratory Data*

Accuracy estimates for filter pack samples for 1998 are presented in Table 6-7. These values ranged from 98.5% for nylon- $\text{SO}_4^{2-}$  to 102.6 for nylon- $\text{NO}_3^-$ . Accuracy results were within acceptance criteria for all quarters and annually for all analytes.

Table 6-8 also presents the accuracy results for wet deposition sampling. Percent recoveries ranged from 95.1 for  $\text{Ca}^{2+}$  to 105.2 for  $\text{Na}^+$ . All accuracy results were within acceptance criteria.

## Analysis of Filter Blanks

In August 1998, ESE changed the manufacturer of Teflon® filters (see Table 1-4). This decision was made because of recurring problems with high background levels of  $\text{NO}_3^-$  on the filters. This problem was first experienced in October 1997. CAPMoN has also been experiencing high background levels on their Teflon® filters. Because of these problems, ESE decided to review the historical record of measured concentrations (i.e., background) on various blank filters for any trends or biases in background levels. This section summarizes the analysis of filter blanks.

Currently, ESE uses three types of filter blanks. Five percent of new Teflon® and nylon and two percent of Whatman impregnated filters

are tested for background. If tested filters exceed detection limits, then that box of filters is rejected for use and stored. Prior to late 1997, 2% of filters were tested. Two laboratory blanks are tested per week, and trip (field) blanks are sent quarterly to each monitoring site. The trip blanks are not exposed to the ambient air. Until 1996, trip blanks were shipped monthly to each site.

Table 6-10 summarizes the historical record of filter blanks. The average concentrations from the trip and laboratory blanks are almost equivalent to the detection limits. The data from the acceptance tests illustrate the problem with the  $\text{NO}_3^-$  background concentrations (e.g., a maximum concentration of 32.18  $\mu\text{g}$  (as N)) on the Teflon® filters. However, boxes of filters with background above the detection limits are not used for field sampling.

Because of the recent problem of high  $\text{NO}_3^-$  background on Teflon® filters, the field and laboratory blanks were analyzed in more detail. Figure 6-1 shows the background  $\text{NO}_3^-$  concentrations on Teflon® trip blanks for the period 1990 through 1998. Figure 6-2 shows laboratory blank results. These data show no change in average background concentrations over the 9-year period. A level of quantification (LOQ) can be defined as the average concentration plus three times its standard deviation. The trip blank results shown in Figure 6-1 have been used to calculate an LOQ for each of the 9 years. CASTNet particulate  $\text{NO}_3^-$  measurements for the period 1992 through 1998 were compared to the calculated LOQ. Appendix B provides the number of weeks by site and year when  $\text{NO}_3^-$  concentration was less than the LOQ and the number of weeks exceeded 20. This analysis gives an indication of uncertainty in nitrate measurements at those sites with low concentrations (i.e., below LOQ). Typically, four to six sites per year have 20 weeks or more with concentrations less than the LOQ. In general, however, this analysis shows there is not a significant problem with background contamination of CASTNet filters, and there is no trend or biases in background levels, except for the sites with very low  $\text{NO}_3^-$  concentrations.

## CASTNet Visibility Program

### *Accuracy*

The quarterly and annual accuracy results for the  $\text{SO}_4^{2-}$  and  $\text{NO}_3^-$  laboratory analyses are determined by analyzing a NIST reference sample at the beginning and end of each analytical batch to verify the accuracy and stability of the calibration curve (within 5% of the known value). The QC data are summarized in Table 6-7 along with the QC data for the CASTNet base program.

The quarterly and annual accuracy results for select analytes from Teflon® filter packs are determined by analyzing a NIST reference sample at the beginning and end of each batch to verify the accuracy

Table 6-1. Data Quality Objectives for CASTNet Field Measurements

| Measurement Parameter | Method                       | Objectives <sup>1</sup>                   |  |
|-----------------------|------------------------------|---|--|
|                       |                              | Precision                                 | Accuracy   |
| Wind Speed            | Anemometer                   | ± 0.5 m/sec<br>or ± 10%                   | ± 0.2 m/s < 5.0 m/s<br>± 5% ≥ 5.0 m/s  |
| Wind Direction        | Wind Vane                    | ± 5° or ± 2% of full scale                | ± 5°   |
| Sigma Theta           | Wind Vane                    | ± 10%                                     | Undefined  |
| Relative Humidity     | Hygrometer                   | ± 10% (of full scale)                     | ± 10% (of full scale)  |
| Solar Radiation       | Pyranometer                  | ± 10%<br>(of reading taken at local noon) | ± 10%  |
| Precipitation         | Tipping Bucket<br>Rain Gauge | ± 10% (of reading)                        | ± 0.05 inch <sup>2</sup>   |
| Ambient Temperature   | Platinum RTD                 | ± 0.5°C                                   | ± 0.25°C   |
| Delta Temperature     | Platinum RTD                 | ± 0.25°C                                  | ± 0.20°C   |
| O <sub>3</sub>        | UV Absorbance                | ± 10% (of reading)                        | ± 10% of actual value<br>0.900 < slope < 1.100<br>-10.0 ppb < int < 10.0 ppb |
| Filter Pack Flow      | Mass Flow Controller         | ± 10%                                     | ±10%   |
| Surface Wetness       | Conductivity Bridge          | Undefined                                 | Undefined  |

Note:

m/sec = meters per second.

RTD = resistance-temperature device.

<sup>1</sup>Precision criteria apply to collocated instruments, and accuracy criteria apply to the calibration of instruments.

<sup>2</sup>For target value of 0.50 inch.

and stability of the calibration curve (within 10 to 15% of the known value depending on the analyte). The QC data are summarized in Table 6-11.

Table 6-12 illustrates annual accuracy data for the carbon analysis. The accuracy is determined by the percent recovery of measured total carbon versus expected carbon within 10% of the expected value.

### Precision

#### Aerosol Data

The quarterly and annual precision results for the aerosol samples (nylon, Teflo®, quartz) are presented in Table 6-13. The analytical precision objectives for SO<sub>4</sub><sup>2-</sup>, NO<sub>3</sub><sup>-</sup>, organic and elemental carbon, and fine mass are ±10%. The analytical precision objectives for the trace/

crustal elements are ±20%. The precision data are the analytical results from the collocated aerosol samples taken at SIK570/270.

During the third quarter, the Teflo® filters at SIK270 were run without a “mask.” Consequently, the XRF measurements are not comparable. The mask was used during the fourth quarter. Results from the collocated denuder/nylon sampling systems do not compare for the fourth quarter. Consequently, precision is poor. ESE investigated the problem and concluded its cause involved gaskets and dirt on the cyclones, which were used randomly by the site operator for the SIK570 and SIK270 nylon filters. New cyclones were provided for the Sikes sampling systems.

#### Nephelometer Data

Precision is estimated by calculating the relative uncertainty of the data based on operator-initiated zero/span calibration checks. The CASTNet

Table 6-2. Data Quality Objectives for CASTNet Laboratory Measurements\*

| Analyte                                  | Medium | Method                | Acceptance Criteria |              |
|--|--------|-----------------------|---------------------|--------------|
|  |        |                       | Precision (ARPD)    | Accuracy (%) |
| pH (as H <sup>+</sup> )**                | W      | Electrometric         | 12                  | 85 - 115     |
| Conductivity                             | W      | Electrometric         | 10                  | 85 - 115     |
| Acidity                                  | W      | Titrimetric           | 15                  | NA           |
| Ammonium (NH <sub>4</sub> <sup>+</sup> ) | W/F    | Automated colorimetry | 10                  | 90 - 110     |
| Sodium (Na <sup>+</sup> )                | W/F    | ICAP-AE               | 10                  | 90 - 110     |
| Potassium (K <sup>+</sup> )              | W/F    | ICAP-AE               | 10                  | 90 - 110     |
| Magnesium (Mg <sup>2+</sup> )            | W/F    | ICAP-AE               | 10                  | 90 - 110     |
| Calcium (Ca <sup>2+</sup> )              | W/F    | ICAP-AE               | 10                  | 90 - 110     |
| Chloride (Cl <sup>-</sup> )              | W      | Ion chromatography    | 5                   | 95 - 105     |
| Nitrite (NO <sub>2</sub> <sup>-</sup> )  | W      | Ion chromatography    | 5                   | NA           |
| Nitrate (NO <sub>3</sub> <sup>-</sup> )  | W/F    | Ion chromatography    | 5                   | 95 - 105     |
| Sulfate (SO <sub>4</sub> <sup>2-</sup> ) | W/F    | Ion chromatography    | 5                   | 95 - 105     |
| Elemental Carbon                         | QF     | TOA                   | 10                  | 90 - 100     |
| Organic Carbon                           | QF     | TOA                   | 10                  | 90 - 100     |
| Mass                                     | TF     | Gravimetric           | ± 10 µg             | ± 3 µg       |
| Trace/Crustal Elements                   | TF     | XRF                   | 20                  | 96.8 - 114   |

Note: F = filter pack samples.  
 ICAP-AE = inductively coupled argon plasma-atomic emission.  
 ARPD = absolute relative percent difference.  
 W = wet deposition samples.  
 QF = quartz filter  
 TF = Teflon® filter

\* The precision criteria apply to the laboratory analysis of field samples and laboratory replicates.

\*\* Precision and accuracy results are based on H<sup>+</sup> concentrations. The accuracy and precision criteria represent approximately ±0.05 pH unit.

nephelometer precision objectives are ±15%. The nephelometer precision results for 1998 are presented in Table 6-14.

## Data Completeness

Tables 6-15 through 6-18 present data completeness statistics for continuous, filter(dry deposition), precipitation chemistry, and visibility measurements for 1998. The meteorological, O<sub>3</sub>, precipitation, and visibility chemistry data are based on those sites operated by ESE. The dry deposition concentration statistics are based on all CASTNet sites. ESE was responsible for operation of EPA-sponsored sites and chemical analysis of all exposed filters. ARS was responsible

for field operations of NPS-sponsored sites. Average data capture exceeded 90% for the four data sets. However, the data completeness statistics for the continuous measurements are somewhat lower than for previous years. Nineteen ninety-eight was the first year ESE performed semi-annual calibrations, rather than quarterly calibrations. Data completeness for filter sampling was excellent. Only one site (Sequoia National Park - SEK402) missed the 90% goal. Data completeness for precipitation samples was also excellent. Concentration measurements from the nylon filters at Sikes were problematical during the last few months of 1998. Otherwise, completeness statistics for the visibility aerosol measurements are above 95%.



Table 6-3. Calibration Acceptance Criteria for CASTNet Field Measurements

| Measurement Parameter  | Measurement Method      | Calibration Method                        | Acceptance Criteria  |
|------------------------|-------------------------|---|--|
| Wind Speed             | Anemometer              | Adjustable Synchronous Motor              | $\pm 0.2$ m/sec < 5 m/sec<br>$\pm 5\% \geq 5$ m/sec  |
| Wind Direction         | Wind Vane               | Vane aligned with compass sighted target  | $\pm 3^\circ$ each point   |
| Relative Humidity (RH) | Thin Film Capacitor     | Transfer Sensor or standard salts         | $\pm 10\%$ RH < 80% $\pm 5\%$ RH $\geq 80\%$   |
| Solar Radiation        | Pyranometer             | Transfer Sensor                           | $\pm 5\%$ of average   |
| Precipitation          | Tipping Bucket Gauge    | Know Volume Addition                      | $\pm 0.02$ inches at 0.50 inches   |
| Temperature            | Platinum RTD            | Certified Platinum RTD in isothermal bath | $\pm 0.15^\circ\text{C}$   |
| Delta Temperature      | Platinum RTD            | Certified Platinum RTD in isothermal bath | $\pm 0.15^\circ\text{C}$   |
| O <sub>3</sub>         | UV Photometric Analyzer | Certified Transfer Photometer             | $\pm 5\%$ of actual for any value<br>$0.9500 < \text{slope} < 1.050$<br>$-3.0 \text{ ppb} < \text{Intercept} < 3.0 \text{ ppb}$<br>$r^2 > 0.995$ |
| Surface Wetness        | Conductivity Bridge     | Test with 230-240 K $\Omega$ resistance   | Full-scale response to test resistance   |
| Filter Pack Flow       | Mass Flow Controller    | Mass Flow Meter or Dry Piston Meter       | $\pm 2\%$ of actual flow rate  |

Table 6-4. Precision (Mean ARPD) for Continuous Data via Collocated Sampling for 1998

| Site ID    | Temp* | Delta Temp* | Relative Humidity | Solar Radiation | Ozone | Wind Speed | Wind Direction | Sigma Theta | Prec. | Wetness | Flow |
|------------|-------|-------------|-------------------|-----------------|-------|------------|----------------|-------------|-------|---------|------|
| Quarter    |       |             |                   |                 |       |            |                |             |       |         |      |
| ASH135/235 |       |             |                   |                 |       |            |                |             |       |         |      |
| First      | 0.19  | 0.23        | 3.54              | 4.39            | 0.65  | 1.24       | 0.70           | 3.66        | 20.30 | 81.61   | 0.19 |
| Second     | 0.14  | 0.21        | 2.28              | 1.63            | 1.31  | 2.73       | 0.92           | 3.01        | 33.20 | 21.88   | 0.21 |
| Third      | 0.05  | 0.07        | 2.91              | 1.40            | 2.11  | 2.06       | 0.99           | 2.90        | 21.41 | 12.95   | 0.19 |
| Fourth     | 0.08  | 0.03        | 3.76              | 3.18            | 2.19  | 2.08       | 1.09           | 2.90        | 36.36 | 13.73   | 0.24 |
| Annual     | 0.12  | 0.14        | 3.12              | 2.65            | 1.57  | 2.03       | 0.93           | 3.12        | 27.82 | 32.54   | 0.21 |
| MCK131/231 |       |             |                   |                 |       |            |                |             |       |         |      |
| First      | 0.06  | 0.12        | 3.72              | 5.63            | 1.94  | 2.47       | 1.17           | 1.91        | 15.91 | 14.53   | 0.20 |
| Second     | 0.22  | 0.09        | 5.69              | 3.02            | 1.54  | 3.64       | 0.93           | 2.53        | 7.73  | 25.33   | 0.56 |
| Third      | 0.11  | 0.11        | 7.38              | 2.75            | 1.72  | 3.85       | 2.24           | 3.55        | 6.69  | 18.24   | 0.53 |
| Fourth     | 0.21  | 0.15        | 2.90              | 2.60            | 6.71  | 5.47       | 1.62           | 3.23        | 13.48 | 14.84   | 0.46 |
| Annual     | 0.15  | 0.12        | 4.92              | 3.50            | 2.98  | 3.86       | 1.49           | 2.81        | 10.95 | 18.24   | 0.44 |

Note: ARPD = Absolute Relative Percent Difference.  
 Prec. = Precipitation.  
 \* Absolute Relative Difference Reported.



Table 6-5. Precision (Mean ARPD) for Filter Pack Data via Collocated Sampling for 1998

| Site ID    | Quarter | SO <sub>4</sub> <sup>2-</sup> | NO <sub>3</sub> <sup>-</sup> | HNO <sub>3</sub> | SO <sub>2</sub> | NH <sub>4</sub> <sup>+</sup> | Total NO <sub>3</sub> <sup>-</sup> |
|------------|---------|-------------------------------|------------------------------|------------------|-----------------|------------------------------|------------------------------------|
| ASH135/235 | First   | 3.91                          | 12.54                        | 10.82            | 5.14            | 8.73                         | 9.75                               |
|            | Second  | 4.95                          | 15.86                        | 9.03             | 17.50           | 13.32                        | 9.28                               |
|            | Third   | 3.22                          | 16.53                        | 17.33            | 11.33           | 8.11                         | 13.35                              |
|            | Fourth  | 8.22                          | 9.82                         | 21.22            | 8.87            | 8.31                         | 14.90                              |
|            | Annual  | 5.10                          | 13.71                        | 14.68            | 10.69           | 9.64                         | 11.86                              |
| MCK131/231 | First   | 1.35                          | 6.54                         | 3.73             | 2.89            | 1.60                         | 2.89                               |
|            | Second  | 3.72                          | 13.94                        | 3.11             | 3.41            | 3.25                         | 3.18                               |
|            | Third   | 5.00                          | 14.06                        | 6.52             | 4.65            | 6.34                         | 5.47                               |
|            | Fourth  | 7.81                          | 15.54                        | 8.29             | 9.29            | 7.71                         | 8.08                               |
|            | Annual  | 4.53                          | 12.64                        | 5.45             | 5.02            | 4.79                         | 4.95                               |

Note: ARPD = Absolute Relative Percent Difference.

Table 6-6. Precision (Mean ARPD) for Wet Deposition Data via Collocated Sampling for 1998

| Site ID    | Quarter | H <sup>+</sup> | NH <sub>4</sub> <sup>+</sup> | Na <sup>+</sup> | Ca <sup>2+</sup> | Mg <sup>2+</sup> | SO <sub>4</sub> <sup>2-</sup> | NO <sub>3</sub> <sup>-</sup> | Prec. |
|------------|---------|----------------|------------------------------|-----------------|------------------|------------------|-------------------------------|------------------------------|-------|
| ALH157/257 | First   | 19.55          | 20.45                        | 28.44           | 36.30            | 37.18            | 16.64                         | 25.89                        | 4.12  |
|            | Second  | 20.22          | 26.32                        | 28.33           | 20.41            | 29.18            | 15.95                         | 14.33                        | 7.16  |
|            | Third   | 7.66           | 26.46                        | 15.98           | 19.35            | 18.53            | 11.37                         | 11.14                        | 5.21  |
|            | Fourth  | 18.03          | 33.88                        | 30.55           | 49.56            | 44.88            | 25.36                         | 26.19                        | 13.90 |
|            | Annual  | 16.23          | 26.25                        | 25.58           | 30.87            | 32.00            | 16.93                         | 19.33                        | 7.31  |

Note: ARPD = Absolute Relative Percent Difference.

Prec. = Precipitation amount from Belfort rain gauge.

Table 6-7. Laboratory Accuracy (Percent Recovery) and Precision (Mean Absolute Percent Difference) for Filter Pack Data ( $\mu\text{g}/\text{filter}$ ) for 1998

|                            | Teflon®            |                 | Nylon              |                 | Whatman            |                 |
|----------------------------|--------------------|-----------------|--------------------|-----------------|--------------------|-----------------|
|                            | $\text{SO}_4^{2-}$ | $\text{NO}_3^-$ | $\text{SO}_4^{2-}$ | $\text{NO}_3^-$ | $\text{SO}_4^{2-}$ | $\text{NO}_3^-$ |
| <b>First Quarter</b>       |                    |                 |                    |                 |                    |                 |
| Accuracy                   | 100.5              | 100.3           | 100.8              | 101.7           | 98.7               | 99.8            |
| Precision Blind Replicate  | 1.69               | 2.41            | 12.97              | 2.70            | 3.35               | 4.48            |
| Precision In-Run Replicate | 0.56               | 0.84            | 5.77               | 1.78            | 2.16               | 4.66            |
| <b>Second Quarter</b>      |                    |                 |                    |                 |                    |                 |
| Accuracy                   | 100.7              | 100.4           | 101.3              | 100.2           | 98.7               | 99.9            |
| Precision Blind Replicate  | 1.21               | 2.43            | 9.25               | 4.12            | 5.73               | 7.36            |
| Precision In-Run Replicate | 0.59               | 1.19            | 6.06               | 1.91            | 2.92               | 5.55            |
| <b>Third Quarter</b>       |                    |                 |                    |                 |                    |                 |
| Accuracy                   | 100.1              | 100.1           | 98.5               | 102.6           | 100.0              | 100.3           |
| Precision Blind Replicate  | 1.35               | 5.94            | 11.64              | 2.36            | 6.01               | 9.15            |
| Precision In-Run Replicate | 0.76               | 3.06            | 4.63               | 1.79            | 3.15               | 7.15            |
| <b>Fourth Quarter</b>      |                    |                 |                    |                 |                    |                 |
| Accuracy                   | 99.4               | 102.1           | 99.6               | 102.2           | 101.8              | 102.3           |
| Precision Blind Replicate  | NA                 | NA              | NA                 | NA              | NA                 | NA              |
| Precision In-Run Replicate | 2.58               | 3.68            | 8.42               | 3.53            | 2.41               | 3.03            |
| <b>Annual</b>              |                    |                 |                    |                 |                    |                 |
| Accuracy                   | 100.1              | 100.7           | 100.0              | 101.8           | 99.8               | 100.7           |
| Precision Blind Replicate  | 1.42               | 3.49            | 12.03              | 3.95            | 5.05               | 7.00            |
| Precision In-Run Replicate | 1.14               | 2.09            | 6.30               | 2.81            | 2.54               | 4.91            |

Note: NA = not applicable (discontinued).

Table 6-8. Laboratory Accuracy (Percent Recovery) and Precision (Mean Absolute Percent Difference) for Wet Deposition Data for 1998

|                       | H <sup>+</sup> | Conductivity | SO <sub>4</sub> <sup>2-</sup> | NO <sub>3</sub> <sup>-</sup> | Cl <sup>-</sup> | NH <sub>4</sub> <sup>+</sup> | Ca <sup>2+</sup> | Mg <sup>2+</sup> | Na <sup>+</sup> | K <sup>+</sup> | NO <sub>2</sub> | Acidity |
|-----------------------|----------------|--------------|-------------------------------|------------------------------|-----------------|------------------------------|------------------|------------------|-----------------|----------------|-----------------|---------|
| <b>First Quarter</b>  |                |              |                               |                              |                 |                              |                  |                  |                 |                |                 |         |
| Accuracy              | 99.7           | 98.2         | 100.2                         | 101.5                        | 100.5           | 100.6                        | 95.1             | 98.6             | 103.1           | 102.2          | NA              | NA      |
| Precision             | 2.39           | 1.85         | 0.56                          | 0.75                         | 3.48            | 3.38                         | 2.81             | 0.41             | 0.48            | 1.17           | 0.89            | 1.32    |
| <b>Second Quarter</b> |                |              |                               |                              |                 |                              |                  |                  |                 |                |                 |         |
| Accuracy              | 99.6           | 96.4         | 100.2                         | 101.2                        | 100.7           | 100.7                        | 101.8            | 97.9             | 105.2           | 100.0          | NA              | NA      |
| Precision             | 7.18           | 0.87         | 0.49                          | 0.56                         | 5.86            | 3.13                         | 3.33             | 1.41             | 0.88            | 1.79           | 3.26            | 4.73    |
| <b>Third Quarter</b>  |                |              |                               |                              |                 |                              |                  |                  |                 |                |                 |         |
| Accuracy              | 100.4          | 97.1         | 100.7                         | 101.7                        | 101.7           | 98.02                        | 104.1            | 101.1            | 99.3            | 96.2           | NA              | NA      |
| Precision             | 12.09          | 0.93         | 0.74                          | 0.82                         | 12.37           | 3.91                         | 3.65             | 1.58             | 0.67            | 0.39           | 0.96            | 3.83    |
| <b>Fourth Quarter</b> |                |              |                               |                              |                 |                              |                  |                  |                 |                |                 |         |
| Accuracy              | 100.6          | 96.4         | 100.9                         | 102.3                        | 100.0           | 100.1                        | 105.0            | 101.7            | 101.0           | 99.9           | NA              | NA      |
| Precision             | 28.9           | 3.91         | 2.07                          | 0.54                         | 5.14            | 7.34                         | 4.65             | 2.45             | 1.15            | 2.42           | 0.07            | 7.05    |
| <b>Annual</b>         |                |              |                               |                              |                 |                              |                  |                  |                 |                |                 |         |
| Accuracy              | 100.0          | 96.7         | 100.5                         | 101.7                        | 100.6           | 99.9                         | 100.9            | 99.6             | 102.4           | 99.9           | NA              | NA      |
| Precision             | 12.97          | 1.96         | 0.89                          | 0.61                         | 6.59            | 4.50                         | 3.56             | 1.46             | 0.79            | 1.25           | 1.03            | 4.18    |

Note: NA = Reference sample not available.

Table 6-9. Accuracy Results\* for Continuous Measurements Determined from Results of Quarterly and Semi-annual Calibrations

| Quarter<br>(Number<br>of Sites) | Temperature |       | Delta Temperature |       | Wind Speed |      | Wind<br>Dir. | Rel.<br>Hum. | Solar<br>Rad. | Prec. | Wetness | O <sub>3</sub> | Flow |
|---------------------------------|-------------|-------|-------------------|-------|------------|------|--------------|--------------|---------------|-------|---------|----------------|------|
|                                 | Ambient     | 0-5°C | Ambient           | 0-5°C | Low        | High |              |              |               |       |         |                |      |
| First<br>(n = 50)               | 11          | 8     | 3                 | 3     | 5          | 1    | 5            | 1            | 1             | 2     | 0       | 2              | 1    |
| Second<br>(n = 50)              | 9           | 5     | 5                 | 4     | 1          | 0    | 4            | 1            | 2             | 2     | 0       | 0              | 3    |
| Third & Fourth<br>(n = 50)      | 12          | 6     | 2                 | 2     | 2          | 4    | 4            | 2            | 5             | 1     | 0       | 2              | 0    |

Note: Prec. = precipitation.  
 Rel. Hum. = relative humidity.  
 Solar Rad. = solar radiation.  
 Wind Dir. = wind direction.

\* Number of times an instrument did not meet accuracy criteria (Table 6-1).

Table 6-10. Summary of Filter Blanks

| Trip Blanks (1990 - 1998)                 |                 |           |              |           |           |       |
|---|-----------------|-----------|--------------|-----------|-----------|-------|
| Parameter Name                            | Detection Limit | Total No. | Avg T.ug     | Std. Dev. | Max       |       |
| Teflon®-NH <sub>4</sub> <sup>+</sup> -N   | 0.50 T.µg       | 3963      | 0.52         | 0.19      | 10.52     |       |
| Teflon®-NO <sub>3</sub> <sup>-</sup> -N   | 0.20 T.µg       | 3974      | 0.21         | 0.05      | 0.88      |       |
| Teflon®-SO <sub>4</sub> <sup>2-</sup>     | 1.00 T.µg       | 3969      | 1.00         | 0.11      | 6.45      |       |
| Nylon-NO <sub>3</sub> <sup>-</sup> -N     | 0.20 T.µg       | 3944      | 0.21         | 0.16      | 9.50      |       |
| Nylon-SO <sub>4</sub> <sup>2-</sup>       | 1.00 T.µg       | 3956      | 1.02         | 0.29      | 15.17     |       |
| Whatman-NO <sub>3</sub> <sup>-</sup> -N   | 0.40 T.µg       | 3941      | 0.58         | 0.29      | 3.10      |       |
| Whatman-SO <sub>4</sub> <sup>2-</sup>     | 2.00 T.µg       | 3925      | 2.65         | 1.60      | 22.61     |       |
| Laboratory Blanks (1990 - 1998)           |                 |           |              |           |           |       |
| Parameter Name                            | Detection Limit | Total No. | Avg T.ug     | Std. Dev. | Max       |       |
| Teflon®-SO <sub>4</sub> <sup>2-</sup>     | 1.00 T.µg       | 772       | 1.01         | 0.20      | 6.58      |       |
| Teflon®-NH <sub>4</sub> <sup>+</sup> -N   | 0.50 T.µg       | 770       | 0.53         | 0.15      | 2.33      |       |
| Teflon®-NO <sub>3</sub> <sup>-</sup> -N   | 0.20 T.µg       | 767       | 0.21         | 0.06      | 1.51      |       |
| Nylon-SO <sub>4</sub> <sup>2-</sup>       | 1.00 T.µg       | 762       | 1.01         | 0.15      | 4.96      |       |
| Nylon-NO <sub>3</sub> <sup>-</sup> -N     | 0.20 T.µg       | 769       | 0.20         | 0.00      | 0.23      |       |
| Whatman-SO <sub>4</sub> <sup>2-</sup>     | 2.00 T.µg       | 768       | 2.19         | 0.73      | 8.38      |       |
| Whatman-NO <sub>3</sub> <sup>-</sup> -N   | 0.40 T.µg       | 771       | 0.46         | 0.18      | 2.66      |       |
| Acceptance Test Values (1990 - 1998)      |                 |           |              |           |           |       |
| Parameter Name                            | Detection Limit | Total No. | No. Above DL | Avg T.ug  | Std. Dev. | Max   |
| Teflon®-NO <sub>3</sub> <sup>-</sup> , -N | 0.20 T.µg       | 1760      | 182          | 0.64      | 2.49      | 32.18 |
| Teflon®-SO <sub>4</sub> <sup>2-</sup>     | 1.00 T.µg       | 1760      | 5            | 2.82      | 2.00      | 5.01  |
| Nylon-NO <sub>3</sub> <sup>-</sup> , -N   | 0.20 T.µg       | 1609      | 96           | 0.33      | 0.13      | 0.63  |
| Nylon-SO <sub>4</sub> <sup>2-</sup>       | 1.00 T.µg       | 1609      | 63           | 2.23      | 1.76      | 6.24  |
| Whatman*-SO <sub>4</sub> <sup>2-</sup>    | 2.00 T.µg       | 3372      | 232          | 3.22      | 1.25      | 9.71  |

Note: T = Total

Whatman filters are not analyzed for ambient NO<sub>3</sub><sup>-</sup>. The blank results are used only for QC.



Figure 6-1. Results of Analysis for  $\text{NO}_3^-$  on Trip BlanksFigure 6-2. Results of Analysis for  $\text{NO}_3^-$  on Laboratory Blanks

Table 6-11. Quarterly and Annual Accuracy Results for Select Analytes from Teflo® Filters for 1998 (Chester LabNet)

| Analyte/SRM    | Silicon/1832 | Silicon/1833 | Calcium/1832 | Titanium/1833 | Iron/1833 |
|----------------|--------------|--------------|--------------|---------------|-----------|
| 1st Quarter    | 98.00        | 97.10        | 103.05       | 100.25        | 101.40    |
| 2nd Quarter    | 99.2         | 98.8         | 104.3        | 100.9         | 98.5      |
| 3rd Quarter    | 100.7        | 101.2        | 104.2        | 98.7          | 99.9      |
| 4th Quarter    | 100.8        | 100.0        | 103.6        | 97.1          | 105.1     |
| Annual Average | 99.68        | 99.28        | 103.79       | 99.24         | 101.23    |

Note: SRM is standard reference method for analytical chemistry measurements.

Table 6-12. Quarterly and Annual Accuracy Results from Quartz Filters for 1998 (Sunset Laboratory)

| Date           | Total Carbon<br>(µg/sq cm) | Expected<br>Total Carbon | Percent<br>Recovery |
|----------------|----------------------------|--------------------------|---------------------|
| First Quarter  | 69.25                      | 68.56                    | 101.01              |
| Second Quarter | 64.53                      | 62.43                    | 103.37              |
| Third Quarter  | 63.82                      | 63.77                    | 100.08              |
| Fourth Quarter | 102.22                     | 102.59                   | 99.64               |
| Annual Average | –                          | –                        | 101.03              |

Note: The quarterly results are based on approximately 20 samples with expected carbon values that range from 20 to 200 µg/sq cm.

Table 6-13. Quarterly and Annual Precision Results (Mean ARPD) for Select Analytes from Collocated Aerosol Samples for 1998

| Analyte        | NO <sub>3</sub>    | SO <sub>4</sub> <sup>2-</sup> | Elemental Carbon   | Organic Carbon | Calcium | Iron  | Fine Mass | Sulfur | Silicon            |
|----------------|--------------------|-------------------------------|--------------------|----------------|---------|-------|-----------|--------|--------------------|
| 1st Quarter    | 8.57               | 5.49                          | 23.84 <sup>1</sup> | 5.24           | 15.09   | 10.86 | 9.69      | 11.85  | 10.92 <sup>2</sup> |
| 2nd Quarter    | 18.28 <sup>1</sup> | 9.67                          | 12.22 <sup>1</sup> | 7.00           | 9.83    | 6.76  | 5.49      | 2.73   | 11.50              |
| 3rd Quarter    | 9.52               | 2.35                          | 20.00 <sup>1</sup> | 8.43           | 23.94   | 21.83 | 3.21      | 32.19  | 22.38              |
| 4th Quarter    | 55.26              | 70.57                         | 24.56 <sup>1</sup> | 7.65           | 10.22   | 6.79  | 6.36      | 7.12   | 10.98              |
| Annual Average | N/A                | N/A                           | 20.16              | 7.08           | 14.77   | 11.56 | 6.19      | 13.47  | 13.95              |

<sup>1</sup> The elevated percent difference is a result of low mean concentrations.

<sup>2</sup> The reported percent difference does not include one outlier of 86.46 percent from the February 4, 1998 sample date.

Note: Results are derived from data collected at SIK570 and SIK270. During the third quarter, the Teflo® filters at SIK270 were run without a “mask.” Consequently, the XRF measurements are not comparable. The mask was used during the fourth quarter. Results from the collocated denuder/nylon sampling systems do not compare for the fourth quarter. Consequently, precision is poor. ESE investigated the problem and concluded its cause involved gaskets and dirt on the cyclones, which were used randomly for the SIK570 and SIK270 nylon filters. New cyclones were provided for the Sikes sampling systems.

Table 6-14. Quarterly and Annual Precision Results for Nephelometer Data for 1998

| Sampling Period | CDZ571 | QAK572 |
|-----------------|--------|--------|
| First Quarter   | 10.5%  | 8.9%   |
| Second Quarter  | 6.0%   | 15.4%  |
| Third Quarter   | 11.7%  | 25.4%  |
| Fourth Quarter  | 9.3%   | 8.8%   |
| Annual Average  | 9.4%   | 14.6%  |



Table 6-15. Percent Data Completeness for Continuous Measurements for 1998

| Site ID | Temperature | Delta Temperature | Relative Humidity | Solar Radiation | Ozone | Precipitation | Wind Speed | Wind Direction | Sigma Theta | Flow Rate | Scalar Wind Speed | Wetness | Average |
|---------|-------------|-------------------|-------------------|-----------------|-------|---------------|------------|----------------|-------------|-----------|-------------------|---------|---------|
| ABT147  | 99.4        | 99.4              | 98.9              | 99.5            | 98.4  | 99.4          | 98.5       | 98.5           | 98.5        | 99.8      | 98.5              | 99.4    | 99.0    |
| ALH157  | 77.5        | 74.8              | 99.2              | 99.6            | 98.7  | 98.7          | 91.2       | 91.2           | 91.2        | 99.8      | 90.6              | 96.7    | 92.4    |
| ANA115  | 99.0        | 98.9              | 98.9              | 97.7            | 94.3  | 98.6          | 98.8       | 98.8           | 98.6        | 99.5      | 97.9              | 97.8    | 98.2    |
| ARE128  | 95.4        | 95.4              | 99.5              | 99.4            | 98.6  | 98.0          | 99.2       | 99.2           | 99.2        | 98.6      | 99.2              | 99.4    | 98.4    |
| ASH135  | 97.9        | 97.9              | 99.2              | 99.4            | 98.0  | 98.9          | 96.2       | 96.2           | 96.2        | 99.9      | 96.0              | 93.0    | 97.4    |
| ASH235  | 99.2        | 99.2              | 99.4              | 99.6            | 98.1  | 99.1          | 97.0       | 97.0           | 97.0        | 99.8      | 97.0              | 98.7    | 98.4    |
| BEL116  | 93.7        | 93.6              | 69.6              | 93.7            | 92.9  | 93.5          | 93.3       | 93.3           | 93.3        | 96.7      | 93.2              | 72.9    | 90.0    |
| BFT142  | 94.7        | 93.9              | 92.4              | 88.8            | 97.8  | 97.2          | 97.1       | 97.1           | 97.1        | 99.2      | 97.1              | 97.1    | 95.8    |
| BVL130  | 98.5        | 98.5              | 98.5              | 98.6            | 98.6  | 98.6          | 97.9       | 97.9           | 97.4        | 99.1      | 97.6              | 98.0    | 98.3    |
| BWR139  | 98.7        | 87.1              | 98.7              | 98.9            | 97.7  | 98.7          | 98.6       | 98.6           | 98.6        | 99.8      | 98.6              | 88.3    | 96.9    |
| CAD150  | 97.8        | 85.4              | 97.8              | 97.8            | 97.2  | 96.3          | 97.4       | 97.4           | 97.3        | 98.1      | 96.8              | 97.1    | 96.4    |
| CAT175  | 97.1        | 97.1              | 97.1              | 97.8            | 34.9  | 97.0          | 96.7       | 96.7           | 96.7        | 99.4      | 96.6              | 96.7    | 92.0    |
| CDR119  | 98.7        | 91.9              | 98.7              | 98.9            | 93.6  | 99.3          | 97.9       | 97.9           | 97.9        | 99.1      | 97.9              | 99.2    | 97.6    |
| CDZ571  | 97.0        | 96.9              | 82.8              | 93.6            | 96.0  | 95.1          | 35.9       | 35.9           | 35.9        | NA        | 97.0              | 86.2    | 77.5    |
| CKT136  | 98.9        | 94.9              | 92.2              | 99.4            | 98.0  | 99.0          | 70.4       | 70.3           | 70.3        | 99.7      | 98.8              | 98.9    | 90.9    |
| CND125  | 98.8        | 98.8              | 89.8              | 85.9            | 95.8  | 95.3          | 97.2       | 97.2           | 97.2        | 99.8      | 97.2              | 93.0    | 95.5    |
| CNT169  | 98.4        | 97.8              | 98.5              | 98.7            | 97.0  | 97.8          | 92.1       | 92.1           | 92.1        | 99.1      | 92.1              | 95.5    | 95.9    |
| COW137  | 98.8        | 98.8              | 99.0              | 99.2            | 91.4  | 98.5          | 98.8       | 98.8           | 98.8        | 97.9      | 98.8              | 97.1    | 98.0    |
| CTH110  | 98.7        | 98.7              | 98.1              | 99.1            | 98.2  | 99.5          | 94.9       | 94.9           | 94.9        | 99.2      | 97.4              | 96.8    | 97.5    |
| CVL151  | 94.9        | 90.5              | 95.7              | 95.9            | 95.0  | 94.4          | 88.0       | 88.0           | 88.0        | 99.3      | 94.2              | 95.0    | 93.2    |
| DCP114  | 99.4        | 99.4              | 96.8              | 96.6            | 98.4  | 99.1          | 96.5       | 96.5           | 96.5        | 99.6      | 99.4              | 98.6    | 98.1    |
| EGB181  | 98.8        | 98.8              | 99.2              | 93.2            | NA    | 98.5          | 99.1       | 99.1           | 99.1        | 99.0      | 99.0              | 98.4    | 98.4    |
| ESP127  | 98.3        | 97.0              | 97.1              | 97.3            | 96.0  | 97.1          | 97.1       | 97.1           | 97.1        | 99.6      | 96.8              | 86.7    | 96.4    |
| GAS153  | 93.9        | 93.9              | 78.0              | 83.9            | 94.9  | 95.5          | 95.7       | 95.7           | 95.6        | 99.6      | 95.9              | 95.6    | 93.2    |
| GTH161  | 93.2        | 93.2              | 85.8              | 97.6            | 98.2  | 98.5          | 99.1       | 99.1           | 99.1        | 99.6      | 98.8              | 99.2    | 96.8    |
| HOW132  | 81.7        | 56.9              | 77.1              | 89.2            | 96.5  | 98.6          | 76.2       | 76.2           | 76.2        | 99.1      | 79.4              | 87.2    | 82.9    |
| KEF112  | 98.2        | 96.3              | 98.3              | 98.5            | 91.1  | 97.6          | 97.6       | 97.6           | 97.6        | 98.2      | 97.6              | 97.1    | 97.1    |
| LRL117  | 98.4        | 92.1              | 72.7              | 91.1            | 97.7  | 98.9          | 95.3       | 95.3           | 95.3        | 99.9      | 98.9              | 74.6    | 92.5    |
| LYE145  | 99.0        | 99.1              | 76.4              | 85.3            | 21.2  | 98.4          | 88.7       | 88.7           | 88.7        | 97.6      | 94.7              | 98.9    | 86.4    |
| LYK123  | 95.7        | 72.9              | 99.6              | 96.5            | 98.7  | 99.6          | 99.6       | 99.6           | 99.6        | 99.5      | 99.6              | 95.0    | 96.3    |
| MCK131  | 96.9        | 75.8              | 94.3              | 97.6            | 96.4  | 97.8          | 95.3       | 95.3           | 95.3        | 99.2      | 95.3              | 91.9    | 94.3    |
| MCK231  | 95.8        | 94.3              | 96.8              | 97.5            | 83.3  | 96.1          | 96.7       | 96.7           | 95.5        | 98.7      | 96.7              | 96.7    | 95.4    |
| MKG113  | 99.0        | 99.0              | 99.0              | 99.2            | 95.3  | 98.7          | 98.4       | 98.4           | 98.4        | 99.2      | 98.7              | 97.1    | 98.4    |
| OXF122  | 99.4        | 99.4              | 99.4              | 99.6            | 97.5  | 99.2          | 99.0       | 99.0           | 99.0        | 99.6      | 99.0              | 97.4    | 99.0    |
| PAR107  | 99.4        | 99.4              | 99.4              | 96.9            | 96.9  | 85.1          | 99.2       | 99.2           | 99.2        | 99.9      | 99.0              | 91.8    | 97.1    |
| PED108  | 98.7        | 98.6              | 98.7              | 98.9            | 90.2  | 92.4          | 92.0       | 92.0           | 92.0        | 99.1      | 98.1              | 82.8    | 94.5    |
| PND165  | 96.2        | 91.9              | 99.6              | 99.7            | 98.7  | 99.6          | 99.4       | 99.4           | 99.4        | 96.5      | 99.4              | 97.3    | 98.1    |
| PNF126  | 94.6        | 87.7              | 92.1              | 88.2            | 93.6  | 90.4          | 61.8       | 61.8           | 61.8        | 99.1      | 61.8              | 78.3    | 80.9    |
| PRK134  | 99.2        | 98.8              | 97.6              | 99.4            | 97.9  | 98.4          | 78.7       | 78.7           | 78.7        | 97.0      | 78.2              | 95.6    | 91.5    |
| PSU106  | 98.8        | 92.5              | 82.9              | 99.2            | 52.4  | 98.9          | 98.3       | 98.3           | 98.3        | 99.8      | 98.9              | 99.0    | 93.1    |
| QAK572  | 97.1        | 90.7              | 97.1              | 97.2            | 94.9  | 97.0          | 97.1       | 97.1           | 97.1        | NA        | 97.1              | 95.8    | 96.2    |
| SAL133  | 98.3        | 98.3              | 98.3              | 91.2            | 96.8  | 99.4          | 94.4       | 94.4           | 94.5        | 99.7      | 97.8              | 91.9    | 96.3    |
| SND152  | 95.6        | 95.6              | 80.8              | 99.7            | 98.6  | 97.8          | 99.3       | 99.3           | 99.3        | 99.8      | 99.3              | 98.9    | 97.0    |
| SPD111  | 99.0        | 95.1              | 99.0              | 98.9            | 97.6  | 97.9          | 97.7       | 97.7           | 97.7        | 99.3      | 98.6              | 98.2    | 98.1    |
| STK138  | 92.9        | 0.0               | 97.6              | 97.8            | 92.1  | 94.5          | 93.2       | 93.2           | 93.2        | 98.9      | 97.5              | 84.3    | 86.3    |
| SUM156  | 82.8        | 67.0              | 61.3              | 85.7            | 86.1  | 84.5          | 97.8       | 97.6           | 97.6        | 86.2      | 92.4              | 85.0    | 85.3    |
| UVL124  | 99.2        | 96.1              | 97.6              | 99.3            | 98.6  | 99.2          | 99.2       | 99.2           | 99.2        | 99.8      | 99.2              | 98.6    | 98.8    |
| VIN140  | 98.2        | 97.8              | 98.1              | 98.3            | 97.3  | 93.4          | 97.5       | 97.5           | 97.5        | 99.6      | 96.9              | 97.0    | 97.4    |
| VPI120  | 91.0        | 91.0              | 98.7              | 99.0            | 95.3  | 96.6          | 98.7       | 98.7           | 98.7        | 99.6      | 96.4              | 96.4    | 96.7    |
| WEL149  | 97.8        | 97.5              | 97.6              | 73.4            | 96.8  | 97.5          | 97.7       | 97.7           | 97.4        | 58.1      | 97.3              | 97.3    | 92.2    |
| WSP144  | 97.8        | 97.8              | 99.1              | 99.3            | 98.1  | 99.2          | 99.1       | 99.1           | 99.1        | 99.4      | 99.1              | 97.0    | 98.7    |
| WST109  | 99.4        | 99.3              | 99.4              | 99.7            | 98.5  | 99.2          | 74.6       | 74.6           | 74.6        | 99.0      | 84.2              | 99.1    | 91.8    |
| AVERAGE | 96.5        | 91.4              | 93.6              | 95.9            | 92.5  | 97.1          | 93.2       | 93.2           | 93.2        | 98.1      | 95.6              | 94.1    | 94.5    |

Table 6-16. Percent Data Completeness for Filter Concentrations for 1998 (page 1 of 2)

| Site ID | Teflon $\text{SO}_4^{2-}$ | Teflon $\text{NO}_3^-$ | Teflon $\text{NH}_4^+$ | Nylon $\text{HNO}_3$ | Nylon $\text{SO}_4^{2-}$ | Whatman $\text{NO}_3^-$ | Whatman $\text{SO}_2$ |
|---------|---------------------------|------------------------|------------------------|----------------------|--------------------------|-------------------------|-----------------------|
| ABT147  | 96.2                      | 96.2                   | 96.2                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| ACA416  | 92.3                      | 92.3                   | 92.3                   | 92.3                 | 92.3                     | 92.3                    | 92.3                  |
| ALH157  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| ANA115  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| ARE128  | 94.2                      | 94.2                   | 96.2                   | 96.2                 | 96.2                     | 96.2                    | 96.2                  |
| ASH135  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| ASH235  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| BBE401  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| BEL116  | 92.3                      | 92.3                   | 92.3                   | 92.3                 | 92.3                     | 92.3                    | 92.3                  |
| BFT142  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| BVL130  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 100.0                   | 100.0                 |
| BWR139  | 98.1                      | 98.1                   | 98.1                   | 96.2                 | 96.2                     | 100.0                   | 100.0                 |
| CAD150  | 94.2                      | 94.2                   | 94.2                   | 94.2                 | 94.2                     | 94.2                    | 94.2                  |
| CAN407  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| CAT175  | 100.0                     | 100.0                  | 100.0                  | 98.1                 | 98.1                     | 100.0                   | 100.0                 |
| CDR119  | 96.2                      | 96.2                   | 96.2                   | 96.2                 | 96.2                     | 98.1                    | 98.1                  |
| CHA467  | 96.2                      | 96.2                   | 96.2                   | 96.2                 | 96.2                     | 96.2                    | 96.2                  |
| CKT136  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| CND125  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| CNT169  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| COW137  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 96.2                    | 96.2                  |
| CTH110  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| CVL151  | 96.2                      | 96.2                   | 96.2                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| DCP114  | 96.2                      | 96.2                   | 96.2                   | 96.2                 | 96.2                     | 98.1                    | 98.1                  |
| DEN417  | 100.0                     | 100.0                  | 100.0                  | 98.1                 | 98.1                     | 100.0                   | 100.0                 |
| DEV412  | 96.2                      | 96.2                   | 96.2                   | 96.2                 | 96.2                     | 96.2                    | 96.2                  |
| EGB181  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| ESP127  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| EVE419  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| GAS153  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| GLR468  | 94.2                      | 94.2                   | 94.2                   | 94.2                 | 94.2                     | 94.2                    | 94.2                  |
| GRB411  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| GRC474  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| GRS420  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| GTH161  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| HOW132  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| JOT403  | 94.2                      | 94.2                   | 94.2                   | 96.2                 | 96.2                     | 96.2                    | 96.2                  |
| KEF112  | 96.2                      | 96.2                   | 96.2                   | 96.2                 | 96.2                     | 96.2                    | 96.2                  |
| LAV410  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| LRL117  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| LYE145  | 94.2                      | 94.2                   | 94.2                   | 94.2                 | 94.2                     | 96.2                    | 96.2                  |
| LYK123  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| MCK131  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 96.2                    | 96.2                  |
| MCK231  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| MEV405  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| MKG113  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 100.0                   | 100.0                 |
| MOR409  | 92.3                      | 92.3                   | 92.3                   | 90.4                 | 90.4                     | 96.2                    | 96.2                  |

Table 6-16. Percent Data Completeness for Filter Concentrations for 1998 (page 2 of 2)

| Site ID | Teflon $\text{SO}_4^{2-}$ | Teflon $\text{NO}_3^-$ | Teflon $\text{NH}_4^+$ | Nylon $\text{HNO}_3$ | Nylon $\text{SO}_4^{2-}$ | Whatman $\text{NO}_3^-$ | Whatman $\text{SO}_2$ |
|---------|---------------------------|------------------------|------------------------|----------------------|--------------------------|-------------------------|-----------------------|
| NCS415  | 96.2                      | 96.2                   | 96.2                   | 96.2                 | 96.2                     | 98.1                    | 98.1                  |
| OLY421  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 100.0                   | 100.0                 |
| OXF122  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| PAR107  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 100.0                   | 100.0                 |
| PED108  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| PIN414  | 90.4                      | 90.4                   | 90.4                   | 90.4                 | 90.4                     | 90.4                    | 90.4                  |
| PND165  | 94.2                      | 94.2                   | 94.2                   | 94.2                 | 94.2                     | 94.2                    | 94.2                  |
| PNF126  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| PRK134  | 98.1                      | 98.1                   | 96.2                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| PSU106  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| ROM406  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| SAL133  | 96.2                      | 96.2                   | 96.2                   | 96.2                 | 96.2                     | 100.0                   | 100.0                 |
| SEK402  | 71.2                      | 71.2                   | 71.2                   | 71.2                 | 71.2                     | 71.2                    | 71.2                  |
| SHN418  | 96.2                      | 96.2                   | 96.2                   | 96.2                 | 96.2                     | 98.1                    | 98.1                  |
| SND152  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 100.0                   | 100.0                 |
| SPD111  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| STK138  | 96.2                      | 96.2                   | 96.2                   | 96.2                 | 96.2                     | 98.1                    | 98.1                  |
| SUM156  | 96.2                      | 96.2                   | 96.2                   | 96.2                 | 96.2                     | 96.2                    | 96.2                  |
| THR422  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| UVL124  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 100.0                   | 100.0                 |
| VII423  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| VIN140  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| VOY413  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 100.0                   | 100.0                 |
| VPI120  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 100.0                   | 100.0                 |
| WEL149  | 98.1                      | 98.1                   | 98.1                   | 96.2                 | 96.2                     | 98.1                    | 98.1                  |
| WSP144  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| WST109  | 100.0                     | 100.0                  | 100.0                  | 100.0                | 100.0                    | 100.0                   | 100.0                 |
| YEL408  | 98.1                      | 98.1                   | 98.1                   | 98.1                 | 98.1                     | 98.1                    | 98.1                  |
| YOS404  | 94.2                      | 94.2                   | 94.2                   | 94.2                 | 94.2                     | 94.2                    | 94.2                  |

Table 6-17. Percent Data Completeness for Precipitation Chemistry for 1998

| Site ID | pH    | Mg    | Na    | NH <sub>4</sub> <sup>+</sup> | NO <sub>3</sub> <sup>-</sup> | SO <sub>4</sub> <sup>2-</sup> |
|---------|-------|-------|-------|------------------------------|------------------------------|-------------------------------|
| ABT147  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| ALH157  | 97.6  | 97.6  | 97.6  | 97.6                         | 97.6                         | 97.6                          |
| ALH257  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| ANA115  | 97.6  | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| ARE128  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| BFT142  | 93.0  | 93.0  | 93.0  | 93.0                         | 93.0                         | 93.0                          |
| CDR119  | 93.5  | 93.5  | 93.5  | 93.5                         | 93.5                         | 93.5                          |
| CHA467  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| CND125  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| DCP114  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| GTH161  | 93.6  | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| LYE145  | 86.4  | 86.4  | 86.4  | 86.4                         | 86.4                         | 86.4                          |
| LYK123  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| PED108  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| PNF126  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| PRK134  | 97.1  | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| SCR180  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| SPD111  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |
| SUM156  | 97.1  | 97.1  | 97.1  | 97.1                         | 97.1                         | 97.1                          |
| UVL124  | 100.0 | 100.0 | 100.0 | 100.0                        | 100.0                        | 100.0                         |

Table 6-18. Data Completeness for Aerosol Samples

|   | Number of<br>Possible Samples | Number of<br>Valid Samples | Percent<br>Completeness |
|---|-------------------------------|----------------------------|-------------------------|
| <b>First Quarter 1998</b>   |                               |                            |                         |
| Nylon   | 127                           | 120                        | 94.5                    |
| Teflo®  | 127                           | 119                        | 93.7                    |
| Quartz  | 127                           | 119                        | 93.7                    |
| Combined*   | 127                           | 118                        | 92.9                    |
| <b>Second Quarter 1998</b>  |                               |                            |                         |
| Nylon   | 128                           | 125                        | 97.7                    |
| Teflo®  | 128                           | 125                        | 97.7                    |
| Quartz  | 128                           | 125                        | 97.7                    |
| Combined*   | 128                           | 121                        | 94.6                    |
| <b>Third Quarter 1998</b>   |                               |                            |                         |
| Nylon   | 127                           | 123                        | 96.9                    |
| Teflo®  | 127                           | 121                        | 95.3                    |
| Quartz  | 127                           | 122                        | 96.1                    |
| Combined*   | 127                           | 121                        | 95.3                    |
| <b>Fourth Quarter 1998</b>  |                               |                            |                         |
| Nylon   | 137                           | 109†                       | 79.6                    |
| Teflo®  | 137                           | 133                        | 97.1                    |
| Quartz  | 137                           | 133                        | 97.1                    |
| Combined*   | 137                           | --                         | --                      |
| <b>Cumulative for 1998</b>  |                               |                            |                         |
| Nylon   | 519                           | 477                        | 95.0                    |
| Teflo®  | 519                           | 498                        | 96.0                    |
| Quartz  | 519                           | 499                        | 96.2                    |
| Combined*   | 519                           | --                         | --                      |
| <b>Note:</b>  |                               |                            |                         |
| * All 3 valid filters.  |                               |                            |                         |
| † All nylon filter data for SIK570/SIK270 are considered invalid. |                               |                            |                         |