



---


# **Achieving Energy Efficient Laboratory Buildings**

***Reducing the flow through the  
fume hood system***

## **Case Study: Chemistry Building Renovation**

- 250 Hoods: 8'
- Traditional Sizing: 400,000 CFM
- Goal: Provide only 160,000 CFM  
(Avoids adding new AHU system &  
offers \$700,000/Year energy savings)





- ### Reducing Fume Hood Flow
- Restrictions**
- Sash Stops
  - Horizontals
  - Operate at reduced FV
  - Smaller hoods

---

## Reducing Fume Hood Flow

### Restrictions

- Sash Stops
- Horizontals
- Operate at reduced FV
- Smaller hoods

### Control flow based on use patterns

- Vary flow with sash position
- Let hood occupancy control FV

## Reducing Fume Hood Flow


### Restrictions

- Sash Stops
- Horizontals
- Operate at reduced FV
- Smaller hoods

### Control flow based on use patterns

- Vary flow with sash position
- Let hood occupancy control FV

## Restrictions



**Restrict hood  
flow to 18 Sash:**

**1050 cfm vs. 1600 cfm**

**Add horizontal  
sashes**


**Containment???**

**Low FV when sash  
stop is overridden**

**Saves: \$1650/year/hd**

**Needs: 265,000CFM**

## Restrictions



**Restrict hood  
flow to 60 fpm:**

**960 cfm vs. 1600 cfm**


**Containment ???**

**Dynamic conditions**

**Saves: \$1900/year/hd**

**Needs 240,000 CFM**

## Restrictions



**Restrict hood  
flow to 18 fpm,  
use 60 fpm, 7 hood**

**630 cfm vs. 1600 cfm**

**Saves: \$2900/year**

**Needs 160,000 CFM**

**Sash stops/override**

**Containment risk?**

**Smaller hoods**

## Reducing Fume Hood Flow


### Restrictions

- Sash Stops
- Horizontals
- Operate at reduced FV
- Smaller hoods


### Control flow based on use patterns

- Vary flow with sash position
- Let hood occupancy control FV


## Hood Usage Control




## Hood Usage Control



## Hood Usage Control



## Usage Patterns





---

## Reducing Fume Hood Flow

### Restrictions

- Forces Reduction

- Saves \$725,000/yr



### Control flow based on use patterns

- Innovative Reduction without restrictions

- Saves \$810,000/yr


## Factors that Affect Fume Hood System Sizing

- Quantity of Hoods (250)
- Flow Set Points (100 FPM or 60 FPM?)
- Usage Patterns
  - When?
  - How long?
  - Sash management habits?
- Manifold size




# Hood Occupancy Stats

Percentage of Fume Hoods with Users Present (maximum)  
(10% presence probability)



## Software<sup>3</sup>



---

## Case Study: University of Richmond

- Chemistry Building with 40 fume hoods using 56,000 CFM
- Needed 60 hoods
- They chose Usage Based Technology
  - Added 20 new hoods (from 40 to 60) without adding mechanical equipment
  - Yet the building operates at 28,000 CFM!
  - Cured existing problems, saves energy (\$80K+/year), and reduced maintenance

## Boehringer Ingelheim Ridgefield, CT

- Local utility provided a \$159,700 rebate for installing a VAV/UBC approach
- Annual Energy Savings: \$160,000
- Received FAME award energy efficient design (Facilities Management Award of Excellence)

---

## Bristol Myers, Evansville

- 57 Hood Retrofit
- 30% ROI
- Annual Energy Savings: \$180,000
- SIGECO Incentive \$250,000 for Usage Based Technology

## Sources

1. Containment Testing for occupied and Unoccupied Laboratory Chemical Hoods - ASHRAE Paper CH-99-9-1. January 1999
2. Phoenix Controls Field Study, 114 hoods @ 35 different sites, October 1993 - July 1994
3. LabPro™
4. Energy calculations based on \$3/CFM/year

---

# **Achieving Energy Efficient Laboratory Buildings**

***Control Flows Based on Usage  
Patterns***

***[www.phoenixcontrols.com](http://www.phoenixcontrols.com)***