

Implementation of Amalgam Separators at Navy Dental Clinics

Mark Stone

Naval Institute for Dental and Biomedical Research

Outline

- Are separators effective in decreasing Hg levels in WWTP influent?
- US Navy's implementation of amalgam separators
- **USEPA's** National Waste Minimization Partnership Program
- GLNPO funded dental Hg working group



Do Separators Work?

- Toronto – 5th largest city in North America and has over 1,100 dental practices
- Sewer use by-law – July 6th 2000
- Requires P2 plan and separator installation by January 1st, 2002
- Discharge limit of 0.01 mg/liter as originally passed
- P2 plan: type of vacuum system type of separator, frequency of maintenance & service, plumbing schematics, SOPs for waste generation, storage, handling, disposal of scrap amalgam

Do Separators Work?

- Since Installation of separators in Toronto there has been 58% reduction in Hg levels in WWTP biosolids (sludge)
- Total mass of Hg in combined sludge reduced from 17 kg to 7 kg per month
- Data obtained when compliance with Toronto sewer by-law estimated to be 800 of 1100 dental clinics (~73%)

Do Separators Work?

- MCES is POTW of Minneapolis/St. Paul, Minnesota
- Study done in Hastings and Cottage Grove
- 24 of 25 dentists in these communities participated in study
- Separators in place for 3 month
- 44% and 29% reductions in Hg levels in WWTP biosolids

Do Separators Work?

- NSSD in Gurnee, IL required Naval Base Great Lakes to install separators
- 20% of WWTP influent comes from base
- Base has end of pipe Hg discharge limit of 0.5 $\mu\text{g}/\text{liter}$, soon to be lowered to 0.1 $\mu\text{g}/\text{liter}$
- History of Hg exceedances from base
- Dental clinics on base use 60,750 double spill amalgam capsules per year (~60 lbs of Hg)

Do Separators Work?

- First pretreatment system was installed in largest clinic in 1996
- Since then all dental clinics have systems installed
- 52% decrease in Hg levels in sludge biosolids since separators installed
- Yearly NOV's have decreased from 54 to 3

Do Separators Work?

- Duluth Minnesota active since 1993
- 50 dental practices with ~100 dentists
- Separators installed on a voluntary basis
- Hg in biosolids decreased from 2.5 mg/kg to 0.19 mg/Kg
- WWTP Hg influent has decreased from 0.18 lbs/day in 1993 to <0.02 lbs/day today
- Hg in WWTP effluent decreased from 20.6 ng/liter to 1.9 ng/liter

Do Separators Work?

- Denmark country twice the size of Massachusetts and active in environmental issues for many years
- Dr. Arenholt-Bindslev wrote one of first papers looking at environment aspects of amalgam
- Survey showed 73% of Danish counties have separators in all dental offices
- Half of WWTPs surveyed showed a significant decrease in sludge Hg levels – 14-to-80%

Do Separators Work?

- AMSA – Association of Metropolitan Sewage Agencies – is currently looking at separator efficacy
- Multi-site effort tracking Hg levels in WWTP influent, effluent as well as in biosolids
- Ongoing study still in data collection phase
- Should help to provide additional evidence for or against separator efficacy

U.S. Navy Implementation of Separators

- Navy has over 170 dental clinics with over 2500 chairs *(not counting ship board DTFs)*
- Clinics range in size from 120 chairs to single chair clinics
- Navy program to install separators arose out of problems at NDC Norfolk in Virginia
- Navy program to install amalgam separators in Navy dental facilities at home, overseas and on ships

U.S. Navy Implementation of Separators

- NIDBR has conducted performance studies on commercially available separators
- Designed, built and installed our own systems (*Institute holds 2 patents*)
- Currently installing systems that remove both amalgam particulate as well as dissolved Hg species – *2 phase pretreatment approach*
- Our studies have shown dissolved Hg can be present in substantial concentrations

U.S. Navy Implementation of Separators

- We have seen dissolved Hg levels in dental-unit wastewater as high as 8000 $\mu\text{g/liter}$
- In large clinics, install SolmeteX Hg10 & Hg20 and ADA Technologies MRU30 and MRU400
- In smaller clinics we install ADA Technologies MRU10
- These systems use filtration and/or settling, oxidation and Hg^{+2} specific resins and sorbents

U.S. Navy Implementation of Separators

ADA Technologies, Inc. Pretreatment Systems

Model Number	Clinic Size	Dimensions of Units	Description of System
BU10	6	8.5"x22"	Particle separator
MRU10c	6	16"x12"x24"	Particles and Dissolved Hg
BU30	12	13"x25"	Particle separator
MRU30	12	13"x25" and 24"x12"x24"	Particles and Dissolved Hg
Custom	100	24"x36"x78" and 21" tank	Particles w/ or w/o dissolved Hg removal
Custom	200	37"x48"x79" and 26" tank	Particles w/ or w/o dissolved Hg removal

U.S. Navy Implementation of Separators



*SolmeteX
Hg20*



*ADA Technologies
MRU 10*

U.S. Navy Implementation of Separators



*ADA Technologies
BU10*



*ADA Technologies
MRU 190E*

U.S. Navy Implementation of Separators



*ADA Technologies MRU 750s
Installed at the Dental
School in San Antonio,
Texas. The school has 400
dental chairs.*

U.S. Navy Implementation of Separators

Clinical evaluation of MRU10c

- ◆ Mean Baseline Hg concentration 15,400 $\mu\text{g/liter}$
- ◆ Treated wastewater Hg concentration was 8.95 $\mu\text{g/liter}$ (n=45, SD=12.7)
- ◆ 99.94% removal efficiency based on concentration

USEPA Waste Minimization Partnership Program



**National
Waste
Minimization
Partnership
Program**

USEPA Waste Minimization Partnership Program

- Effort to form voluntary partnerships to reduce generation of hazardous wastes containing any of 30 **Waste Minimization Priority Chemicals (WMPCs)**
- Goal is to reduce the quantity of WMPCs found in hazardous waste by 50 percent by 2005 (*from 1991 baseline*)
- Encourages manufacturers to reduce **WMPCs** through source reduction and, where source reduction is not practical, through environmentally sound recycling







USEPA Waste Minimization Partnership Program

- Dow Chemical Company, Texas
- Toyota Motor Manufacturing, Indiana
- American Video Glass Company
- BP Products North America, Inc.
- U.S. Steel Corporation: Mon Valley Works, PA
- Uniseal, Incorporated - Foam Division
- Department of Army: Tobyhanna Army Depot, PA
- Hewlett Packard: Aguadilla, PR
- General Electric Consumer Products
- E.I. du Pont de Nemours and Company
- International Truck and Engine Corporation



USEPA Waste Minimization Partnership Program

- US Navy – NIDBR has started the enrollment process for this program
- Focusing on dental mercury and installation of separators in Navy dental treatment facilities
- EPA Region 5 POC is **Janet Haff**
 -  haff.janet@epa.gov
 -  (312) 353-7923
- US EPA point of contact is **Newman Smith**
 -  smith.newman@epa.gov
 -  USEPA Office of Solid Waste

GLNPO Dental Mercury Working Group

- Delta Institute, University of Wisconsin - Extension Solid and Hazardous Waste Education Center, Erie County Department of Environment and Planning (*Buffalo NY*) , US Navy (*NIDBR*)
- Developing DVD and streaming video to demonstrate BMPs for dental offices
- Out reach to state and local dental societies
 - *Ohio Dental Society*
 - *Wisconsin Dental Association*