

Perchlorate Treatment by Enhanced Coagulation, Oxidation, and Membranes

**Sun Liang, Ph.D., Karen Scott,
Leslie Palencia, and Jeanne-Marie Bruno**
The Metropolitan Water District of Southern California

Objectives

- Investigate enhanced coagulation for ClO_4^- removal
- Investigate ClO_4^- removal in ozone/PEROXONE/GAC systems
- Evaluate the effectiveness of membranes for ClO_4^- reduction



Enhanced Coagulation Study Objectives

- **Investigate the feasibility of enhanced coagulation for ClO_4^- removal**
- **Evaluate the effects of pH on enhanced coagulation for ClO_4^- removal**



Experimental Design for Enhanced Coagulation

- **Conventional treatment processes**
- **Chemical Dosages**
 - **40 mg/L of Alum, 3 mg/L of polymer, 0.01 mg/L of filter aid**
 - **25 mg/L of FeCl_3 , 3 mg/L of polymer**
- **pHs at ambient and 6.5**



Results from Enhanced Coagulation

Coagulant/ Dose (mg/L)	Filter Aid (mg/L)	Site	pH (unit)	ClO ₄ ⁻ (μg/L)
FeCl ₃ /25	0	PI	8.28	6
		FE	7.24	7
FeCl ₃ /25	0	PI	8.27	7
		FE	7.05	6
Alum/40	0.01	PI	8.26	7
		FE	7.33	6
Alum/40	0.01	PI	8.21	7
		FE	6.65	7

All tests with 3 mg/L of polyDADMAC polymer



Oxidation Study Objectives


- **Determine optimum applied ozone and/or hydrogen peroxide doses for ClO_4^- removal**
- **Identify the effects of various ClO_4^- levels on ClO_4^- removal**
- **Evaluate oxidation followed by GAC adsorption for ClO_4^- removal**




Experimental Design for Oxidation

- Pilot plant flow of 3 gpm CRW through ozone contactor columns
- Applied ozone doses of 2, 3, and 4 mg/L without H_2O_2 and at 1:0.5 and 1:1 $\text{O}_3:\text{H}_2\text{O}_2$ ratios
- Spiked ClO_4^- at 10, 20, and 90 $\mu\text{g/L}$
- Tested ClO_4^- removal at ambient, 6.5, and 9.3 pH








**Perchlorate
Oxidation at Various pHs (Dose = 90 μ g/L ClO₄)**

Experimental Design for Oxidation/GAC

- **Ozone contactor effluent treated in GAC mini column (82 mL/min)**
- **2 conditions @ 90 mg/L ClO_4^- dose**
 - 2 mg/L Ozone**
 - 3 mg/L Ozone: 1.5 mg/L H_2O_2**



Perchlorate Removal in Pilot Plant (~25% SPW)



Membrane Study Objectives

- Compare ClO_4^- removal using nanofiltration (NF) and reverse osmosis (RO) membranes
- Evaluate the effect of ClO_4^- feed concentration on ClO_4^- rejection rates
- Evaluate the effect of recycling the retentate



Experimental Design for Membranes

- **Spiral Wound Membranes**
 - Film Tech N70 4040-B (NF)
 - Fluid Systems TFC 4820-ULPT (RO)
- **Post treatment**
- **Spiked ClO_4^- Dosages:**
 - Low: 20-50 $\mu\text{g/L}$
 - Medium: 500-800 $\mu\text{g/L}$
 - High: 1,000-2,000 $\mu\text{g/L}$



Experimental Design (Cont'd)

- **Brine recycle at 50% of influent flow**
- **Test duration 3 hours**
- **Sampled 2nd and 3rd hour at influent, influent with recycle, permeate, and brine**
- **Measured ClO_4^- , total organic carbon (TOC), conductivity, UV_{254} absorbing organics, turbidity, and particle counts**




Membrane Characteristics

Type	MWCO	Surface Charge	Composition	Surface area (ft ²)	Flux (GFD)	Recovery (%)
NF	300 Da	Negative Charge	Thin Film Composite	82	15	20
RO	-----	Negative Charge	Thin Film Composite	72	15	20

MWCO - molecular weight cutoff



Schematic of Membrane Bench Testing Unit



Membrane Influent Water Quality

Source Water	CRW
Total Organic Carbon	2.40 - 3.05 mg/L
UVA₂₅₄	0.024 - 0.032 abs/cm
Conductivity	969 - 1030 μmhos/cm
Temperature	20.4 - 21.5 °C
pH	8.09 - 8.24
Turbidity	0.12 - 0.78 NTU
Particle Count	113 - 1590 /mL




Specific Flux for Membranes

Membrane	Average Pressure (psi)	Average Permeate (gpm)	Average Flux (GFD)	Specific Flux (GFD/psi)
NF	87	0.86	15	0.17
RO	106	0.76	15	0.14




Perchlorate Removal



Permeate Characteristics

■ Nanofiltration (w/o Recycle) ■ Nanofiltration (w/Recycle)
■ Reverse Osmosis (w/o Recycle) ■ Reverse Osmosis (w/Recycle)



Brine Characteristics

- Perchlorate, TOC, conductivity, UV_{254} absorbing organics were concentrated in the brine
- Membrane systems concentrated ClO_4^- in brine by approximately 20-50 percent



Membrane Study Results

- NF and RO membranes can effectively remove ClO_4^- from CRW
- NF and RO performed equally well for ClO_4^- removal at low levels of ClO_4^- and lowered ClO_4^- concentration below 4 $\mu\text{g/L}$ in permeate
- RO performed better than NF for ClO_4^- removal at medium and high levels of perchlorate



Membrane Study Results (Cont'd)

- **Brine recycle did not significantly affect ClO_4^- percent rejection, but produced higher ClO_4^- levels in permeate**
- **Conductivity increased in permeate when brine recycled**
- **Brine disposal/treatment is required**



Conclusions

- Enhanced coagulation does not appear promising in the treatment of ClO_4^- in CRW
- Oxidation does not appear promising in treating low levels of ClO_4^- (10-20 $\mu\text{g/L}$); at higher levels (90 $\mu\text{g/L}$), some ClO_4^- removal may be expected, however results are mixed



Conclusions (Cont'd)

- **Oxidation followed by GAC did not reduce ClO_4^- levels**
- **NF and RO membranes consistently removed greater than 80 percent of the applied ClO_4^-**

