



UNITED STATES ENVIRONMENTAL PROTECTION AGENCY

NATIONAL EXPOSURE RESEARCH LABORATORY

HUMAN EXPOSURE & ATMOSPHERIC SCIENCES DIVISION (MD-46)

Research Triangle Park, NC 27711

919-541-2622

Office of
Research and Development

LIST OF DESIGNATED REFERENCE AND EQUIVALENT METHODS

Issue Date: March 24, 2000

(www.epa.gov/ttn/amtic/criteria.html)

These methods for measuring ambient concentrations of specified air pollutants have been designated as "reference methods" or "equivalent methods" in accordance with Title 40, Part 53 of the Code of Federal Regulations (40 CFR Part 53). Subject to any limitations (e.g., operating range or temperature range) specified in the applicable designation, each method is acceptable for use in state or local air quality surveillance systems under 40 CFR Part 58 unless the applicable designation is subsequently canceled. Automated methods for pollutants other than PM_{10} are acceptable for use only at shelter temperatures between 20EC and 30EC and line voltages between 105 and 125 volts unless wider limits are specified in the method description.

Prospective users of the methods listed should note (1) that each method must be used in strict accordance with its associated operation or instruction manual and with applicable quality assurance procedures, and (2) that modification of a method by its vendor or user may cause the pertinent designation to be inapplicable to the method as modified. (See Section 2.8 of Appendix C, 40 CFR Part 58 for approval of modifications to any of these methods by users.)

Further information concerning particular designations may be found in the *Federal Register* notice cited for each method or by writing to the National Exposure Research Laboratory, Human Exposure and Atmospheric Sciences Division (MD-46), U.S. Environmental Protection Agency, Research Triangle Park, North Carolina 27711. Technical information concerning the methods should be obtained by contacting the source listed for each method. Source addresses are listed at the end of the listing of methods, except for the addresses for lead method sources, which are given with the method. New analyzers or PM_{10} samplers sold as reference or equivalent methods must carry a label or sticker identifying them as designated methods. For analyzers or PM_{10} samplers sold prior to the designation of a method with the same or similar model number, the model number does not necessarily identify an analyzer or sampler as a designated method. Consult the manufacturer or seller to determine if a previously sold analyzer or sampler can be considered a designated method or if it can be upgraded to designation status. Analyzer users who experience operational or other difficulties with a designated analyzer or sampler and are unable to resolve the problem directly with the instrument manufacturer may contact EPA (preferably in writing) at the above address for assistance.

This list will be revised as necessary to reflect any new designations or any cancellation of a designation currently in effect. The most current revision of the list will be available for inspection at EPA's Regional Offices, and copies may be obtained by writing to the National Exposure Research Laboratory at the address specified above.

Most Recent Designations

DKK Corp. Model GUX-113E U. V. Ozone Analyzer	March 2, 2000
DKK Corp. Model GFS-112E U.V. Fluorescence SO_2 Analyzer	January 18, 2000
Andersen RAAS10-100, RAAS10-200, RAAS10-300 PM_{10} Samplers	June 23, 1999
Rupprecht & Patashnick Partisol® Model 2000 $PM_{2.5}$ Audit Sampler	April 19, 1999
Andersen Model RAAS2.5-200 $PM_{2.5}$ Audit Air Sampler	March 11, 1999

PARTICULATE MATTER - TSP

Reference Method for TSP

Manual Reference Method: **40 CFR Part 50, Appendix B**

Reference Method for the Determination of Suspended Particulate Matter in the Atmosphere (High-Volume Method)

[Federal Register: Vol 47, page 54912, 12/06/82 and Vol 48, page 17355, 04/22/83]

PARTICULATE MATTER - PM₁₀

Andersen Model RAAS10-100 PM₁₀ Single Channel PM₁₀ Sampler

Manual Reference Method: **RFPS-0699-130**

"Andersen Instruments, Incorporated Model RAAS10-100 Single Channel Reference Method PM₁₀ Sampler," with RAAS-10 PM₁₀ inlet, configured as a PM₁₀ reference method, and operated for 24-hour continuous sample periods at a flow rate of 16.67 liters/ minute, and in accordance with the Model RAAS105-100 Operator's Manual and with the requirements and sample collection filters specified in 40 CFR Part 50, Appendix J or Appendix M.

[Federal Register: Vol 64, page 33481, 06/23/99]

Andersen Model RAAS10-200 PM₁₀ Single Channel PM₁₀ Audit Sampler

Manual Reference Method: **RFPS-0699-131**

"Andersen Instruments, Incorporated Model RAAS10-200 Single Channel Reference Method PM₁₀ Audit Sampler," with RAAS-10 PM₁₀ inlet, configured as a PM₁₀ reference method, and operated for 24-hour continuous sample periods at a flow rate of 16.67 liters/minute, and in accordance with the Model RAAS105-200 Operator's Manual and with the requirements and sample collection filters specified in 40 CFR Part 50, Appendix J or Appendix M.

[Federal Register: Vol 64, page 33481, 06/23/99]

Andersen Model RAAS10-300 PM₁₀ Multi Channel PM₁₀ Sampler

Manual Reference Method: **RFPS-0699-132**

"Andersen Instruments, Incorporated Model RAAS10-300 Multi Channel Sequential Reference Method PM₁₀ Sampler," with RAAS-10 PM₁₀ inlet, configured as a PM₁₀ reference method, and operated for 24-hour continuous sample periods at a flow rate of 16.67 liters/ minute, and in accordance with the Model RAAS105-300 Operator's Manual and with the requirements and sample collection filters specified in 40 CFR Part 50, Appendix J or Appendix M.

[Federal Register: Vol 64, page 33481, 06/23/99]

BGI Incorporated Model PQ100 Air Sampler

Manual Reference Method: **RFPS-1298-124**

"BGI Incorporated Model PQ100 Air Sampler" with BGI 16.7 Inlet Kit or the louvered inlet specified in 40 CFR 50 Appendix L, Figs. L-2 thru L-19, configured as a PM₁₀ reference method, for 24-hour continuous sample periods at a flow rate of 16.7 liters/minute, operated in accordance with the Model PQ100 Instruction Manual and with the requirements specified in 40 CFR Part 50, Appendix J or Appendix M, using either the original or the newer PQ200-type filter cassettes, and with or without the optional Solar Panel Power Supply.

[Federal Register: Vol 63, page 69625, 12/17/98]

BGI Incorporated Model PQ200 Air Sampler

Manual Reference Method: **RFPS-1298-125**

"BGI Incorporated Model PQ200 Air Sampler" with "flat plate" PM₁₀ inlet or the louvered inlet specified in 40 CFR 50 Appendix L, Figs. L-2 thru L-19, configured as a PM₁₀ reference method, and operated for 24-hour continuous sample periods in accordance with the Model PQ200 Instruction Manual and with the requirements specified in 40 CFR Part 50, Appendix J or Appendix M, and with or without the optional Solar Panel Power Supply.

[Federal Register: Vol 63, page 69625, 12/17/98]

Graseby Andersen/GMW Model 1200 High-Volume Air Sampler

Manual Reference Method: **RFPS-1287-063**

Sierra-Andersen or General Metal Works Model 1200 PM₁₀ High-Volume Air Sampler System," consisting of a Sierra-Andersen or General Metal Works Model 1200 PM₁₀ Size-Selective Inlet and any of the high-volume air samplers identified as SAUV-10H, SAUV-11H, GMW-IP-10, GMW-IP-10-70, GMW-IP-10-801, or GMW-IP-10-8000, which include the following components: Anodized aluminum high-volume shelter with either acrylonitrile butadiene styrene plastic filter holder and motor/blower housing or stainless steel filter holder and phenolic plastic motor/blower housing; 0.6 hp motor/blower; pressure transducer flow recorder; either an electronic mass flow controller or a volumetric flow controller; either a digital timer/programmer, seven-day mechanical timer, six-day timer/programmer, or solid-state timer/programmer; elapsed time indicator; and filter cartridge.

[Federal Register: Vol 52, page 45684, 12/01/87 and Vol 53, page 1062, 01/15/88]

Graseby Andersen/GMW Model 321-B High-Volume Air Sampler*Manual Reference Method: RFPS-1287-064*

"Sierra-Andersen or General Metal Works Model 321-B PM₁₀ High-Volume Air Sampler System," consisting of a Sierra-Andersen or General Metal Works Model 321-B PM₁₀ Size-Selective Inlet and any of the high-volume air samplers identified as SAUV-10H, SAUV-11H, GMW-IP-10, GMW-IP-10-70, GMW-IP-10-801, or GMW-IP-10-8000, which include the following components: Anodized aluminum high-volume shelter with either acrylonitrile butadiene styrene plastic filter holder and motor/blower housing or stainless steel filter holder and phenolic plastic motor/blower housing; 0.6 hp motor/blower; pressure transducer flow recorder; either an electronic mass flow controller or a volumetric flow controller; either a digital timer/programmer, seven-day mechanical timer, six-day timer/programmer, or solid-state timer/programmer; elapsed time indicator; and filter cartridge.

[Federal Register: Vol 52, page 45684, 12/01/87 and Vol 53, page 1062, 01/15/88]

Graseby Andersen/GMW Model 321-C High-Volume Air Sampler*Manual Reference Method: RFPS-1287-065*

"Sierra-Andersen or General Metal Works Model 321-C PM₁₀ High-Volume Air Sampler System," consisting of a Sierra-Andersen General Metal Works Model 321-C PM₁₀ or Size-Selective Inlet and any of the high-volume air samplers identified as SAUV-10H, SAUV-11H, GMW-IP-10, GMW-IP-10-70, GMW-IP-10-801, or GMW-IP-10-8000, which include the following components: Anodized aluminum high-volume shelter with either acrylonitrile butadiene styrene plastic filter holder and motor/blower housing or stainless steel filter holder and phenolic plastic motor/blower housing; 0.6 hp motor/blower; pressure transducer flow recorder; either an electronic mass flow controller or a volumetric flow controller; either a digital timer/programmer, seven-day mechanical timer, six-day timer/programmer, or solid-state timer/programmer; elapsed time indicator; and filter cartridge.

[Federal Register: Vol 52, page 45684, 12/01/87 and Vol 53, page 1062, 01/15/88]

Graseby Andersen/GMW Models SA241 and SA241M Dichotomous Sampler*Manual Reference Method: RFPS-0789-073*

"Sierra-Andersen Models SA241 and SA241M or General Metal Works Models G241 and G241M PM₁₀ Dichotomous Samplers," consisting of the following components: Sampling Module with SA246b or G246b 10 Fm inlet, 2.5 Fm virtual impactor assembly, 37 mm coarse and fine particulate filter holders, and tripod mount; Control Module with diaphragm vacuum pump, pneumatic constant flow controller, total and coarse flow rotameters and vacuum gauges, pressure switch (optional), 24-hour flow/event recorder, digital timer/programmer or 7-day skip timer, and elapsed time indicator.

[Federal Register: Vol 54, page 31247, 07/27/89]

Graseby Andersen/GMW Model FH62I-N Beta Monitor*Automated Equivalent Method: EQPM-0990-076*

"Andersen Instruments Model FH62I-N PM₁₀ Beta Attenuation Monitor," consisting of the following components: FH101 Vacuum Pump Assembly; FH102 Accessory Kit; FH107 Roof Flange Kit; FH125 Zero and Span PM₁₀ Mass Foil Calibration Kit; FH62I Beta Attenuation 19-inch Control Module; SA246b PM₁₀ Inlet (16.7 liter/min); operated for 24-hour average measurements, with an observing time of 60 minutes, the calibration factor set to 2400, a glass fiber filter tape, an automatic filter advance after each 24-hour sample period, and with or without either of the following options: FH0P1 Indoor Cabinet; FH0P2 Outdoor Shelter Assembly.

[Federal Register: Vol 55, page 38387, 09/18/90]

Met One or Sibata Models BAM/GBAM 1020, BAM/GBAM 1020-1*Automated Equivalent Method: EQPM-0798-122*

"Met One Instruments or Sibata Scientific Technology Models BAM 1020, GBAM 1020, BAM 1020-1, and GBAM 1020-1 PM₁₀ Beta Attenuation Monitor," including the BX-802 sampling inlet, operated for 24-hour average measurements, with a filter change frequency of one hour, with glass fiber filter tape, and with or without any of the following options: BX-823, tube extension; BX-825, heater kit; BX-826, 230 Vac heater kit; BX-828, roof tripod; BX-902, exterior enclosure; BX-903, exterior enclosure with temperature control; BX-961, mass flow controller; BX-967, internal calibration device

[Federal Register: Vol 63, page 41253, 08/03/98]

Oregon DEQ Medium Volume PM₁₀ Sampler*Manual Reference Method: RFPS-0389-071*

"Oregon DEQ Medium Volume PM₁₀ Sampler." NOTE: This method is not now commercially available.

[Federal Register: Vol 54, page 12273, 03/24/89]

Rupprecht & Patashnick TEOM Series 1400/1400a PM₁₀ Monitors*Automated Equivalent Method: EQPM-1090-079*

"Rupprecht & Patashnick TEOM Series 1400 and Series 1400a PM-10 Monitors" (including serial number prefixes 1400, 140A, 140AA, 140AB, 140AT, and 140UP), consisting of the following components: TEOM Sensor Unit; TEOM Control Unit; Flow Splitter (3 liter/min sample flow); Teflon-Coated Glass Fiber Filter Cartridges; Rupprecht & Patashnick PM-10 Inlet (part number 57-00596), Sierra-Andersen Model 246b PM-10 Inlet (16.7 liter/min) or louvered inlet specified in 40 CFR 50 Appendix L, Figs. L-2 thru L-19; operated for 24-hour average measurements, with the total mass averaging time set at 300 seconds, the mass rate/mass concentration averaging time set at 300 seconds, the gate time set at 2 seconds, and with or without any of the following options: Tripod; Outdoor Enclosure; Automatic Cartridge Collection Unit (Series 1400a only); Flow Splitter Adapter (for 1 or 2 liter/min sample flow).

[Federal Register: Vol 55, page 43406, 10/29/90]

Rupprecht & Patashnick Partisol Model 2000 Air Sampler

Manual Reference Method: **RFPS-0694-098**

"Rupprecht & Patashnick Partisol Model 2000 Air Sampler," consisting of a Hub Unit and 0, 1, 2, or 3 Satellite Units, with each sampling station used for PM₁₀ measurements equipped with a Rupprecht & Patashnick PM-10 inlet and operated for continuous 24-hour periods using the Basic, Manual, Time, Analog Input, or Serial Input programming modes, and with or without any of the following options: PM_{2.5}-style filter cassette holder; louvered inlet specified in 40 CFR 50 Appendix L, Figs. L-2 thru L-19 in lieu of standard inlet; 57-002320 Stand for Hub or Satellite; 59-002542 Advanced EPROM; 10-001403 Large Pump (1/4 hp); 120 VAC. Hardware for Indoor Installation consists of: 51-002638-xxxx Temperature Sensor (Extended Length); 55-001289 Roof Flange (1 1/4"); 57-000604 Support Tripod for Inlet; 57-002526-0001 Sample Tube Extension (1 m); 57-002526-0002 Sample Tube Extension (2 m). Hardware for Outdoor Installation in Extreme Cold Environments consists of: 10-002645 Insulating Jacket for Hub Unit.

[Federal Register: Vol 59, page 35338, 07/11/94]

Rupprecht and Patashnick Co. Partisol®-FRM Model 2000 PM₁₀ Air Sampler

Manual Reference Method: **RFPS-1298-126**

"Rupprecht and Patashnick Company Partisol®-FRM Model 2000 PM₁₀ Air Sampler" with PM₁₀ inlet or louvered inlet specified in 40 CFR 50 Appendix L, Figs. L-2 thru L-19, configured as a PM₁₀ reference method, and operated for 24-hour continuous sample periods in accordance with the Model 2000 Instruction Manual and with the requirements specified in 40 CFR Part 50, Appendix J or Appendix M.

[Federal Register: Vol 63, page 69625, 12/17/98]

Rupprecht and Patashnick Partisol®-Plus Model 2025 PM₁₀ Seq. Air Sampler

Manual Reference Method: **RFPS-1298-127**

"Rupprecht and Patashnick Company Partisol®-Plus Model 2025 PM₁₀ Sequential Air Sampler" with PM₁₀ inlet or louvered inlet specified in 40 CFR 50 Appendix L, Figs. L-2 thru L-19, configured as a PM₁₀ reference method, and operated for 24-hour continuous sample periods in accordance with the Model 2025 Instruction Manual and with the requirements specified in 40 CFR Part 50, Appendix J or Appendix M.

[Federal Register: Vol 63, page 69625, 12/17/98]

Wedding & Associates' or Thermo Environmental Instruments Inc.

Manual Reference Method: **RFPS-1087-062**

Model 600 PM₁₀ High-Volume Sampler

"Wedding & Associates' or Thermo Environmental Instruments, Inc. Model 600 PM₁₀ Critical Flow High-Volume Sampler," consisting of the following W&A/TEII components: PM₁₀Inlet; Critical Flow Device; Anodized Aluminum Shelter; Blower Motor Assembly for 115, 220 or 240 VAC and 50/60 Hz; Mechanical Timer; Elapsed Time Indicator; and Filter Cartridge/Cassette, and with or without the following options: Digital Timer, 6 or 7 Day Timer, and 1 or 7 Day Pressure Recorder.

[Federal Register: Vol 52, page 37366, 10/06/87]

Wedding & Associates' or Thermo Environmental Instruments Inc.

Automated Equivalent Method: **EQPM-0391-081**

Model 650 PM₁₀ Beta Gauge

"Wedding & Associates' or Thermo Environmental Instruments, Inc. Model 650 PM₁₀ Beta Gauge Automated Particle Sampler," consisting of the following W&A/TEII components: Particle Sampling Module, PM₁₀ Inlet (18.9 liter/min), Inlet Tube and Support Ring, Vacuum Pump (115, 220 or 240 VAC and 50/60 Hz); and operated for 24-hour average measurements with glass fiber filter tape.

[Federal Register: Vol 56, page 9216, 03/05/91]

PARTICULATE MATTER - PM_{2.5}

Andersen Model RAAS2.5-200 PM_{2.5} Ambient Audit Air Sampler

Manual Reference Method: **RFPS-0299-128**

"Andersen Instruments, Incorporated Model RAAS2.5-200 PM_{2.5} Audit Sampler," configured as a PM_{2.5} reference method and operated with software (firmware) version 4B or 5.0.1, for 24-hour continuous sample periods at a flow rate of 16.67 liters/minute, and in accordance with the Model RAAS2.5-200 Operator's Manual and with the requirements and sample collection filters specified in 40 CFR Part 50, Appendix L.

[Federal Register: Vol 64, page 12167, 03/11/99]

BGI Inc. Models PQ200 and PQ200A PM_{2.5} Ambient Fine Particle Sampler

Manual Reference Method: **RFPS-0498-116**

"BGI Incorporated Models PQ200 and PQ200A PM_{2.5} Ambient Fine Particle Sampler," operated with firmware version 3.88 or 3.89R, for 24-hour continuous sample periods, in accordance with the Model PQ200/PQ200A Instruction Manual and with the requirements and sample collection filters specified in 40 CFR Part 50, Appendix L, and with or without the optional Solar Power Supply or the optional dual-filter cassette (P/N F-21/6) and associated lower impactor housing (P/N B2027), where the upper filter is used for PM_{2.5}. The Model PQ200A is described as a portable audit sampler and includes a set of three carrying cases.

[Federal Register: Vol 63, page 18911, 04/16/98]

Graseby Andersen Model RAAS2.5-100 PM_{2.5} Ambient Air Sampler

Manual Reference Method: **RFPS-0598-119**

"Graseby Andersen Model RAAS2.5-100 PM_{2.5} Ambient Air Sampler," operated with software version 4B or 5.0.1 configured for "Single 2.5" operation, for 24-hour continuous sample periods at a flow rate of 16.67 liters/minute, and in accordance with the Model RAAS2.5-100 Operator's Manual and with the requirements and sample collection filters specified in 40 CFR Part 50, Appendix L.

[Federal Register: Vol 63, page 31991, 06/11/98]

Graseby Andersen Model RAAS2.5-300 PM_{2.5} Sequential Ambient Air Sampler *Manual Reference Method: **RFPS-0598-120***
 "Graseby Andersen Model RAAS2.5-300 PM_{2.5} Sequential Ambient Air Sampler," operated with software version 4B or 5.0.1 configured for "Multi 2.5" operation, for 24-hour continuous sample periods at a flow rate of 16.67 liters/minute, and in accordance with the Model RAAS2.5-300 Operator's Manual and with the requirements and sample collection filters specified in 40 CFR Part 50, Appendix L. [Federal Register: Vol 63, page 31991, 06/11/98]

Rupprecht & Patashnick Partisol®-FRM Model 2000 Air Sampler *Manual Reference Method: **RFPS-0498-117***
 "Rupprecht & Patashnick Company, Incorporated Partisol®-FRM Model 2000 PM-2.5 Air Sampler," operated with software versions 1.102 - 1.202, with either R&P-specified machined or molded filter cassettes, with or without the optional insulating jacket for cold weather operation, for 24-hour continuous sample periods, in accordance with the Model 2000 Instruction Manual and with the requirements and sample collection filters specified in 40 CFR Part 50, Appendix L. [Federal Register: Vol 63, page 18911, 04/16/98]

Rupprecht & Patashnick Partisol® Model 2000 PM-2.5 Audit Sampler *Manual Reference Method: **RFPS-0499-129***
 "Rupprecht & Patashnick Company, Inc. Partisol® Model 2000 PM-2.5 Audit Sampler," configured as a PM_{2.5} reference method and operated with software (firmware) version 1.2 - 1.202, for 24-hour continuous sample periods at a flow rate of 16.67 liters/minute, in accordance with the Partisol® Model 2000 Operating Manual and with the requirements and sample collection filters specified in 40 CFR Part 50, Appendix L. [Federal Register: Vol 64, page 19153, 04/19/99]

Rupprecht & Patashnick Partisol®-Plus Model 2025 Sequential Air Sampler *Manual Reference Method: **RFPS-0498-118***
 "Rupprecht & Patashnick Company, Incorporated Partisol®-Plus Model 2025 PM-2.5 Sequential Air Sampler," operated with any software version 1.003 through 1.400, with either R&P-specified machined or molded filter cassettes, for 24-hour continuous sample periods, in accordance with the Model 2025 Instruction Manual and with the requirements and sample collection filters specified in 40 CFR Part 50, Appendix L. [Federal Register: Vol 63, page 18911, 04/16/98]

Thermo Environmental Instruments, Incorporated Model 605 "CAPS" Sampler *Manual Reference Method: **RFPS-1098-123***
 "Thermo Environmental Instruments, Incorporated Model 605 "CAPS" Computer Assisted Particle Sampler," configured as a PM_{2.5} reference method and operated with software version 1.02A, for 24-hour continuous sample periods, in accordance with the Model 605 Instruction Manual and with the requirements and sample collection filters specified in 40 CFR Part 50, Appendix L. [Federal Register: Vol 63, page 58036, 10/29/98]

SULFUR DIOXIDE

Reference Method for SO₂ (Pararosaniline Method) *Manual Reference Method: **40 CFR Part 50, Appendix A***
 Reference Method for the Determination of Sulfur Dioxide in the Atmosphere (Pararosaniline Method)
 [Federal Register: Vol 47, page 54899, 12/06/82 and Vol 48, 17355, 04/22/83]

Pararosaniline Method for SO₂ - Technicon I *Manual Equivalent Method: **EQS-0775-001***
 "Pararosaniline Method for the Determination of Sulfur Dioxide in the Atmosphere-Technicon I Automated Analysis System"
 [Federal Register: Vol 40, page 34024, 08/13/75]

Pararosaniline Method for SO₂ - Technicon II *Manual Equivalent Method: **EQS-0775-002***
 "Pararosaniline Method for the Determination of Sulfur Dioxide in the Atmosphere-Technicon II Automated Analysis System"
 [Federal Register: Vol 40, page 34024, 08/13/75]

Advanced Pollution Instrumentation, Inc. Model 100 SO₂ Analyzer *Automated Equivalent Method: **EQSA-0990-077***
 "Advanced Pollution Instrumentation, Inc. Model 100 Fluorescent SO₂ Analyzer," operated on the 0-0.1 ppm¹, the 0-0.2 ppm¹, the 0-0.5 ppm, or the 0-1.0 ppm range with a 5-micron TFE filter element installed in the rear-panel filter assembly, either a user- or vendor-supplied vacuum pump capable of providing 20 inches of mercury vacuum at 2.5 L/min, with or without any of the following options: Internal Zero/Span; Pump Pack; Rack Mount With Slides; RS-232 Interface; Status Output; TFE Zero/Span Valves; Zero Air Scrubber; Dual Range.² [Federal Register: Vol. 55, page 38149, 09/17/90]

Advanced Pollution Instrumentation, Inc. Models 100A and 100AS SO₂ Analyzer *Automated Equivalent Method: **EQSA-0495-100***
 "Advanced Pollution Instrumentation, Inc. Model 100A or 100AS Sulfur Dioxide Analyzer," operated on any full scale range between 0-50 ppb¹ and 0-1000 ppb, at any temperature in the range of 5 to 40 degrees C, with a 5-micron TFE filter element installed in the filter assembly, with either the vendor-supplied internal pump or a user- or vendor-supplied external vacuum pump capable of maintaining an absolute pressure of 35 cm (14 inches) of mercury (or less) at 1.0 standard liter per minute flow rate, with the following software settings: Dynamic zero: OFF or ON; Dynamic span: OFF; AutoCal: ON or OFF; Dual range: ON or OFF; Autorange: ON or OFF; Temp/pressure compensation: ON; dilution factor: 1.0; and with or without any of the following options:²
 Rack mount with chassis slides Rack mount without slides, ears only Fluorocarbon zero/span valves

Internal zero/span (IZS)	4-20 mA, isolated outputs	External pump
Status outputs	Rack mount for external pump with tray	RS-232 output
SO ₂ Permeation tube, uncertified, 0.4 ppm @ 0.7 L/min	SO ₂ Permeation tube, certified, 0.4 ppm @ 0.7 L/min	Combustion Filter
SO ₂ Permeation tube, uncertified, 0.8 ppm @ 0.7 L/min	SO ₂ Permeation tube, certified, 0.8 ppm @ 0.7 L/min	
[Federal Register: Vol. 60, page 17061, 04/04/95]		

ASARCO Model 500 SO₂ Monitor*Automated Equivalent Method: EQSA-0877-024*

"ASARCO Model 500 Sulfur Dioxide Monitor," operated on a 0-0.5 ppm range; or "ASARCO Model 600 Sulfur Dioxide Monitor," operated on a 0-1.0 ppm range. (Both models are identical except for the range.) NOTE: This method is not now commercially available.

[Federal Register: Vol 42, page 44264, 09/02/77 and Vol 44, page 67522, 11/26/79]

Beckman Model 953 Fluorescent Ambient SO₂ Analyzer*Automated Equivalent Method: EQSA-0678-029*

"Beckman Model 953 Fluorescent Ambient SO₂ Analyzer," operated on a range of either 0-0.5 or 0-1.0 ppm, with a time constant setting of 2, 2.5, or 3 minutes, a 5 to 10 micron membrane filter element installed in the rear-panel filter assembly, with or without any of the following options: Remote Operation Kit, Catalog No. 641984; Digital Panel Meter, Catalog No. 641710; Rack Mount Kit, Catalog No. 641709; Panel Mount Kit, Catalog No. 641708.

[Federal Register: Vol 43, page 35995, 08/14/78]

Bendix Model 8303 Sulfur Analyzer*Automated Equivalent Method: EQSA-1078-030*

"Bendix Model 8303 Sulfur Analyzer," operated on a range of either 0-0.5 or 0-1.0 ppm, with a Teflon filter installed on the sample inlet of the H₂S scrubber assembly.

[Federal Register: Vol 43, page 50733, 10/31/78]

Columbia Scientific Industries Model 5700 SO₂ Analyzer*Automated Equivalent Method: EQSA-0494-095*

"Columbia Scientific Industries Model 5700 Sulfur Dioxide Analyzer", operated with software version 1.0 on any full scale range between 0-250 ppb¹ and 0-1000 ppb, at any integration time setting from 20 to 99 seconds, at any temperature in the range of 15EC to 30EC, at any AC line voltage in the range of 105 to 130 volts, and with or without any of the following options:

964-0121 Alarm Relay Contacts	964-0125 Dual Current Outputs	964-0131 Rack Mount
964-0122 Input Solenoids	964-0126 Printer	964-0012 Single Headed Pump
964-0124 Dual Analog Voltage Outputs		

[Federal Register: Vol 59, page 18818, 04/20/94]

Dasibi Model 4108 U.V. Fluorescence SO₂ Analyzer*Automated Equivalent Method: EQSA-1086-061*

"Dasibi Model 4108 U.V. Fluorescence SO₂ Analyzer," operated with a range of 0-100 ppb¹, 0-200 ppb¹, 0-500 ppb, or 0-1000 ppb, with a Teflon-coated particulate filter and continuous hydrocarbon removal system, with or without any of the following options: Rack Mounting Brackets And Slides; RS-232-C Interface; Temperature Correction. [Federal Register: Vol 51, page 32244, 09/10/86]

DKK Corp. Model GFS-32 U.V. Fluorescent SO₂ Analyzer*Automated Equivalent Method: EQSA-0701-115*

"DKK Corporation Model GFS-32 Ambient Air SO₂ Ultraviolet Fluorescent Analyzer, operated within the 0.000 to 0.500 ppm range in the temperature range of 20EC to 30EC.

[Federal Register: Vol 62, page 44007, 08/18/97]

DKK Corp. Model GFS-112E U. V. Fluorescent SO₂ Analyzer*Automated Equivalent Method: EQSA-0100-133*

"DKK Corporation Model GFS-112E U.V. Fluorescence SO₂ Analyzer," operated at any temperature ranging from 15° C to 35° C and on any of the following measurement ranges: 0-0.05 ppm, 0-0.100 ppm, 0-0.200 ppm, 0-0.5 ppm, or 0-1.000 ppm.

[Federal Register: Vol 65, page 2610, 01/18/00]

Environnement S.A. Model AF21M SO₂ Analyzer*Automated Equivalent Method: EQSA-0292-084*

"Environnement S.A. Model AF21M Sulfur Dioxide Analyzer," operated on a range of 0-0.5 ppm with a response time coefficient setting of 01, a Teflon filter installed in the rear-panel filter assembly, and with or without any of the following options: Rack Mount/Slides; RS-232-C Interface.

[Federal Register: Vol 57, page 5444, 02/14/92]

Horiba Models APSA-360, APSA-360-CE, or APSA-360A-CE SO₂ Monitors*Automated Equivalent Method: EQSA-0197-114*

"Horiba Instruments, Inc. Model APSA-360 and Model APSA-360-CE Ambient Sulfur Dioxide Monitor," operated with a full scale range of 0 - 0.50 ppm, at any temperature in the range of 5 EC to 40 EC, with a Line Setting of "MEASURE", an Analog Output Setting of "MOMENTARY VALUE", and with or without any of the following options:²

- 1) Rack Mounting Plate and Side Rails,
- 2) RS-232 Communications Port, and
- 3) Internal zero gas and span gas generator.

"Horiba Instruments, Inc. Model APSA-360A-CE Ambient Sulfur Dioxide Monitor," operated with one of the following measurement ranges: 0-0.05 ppm, 0-0.1 ppm, 0-0.2 ppm, 0-0.5 ppm or 0-1.0 ppm; with selectable time constants from 10 to 300 seconds; at any temperature in the range of 5EC to 40 EC; and with or without the optional internal zero gas and span gas generator.

[Federal Register: Vol 63, page 31992, 06/11/98]

Lear Siegler Model AM2020 SO₂ Monitor*Automated Equivalent Method: EQSA-0486-049*

"Lear Siegler Model AM2020 Ambient SO₂ Monitor," operated on a range of either 0-0.5 or 0-1.0 ppm, at a wavelength of 299.5 nm, with a 5 minute integration period, over any 10EC temperature range between 20EC and 45EC, with or without the automatic zero and span correction feature.

[Federal Register: Vol 45, page 79574, 12/01/80 and Vol 46, page 9997, 01/30/81]

Lear Siegler Model SM1000 SO₂ Monitor*Automated Equivalent Method: EQSA-1275-005*

"Lear Siegler Model SM1000 SO₂ Ambient Monitor," operated on the 0-0.5 ppm range, at a wavelength of 299.5 nm, with the "slow" (300 second) response time, with or without any of the following options: SM-1 Internal Zero/Span; SM-2 Span Timer Card; SM-3 0-0.1 Volt Output; SM-4 0-5 Volt Output; SM-5 Alternate Sample Pump; SM-6 Outdoor Enclosure. [Federal Register:

Vol 41, page 3893, 01/27/76; Vol 41, page 32946, 08/06/76; Vol 42, page 13044, 03/08/77; Vol 45, page 1147, 01/04/80]

Meloy Model SA185-2A SO₂ Analyzer*Automated Equivalent Method: EQSA-1275-006*

"Meloy Model SA185-2A Sulfur Dioxide Analyzer," operated on the 0-0.5 ppm range, with or without any of the following options:

S-1 Linearized Output	S-2 Modified Recorder Output	S-18 Rack Mount Conversion
S-24 Dual Range Linearized Output	S-5 Teflon-Coated Block	S-18A Rack Mount Conversion
S-33 Remote Range Control And Status	S-6A Reignite Timer Circuit	S-21 Front Panel Digital (Signals)
S-7 Press To Read Volt Meter	S-34 Remote Control	S-11A Manual Zero And Span
S-22 Remote Zero/Span Control And Status (Timer)	S-35 Front Panel Digital Meter With BCD Output	
S-11B Automatic Zero And Span	S-13 Status Lights	S-22A Remote Zero/Span Control
S-36 Dual Range Log-Linear Output	S-14 Output Booster Amplifier	S-23 Automatic Zero Adjust
S-38 Sampling Mode Status	S-14B Line Transmitter Board	S-23A Automatic/Manual Zero Adjust

or operated on the 0-1.0 ppm range with either option S-36 or options S-1 and S-24, with or without any of the other options.

[Federal Register: Vol 41, page 3893, 01/27/76 and Vol 43, page 38088, 08/25/78]

Meloy Model SA285E SO₂ Analyzer*Automated Equivalent Method: EQSA-1078-032*

"Meloy Model SA285E Sulfur Dioxide Analyzer," operated on the following ranges and time constant switch positions:

Range, ppb: 0-50¹, 0-100¹, 0-500, 0-1000

Time Constant Setting: 1 or 10 1 or 10 off, 1 or 10 off, 1 or 10

The analyzer may be operated at temperatures between 10EC and 40EC and at line voltages between 105 and 130 volts, with or without any of the following options:

S-5 Teflon Coated Block	S-22B Remote Zero/Span Control	S-30 Auto Reignite
S-14B Line Transmitter Board	And Status (Pulse)	S-32 Remote Range Control And Status
S-18 Rack Mount Conversion	S-23 Auto Zero Adjust	S-35 Front Panel Digital Meter With
S-18A Rack Mount Conversion	S-23A Auto/Manual Zero Adjust	BCD Output
S-21 Front Panel Digital Meter	S-25 Press To Read S-37 Temperature Status Lights	
S-22 Remote Zero/Span Control	S-26 Manual Zero And Span	S-38 Sampling Mode Status
And Status (Timer)	S-27 Auto Manual Zero/Span	
S-22A Remote Zero/Span Control	S-28 Auto Range And Status	

[Federal Register: Vol 43, page 50733, 10/31/78]

Meloy Model SA 700 Fluorescence Sulfur Dioxide Analyzer*Automated Equivalent Method: EQSA-0580-046*

"Meloy Model SA 700 Fluorescence Sulfur Dioxide Analyzer," operated on the 0-250 ppb¹, the 0-500 ppb, or the 0-1000 ppb range with a time constant switch position of either 2 or 3. The analyzer may be operated at temperatures between 20EC and 30EC and at line voltages between 105 and 130 volts, with or without any of the following options: FS-1 Current Output; FS-2 Rack Mount Conversion; FS-2A Rack Mount Conversion; FS-2B Rack Mount Conversion; FS-3 Front Panel Mounted Digital Meter; FS-5 Auto/Manual Zero/Span With Status; FS-6 Remote/Manual Zero/Span With Status; FS-7 Auto Zero Adjust.

[Federal Register: Vol 45, page 31488, 05/13/80]

Monitor Labs Model 8450 Sulfur Monitor*Automated Equivalent Method: EQSA-0876-013*

"Monitor Labs Model 8450 Sulfur Monitor", operated on a range of either 0-0.5 or 0-1.0 ppm, with a 5 second time constant, a model 8740 hydrogen sulfide scrubber in the sample line, with or without any of the following options: BP Bipolar Signal Processor; IZS Internal Zero/Span Module; V Zero/Span Valves; CLO Current Loop Output; TF TFE Sample Particulate Filter; VT Zero/Span Valves And Timer; DO Status Remote Interface.

[Federal Register: Vol 41, page 36245, 08/27/76 and Vol 44, page 33476, 06/11/79]

Monitor Labs/Lear Siegler Model 8850 SO₂ Analyzer*Automated Equivalent Method: EQSA-0779-039*

"Monitor Labs or Lear Siegler Model 8850 Fluorescent SO₂ Analyzer," operated on a range of either 0-0.5 or 0-1.0 ppm, with an internal time constant setting of 55 seconds, a TFE sample filter installed on the sample inlet line, with or without any of the following options: 03A Rack; 03B Slides; 05A Valves Zero/Span; 06A IZS Internal Zero/Span Source; 06B,C,D NIST Traceable Permeation Tubes; 08A Pump; 09A Rack Mount For Option 08A; 010 Status Output W/Connector; 013 Recorder Output Options; 014 DAS Output Options; 017 Low Flow Option; 018 Kicker.

[Federal Register: Vol 44, page 44616, 07/30/79]

Monitor Labs/Lear Siegler Model 8850S SO₂ Analyzer*Automated Equivalent Method: EQSA-0390-075*

"Monitor Labs or Lear Siegler Model 8850S SO₂ Analyzer," operated on a range of either 0-0.5 or 0-1.0 ppm.

[Federal Register: Vol 55, page 5264, 02/14/90]

Monitor Labs/Lear Siegler Model ML9850,*Automated Equivalent Method: EQSA-0193-092***Monitor Labs Model ML9850B, or Wedding & Associates Model 1040 SO₂ Analyzers**

"Lear Siegler Measurement Controls Corporation or Monitor Labs Model ML9850, Monitor Labs Model ML9850B, or Wedding & Associates, Inc. Model 1040 Sulfur Dioxide Analyzers," operated on any full scale range between 0-0.050 ppm¹ and 0-1.0 ppm, at any temperature in the range of 15EC to 35EC, with the service switch on the secondary panel set to the *In* position; with the following menu choices selected: Range: *0.05 ppm to 1.0 ppm*; Over-ranging: *Enabled* or *Disabled*; Background: *Not Disabled*; Calibration: *Manual* or *Timed*; Diagnostic Mode: *Operate*; Filter Type: *Kalman*; Pres/Temp/Flow Comp: *On*; Span Comp: *Disabled*; and as follows: **Model ML9850** - with a five-micron Teflon® filter element installed internally, with the 50-pin I/O board installed on the rear panel configured at any of the following output range settings: Voltage, 0.1 V, 1 V, 5 V, 10 V; Current, 0-20 mA, 2-20 mA, 4-20 mA; and with or without any of the following options: Valve Assembly for External Zero/Span (EVS); Rack Mount Assembly; Internal Floppy Disk Drive. **Models ML9850B and 1040** - with either a vendor-supplied or equivalent user supplied five-micron Teflon® filter, zero air scrubber, and exhaust pump, and with or without any of the following options: Valve Assembly for External Zero/Span (EVS); Rack Mount Assembly; 50-pin I/O board; Exhaust Scrubber; Internal Zero/Span Assembly (IZS); hinged, fold-down front panel.

[Federal Register: Vol 58, page 6964, 02/03/93]

Opsis Model AR 500 and System 300 Open Path Ambient Air Monitoring Systems for SO₂*Automated Equivalent Method: EQSA-0495-101*

"Opsis Model AR 500 System" or "System 300" Open Path (long path) Ambient Air Monitoring Systems, configured for measuring SO₂, with one detector and movable grating, operated with a measurement range of 0 to 0.5 ppm or 0 to 1.0 ppm, an installed monitoring path length between 20 and 500 meters (or 20 and 1000 meters with the ER 150 option, AR 500 System only), xenon lamp type B (150 watt), fiber optic cable length between 3 to 20 meters; operating within an ambient air temperature range of -50 to +50EC, an analyzer temperature range of 20 to 30EC, a measurement (integrating) time setting between 30 and 120 seconds (0 min:30 sec. to 2 min:00 sec.), and with a complete cycle time of not more than 200 seconds (3 min, 20 sec.). Under this method designation, the Model AR 500 System or System 300 consists of: AR 500 opto-analyser; emitter EM 110 and receiver RE 110 (together identified as ER 110); optic fibre cable OF60-S; power supply PS 150; OPSIS operational software, version 7.0 or 7.1; and initial on-site installation, setup, and limited operator training.²

Optional components that can be used with the Model AR 500 only, in addition to or as alternative to corresponding components listed above:

AR 503 opto-analyzer configured as Model AR 500 (only the center detector active, sequential monitoring)

Emitter/receiver ER 150 (for monitoring path lengths up to 1 kilometer)

Transceiver ER 130 and Retroreflector RE 090 with:

7 prisms (max. monitoring path length 150 meters) or

12 prisms (max. monitoring path length 250 meters)

Receiver RE 130

Xenon lamp type A (higher short-wavelength UV output)

Optic fibre cable OF60-R (low-loss for short wavelengths)

Multiplexers MX 004 and MX 024

Dataloggers DL 010 and DL 016

Analogue and digital input/output cards AO 008, AI 016, and DI 032

Analogue and digital isolation cards IA 008, ID 008, OA 008, and OD 008,

Window heaters HF 110 and HF 150

Mirror heaters HM 110 and HM 150

Auto calibration unit CU 007

Software packages IO 80 (for the analogue and digital input/output adapters), DL10 and DL16 (for data loggers),

COMVISION, and STAT 500;

Recommended calibration and accuracy audit components (or equivalent) for either Model AR 500 or System 300:

Wavelength calibration lamp CA 004

Calibration bench CB 100

Receiver unit RE 060 (two required)

Calibration unit CA 150, with same type lamp as used in the monitoring path emitter

Power supply PS 150 for calibration unit CA 150

Calibration cells CC 001-X, where X represents various cell lengths from 1 to 900 mm

Special calibration cells CC 110 or CC 150 (for mounting directly on receiver)

Light meter LM 010.

[Federal Register: Vol. 60, page 21518, 05/02/1995]

Philips PW9755 SO₂ Analyzer*Automated Equivalent Method: EQSA-0676-010*

"Philips PW9755 SO₂ Analyzer," consisting of the following components: PW9755/02 SO₂ Monitor with PW9741/00 SO₂ Source, PW9721/00 Filter Set SO₂, PW9711/00 Electrolyte SO₂, PW9750/00 Supply Cabinet, PW9750/10 Supply Unit/ Coulometric, either PW9731/00 Sampler or PW9731/20 Dust Filter (or vendor-approved alternate particulate filter); operated with a 0-0.5 ppm range and with a reference voltage setting of 760 millivolts; with or without any of the following options: PW9750/30 Frame For MTT; PW9752/00 Air Sampler Manifold; PW9753/00 Mounting Rack For Accessories; PW9750/41 Control Clock 60 Hz; PW9754/00 Air Distributor. [Federal Register: Vol 41, page 26252, 6/25/76; Vol 41, page 46019, 10/19/76; Vol 42, page 28571, 6/03/77]

Philips PW9700 SO₂ Analyzer*Automated Equivalent Method: EQSA-0876-011*

"Philips PW9700 SO₂ Analyzer," consisting of the following components: PW9710/00 Chemical Unit with PW9711/00 Electrolyte SO₂, PW9721/00 Filter Set SO₂, PW9740/00 SO₂ Source; PW9720/00 Electrical Unit; PW9730/00 Sampler Unit (or vendor-approved alternate particulate filter); operated with a 0-0.5 ppm range and with a reference voltage of 760 millivolts.

[Federal Register: Vol 41, page 34105, 08/12/76]

Thermo Electron Model 43 SO₂ Analyzer*Automated Equivalent Method: EQSA-0276-009*

"Thermo Electron Model 43 Pulsed Fluorescent SO₂ Analyzer," equipped with an aromatic hydrocarbon cutter and operated on a range of either 0-0.5 or 0-1.0 ppm, with or without any of the following options: 001 Rack Mounting For Standard 19 Inch Relay Rack; 002 Automatic Actuation Of Zero And Span Solenoid Valves; 003 Type S Flash Lamp Power Supply; 004 Low Flow.

[Federal Register: Vol 41, page 8531, 02/27/76; Vol 41, page 15363, 04/12/76; Vol 42, page 20490, 04/20/77
Vol 44, page 21861, 04/12/79; Vol 45, page 2700, 01/14/80; Vol 45, page 32419, 05/16/80]

Thermo Environmental Instruments, Inc. Models 43A, 43B, 43C Analyzers*Automated Equivalent Method: EQSA-0486-060*

"Thermo Electron or Thermo Environmental Instruments, Inc. Model 43A or 43B Pulsed Fluorescence SO₂ Analyzer," operated on the 0-0.1 ppm¹, the 0-0.2 ppm¹, the 0-0.5 ppm, or the 0-1.0 ppm range, with either a high or a low time constant setting (Model 43A) and with or without any of the following options:²

001 Teflon Particulate Filter	004 High Flow Rate (1 LPM)	007 Remote Activation Of Zero/Span Valves
002 19" Rack Mounting Configuration	005 Current Output	008 RS-232 Interface (Model 43B)
003 Internal Zero/Span Valves	006 Internal Permeation Span Source	009 Pressure/Temperature Compensation (Model 43B)

"Thermo Environmental Instruments, Inc. Model 43C Pulsed Fluorescence SO₂ Analyzer," operated on any measurement range between 0-50 ppb¹ and 0-1000 ppb, with any time average setting from 10 to 300 seconds, with temperature and/or pressure compensation on or off, operated at temperatures between 20 °C and 30 °C, with or without any of the following options:²

43C-001 Teflon particulate filter	43C-005 4-20 mA current output
43C-002 Rack mounts	43C-006 Internal permeation span source
43C-003 Internal zero/span and sample solenoid valves	43C-007 Remote activation of zero/span and sample valves
43C-004 High flow rate (0.5-1.0 LPM)	43C-008 RS-232/485 interface

[Federal Register: Vol 51, page 12390, 04/10/86]

OZONE**Advanced Pollution Instrumentation, Inc. Model 400/400A Ozone Analyzer***Automated Equivalent Method: EQOA-0992-087*

"Advanced Pollution Instrumentation, Inc. Model 400 or 400A Ozone Analyzer," operated on any full scale range between 0-100 ppb* and 0-1000 ppb, with any range mode (Single, Dual, or AutoRange), at any ambient temperature in the range of 5EC to 40EC, with the dynamic zero and span adjustment feature (some Model 400 units only) set to OFF, with a 5-micron TFE filter element installed in the rear-panel filter assembly, and with or without any of the following options: Zero/Span Valve option, Internal Zero/Span (IZS) option, IZS ozone generator reference feedback option, standard serial port or Multi-drop RS-232, digital status outputs, analog outputs: 100 mV, 1 V, 5 V, 10 V, 4-20 mA current loop, optional metal wool ozone scrubber, optional external sample pump, optional 47 mm diameter filter, optical bench heater, rack mount with slides.

[Federal Register: Vol 63, page 31992, 06/11/98]

Beckman Model 950A Ozone Analyzer*Automated Reference Method: RFOA-0577-020*

"Beckman Model 950A Ozone Analyzer," operated on a range of 0-0.5 ppm and with the "SLOW" (60 second) response time, with or without any of the following options: Internal Ozone Generator; Computer Adaptor Kit; Pure Ethylene Accessory.

[Federal Register: Vol 42, page 28571, 06/03/77]

Bendix or Combustion Engineering Model 8002 Ozone Analyzer*Automated Reference Method: RFOA-0176-007*

"Bendix or Combustion Engineering Model 8002 Ozone Analyzer", operated on the 0-0.5 ppm range, with a 40 second time constant, with or without any of the following options: Rack Mounting With Chassis Slides; Rack Mounting Without Chassis Slides; Zero And Span Timer; Ethylene/CO₂ Blend Reactant Gas.

[Federal Register: Vol 41, page 5145, 02/04/76 and Vol 45, page 18474, 03/21/80]

Columbia Scientific Industries Model 2000 Ozone Meter*Automated Reference Method: RFOA-0279-036*

"Columbia Scientific Industries Model 2000 Ozone Meter," when operated on the 0-0.5 ppm range with either AC or battery power: The BCA 952 battery charger/AC adapter M952-0002 (115V) or M952-0003 (230V) is required for AC operation; an internal battery M952-0006 or 12 volt external battery is required for portable non-AC powered operation.

[Federal Register: Vol 44, page 10429, 02/20/79]

Dasibi Models 1003-AH, 1003-PC, or 1003-RS Ozone Analyzers*Automated Equivalent Method: EQOA-0577-019*

"Dasibi Model 1003-AH, 1003-PC, or 1003-RS Ozone Analyzer," operated on a range of either 0-0.5 or 0-1.0 ppm, with or without any of the following options: Adjustable Alarm; Aluminum Coated Absorption Tubes, Integrated Output; Vycor-Jacketed U.V. Source Lamp; BCD Digital Output; Rack Mounting Ears And Slides; 0-10 mV, 0-100 mV, 0-1 V, Or 0-10 V; Glass (Pyrex) Absorption Tubes; Teflon-based Solenoid Valve; Analog Output.

[Federal Register: Vol 42, page 28571, 06/03/77]

Dasibi Models 1008-AH, 1008-PC, or 1008-RS Ozone Analyzers*Automated Equivalent Method: EQOA-0383-056*

"Dasibi Model 1008-AH, 1008-PC, or 1008-RS Ozone Analyzer," operated on a range of either 0-0.5 or 0-1.0 ppm, with or without any of the following options: Aluminum Coated Absorption Tubes; BCD Digital Output; RS232 Interface; Glass (Pyrex) Absorption Tubes; Vycor-Jacketed U.V. Source Lamp; Ozone Generator; Teflon-based Solenoid Valve; Photometer Flow Restrictor (2 LPM); 4-20 mA, Isolated, Or Dual Analog Outputs; Rack Mounting Brackets Or Slides; 20 Second Update Software.

[Federal Register: Vol 48, page 10126, 03/10/83]

DKK Corp. Model GUX-113E Ozone Analyzer*Automated Equivalent Method: EQOA-0200-134*

"DKK Corporation Model GUX-113E Ozone Analyzer," operated at any temperature in the range of 15° C to 35° C and on any of the following measurement ranges: 0-0.100 ppm, 0-0.200 ppm, 0-0.5 ppm, or 0-1.000 ppm.

[Federal Register: Vol 65, page 11308, 03/02/00]

EnviroNics Series 300 Ozone Analyzer*Automated Equivalent Method: EQOA-0990-078*

"EnviroNics Series 300 Computerized Ozone Analyzer," operated on the 0-0.5 ppm range, with the following parameters entered into the analyzer's computer system: Absorption Coefficient = 308 ± 4 ; Flush Time = 3; Integration Factor = 1; Offset Adjustment = 0.025 ppm; Ozone Average Time = 4; Signal Average = 0; Temp/Press Correction = 0; and with or without the RS-232 Serial Data Interface.

[Federal Register: Vol 55, page 38386, 09/18/90]

Environnement S.A. Model O₃41M UV Ozone Analyzer*Automated Equivalent Method: EQOA-0895-105*

"Environnement S.A. Model O₃41M UV Photometric Ozone Analyzer," operated on a full scale range of 0 - 500 ppb, at any temperature in the range of 15 EC to 35 EC, with the response time set to 50 seconds, and with or without any of the following options:² Internal Ozone Generator; Span External Control; RS232-422 Serial Interface; Internal Printer.

[Federal Register: Vol. 60, page 39382, 08/02/95]

Horiba Instruments Models APOA-360 and APOA-360-CE Ozone Monitor*Automated Equivalent Method: EQOA-0196-112*

"Horiba Instruments, Inc. Model APOA-360 or APOA-360-CE Ambient Ozone Monitor," operated with a full scale range of 0 - 0.50 ppm, at any temperature in the range of 10EC to 40EC, with a Line Setting of "MEASURE", and an Analog Output of "MOMENTARY VALUE", and with or without any of the following options:² 1) Rack Mounting Plate and Side Rails 2) RS-232 Communications Port, and 3) Optional Internal Zero/Span Check.

[Federal Register: Vol. 61, page 11404, 03/20/96]

McMillan (MEC) Models 1100-1, 1100-2, and 1100-3 Ozone Meters

"MEC Model 1100-1 Ozone Meter,"

Automated Reference Method: RFOA-1076-014

"MEC Model 1100-2 Ozone Meter,"

Automated Reference Method: RFOA-1076-015

"MEC Model 1100-3 Ozone Meter,"

Automated Reference Method: RFOA-1076-016

operated on a 0-0.5 ppm range, with or without any of the following options: 0011 Rack Mounting Ears; 0026 Alarm Set Feature; 0012 Instrument Bail; 0033 Local-Remote Sample; Zero, Span Kit Blend Feature; 0016 Chassis Slide Kit; 0040 Ethylene/CO₂.

[Federal Register: Vol 41, page 46647, 10/22/76 and Vol 42, page 30235, 06/13/77]

Meloy Model OA325-2R Ozone Analyzer*Automated Reference Method: RFOA-1075-003*

"Meloy Model OA325-2R Ozone Analyzer," operated with a scale range of 0-0.5 ppm, with or without any of the following options: 0-4 Output Booster Amplifier; 0-18 Rack Mount Conversion; 0-18A Rack Mount Conversion.

[Federal Register: Vol 40, page 54856, 11/26/75]

Meloy Model OA350-2R Ozone Analyzer*Automated Reference Method: RFOA-1075-004*

"Meloy Model OA350-2R Ozone Analyzer," operated with a scale range of 0-0.5 ppm, with or without any of the following options: 0-2 Automatic Zero And Span; 0-3 Remote Control Zero And Span; 0-4 Output Booster Amplifier; 0-18 Rack Mount Conversion; 0-18A Rack Mount Conversion.

[Federal Register: Vol 40, page 54856, 11/26/75]

Monitor Labs Model 8410E Ozone Analyzer*Automated Reference Method: RFOA-1176-017*

"Monitor Labs Model 8410E Ozone Analyzer," operated on a range of 0-0.5 ppm with a time constant setting of 5 seconds, with or without any of the following options: DO Status Outputs; ER Ethylene Regulator Assembly; V TFE Zero/Span Valves; TF TFE Sample Particulate Filter; VT TFE Zero/Span Valves And Timer.

[Federal Register: Vol 41, page 53684, 12/08/76]

Monitor Labs/Lear Siegler Model 8810 Ozone Analyzer*Automated Equivalent Method: EQOA-0881-053*

"Monitor Labs or Lear Siegler Model 8810 Photometric Ozone Analyzer," operated on a range of either 0-0.5 or 0-1.0 ppm, with selectable electronic time constant settings from 20 through 150 seconds, with or without any of the following options: 05 Pressure Compensation; 06 Averaging Option; 07 Zero/Span Valves; 08 Internal Zero/Span (Valve And Ozone Source); 09 Status; 10 Particulate Filter; 15 through 20 DAS/REC Output.

[Federal Register: Vol 46, page 52224, 10/26/81]

Monitor Labs/Lear Siegler Models ML9810, ML9811, or ML9812,*Automated Equivalent Method: EQOA-0193-091***Monitor Labs Model ML9810B, or Wedding & Associates Model 1010 Ozone Analyzers**

"Lear Siegler Measurement Controls Corporation Model ML9810 or Monitor Labs Models ML9810, ML9811, or ML9812, Monitor Labs Model 9810B, or Wedding & Associates, Inc. Model 1010 Ozone Analyzers," operated on any full scale range between 0-0.05 ppm¹ and 0-1.0 ppm, at any temperature in the range of 15EC to 35EC, with the service switch on the secondary panel set to the *In* position; with the following menu choices selected: Range: *0.05 ppm to 1.0 ppm*; Over-ranging: *Enabled* or *Disabled*; Calibration: *Manual* or *Timed*; Diagnostic Mode: *Operate*; Filter Type: *Kalman*; Pres/Temp/Flow Comp: *On*; Span Comp: *Disabled*; and as follows: **Models ML9810, ML9811, and ML9812** - with a five-micron Teflon® filter element installed internally, with the 50-pin I/O board installed on the rear panel configured at any of the following output range settings: Voltage, 0.1 V, 1 V, 5 V, 10 V; Current, 0-20 mA, 2-20 mA, 4-20 mA; and with or without any of the following options: Valve Assembly for External Zero/Span (EVS); Rack Mount Assembly; Internal Floppy Disk Drive. **Models ML9810B and 1010** - with either a vendor-supplied or equivalent user-supplied five micron Teflon® filter and exhaust pump, and with or without any of the following options: Valve Assembly for External Zero/Span (EVS); Rack Mount Assembly; 50-pin I/O board; Internal Zero/Span Assembly (IZS); hinged, fold-down front panel. [Federal Register: Vol 58, page 6964, 02/03/93]

Opsis Model AR 500 and System 300 Open Path Ambient Air Monitoring Systems for Ozone

Automated Equivalent Method: EQOA-0495-103

"Opsis Model AR 500 System" or "System 300" Open Path (long path) Ambient Air Monitoring Systems, configured for measuring O₃, with one detector and moveable grating, operated with a measurement range of 0 to 0.5 ppm, an installed monitoring path length between 20 and 500 meters (or 20 and 1000 meters with the ER 150 option, AR 500 System only), xenon lamp type B (150 watt), fiber optic cable length between 3 to 20 meters; operating within an ambient air temperature range of -50 to + 50EC, an analyzer temperature range of 20 to 30EC, a measurement (integrating) time setting between 30 and 120 seconds (0 min:30 sec. to 2 min:00 sec.), and with a complete cycle time of not more than 200 seconds (3 min, 20 sec.). Under this method designation, the Model AR 500 System or System 300 consists of: AR 500 opto-analyser; emitter EM 110 and receiver RE 110 (together identified as ER 110); optic fibre cable OF60-S; power supply PS 150, OPSIS operational software, version 7.0 or 7.1; and initial on-site installation, setup, and limited operator training.²

Optional components that can be used with the Model AR 500

Auto calibration unit CU 007

only, in addition to or as alternative to corresponding components listed above:

Software packages IO 80 (for the analogue and digital input/output adapters), DL10 and DL16 (for data loggers), ComVision, and STAT 500;

AR 503 opto-analyzer configured as Model AR 500 (only the center detector active, sequential monitoring)

Emitter/receiver ER 150 (for monitoring path lengths up to 1 kilometer)

Transceiver ER 130 and Retroreflector RE 090 with:
7 prisms (max. monitoring path length 150 meters) or
12 prisms (max. monitoring path length 250 meters)

Receiver RE 130

Optic fibre cable OF60-R (low-loss for short wavelengths)

Multiplexers MX 004 and MX 024

Dataloggers DL 010 and DL 016

Analogue and digital input/output cards AO 008, AI 016, and DI 032

Analogue and digital isolation cards IA 008, ID 008, OA 008, and OD 008,

Window heaters HF 110 and HF 150

Mirror heaters HM 110 and HM 150

Recommended calibration and accuracy audit components (or equivalent) for either Model AR 500 or System 300:

Wavelength calibration lamp CA 004

Calibration bench CB 100

Receiver unit RE 060 (two required)

Calibration unit CA 150, with same type lamp as used in the monitoring path emitter

Power supply PS 150 for calibration unit CA 150

Calibration cells CC 001-X, where X represents various cell lengths from 1 to 900 mm

Special calibration cells CC 110 or CC 150 (for mounting directly on receiver)

Ozone generator OC 500

Light meter LM 010.

Federal Register: Vol. 60, page 21518, 05/02/1995]

PCI Ozone Corporation Model LC-12 Ozone Analyzer

Automated Equivalent Method: EQOA-0382-055

"PCI Ozone Corporation Model LC-12 Ozone Analyzer," operated on a range of 0-0.5 ppm.

[Federal Register: Vol 47, page 13572, 03/31/82]

Philips PW9771 03 Analyzer

Automated Equivalent Method: EQOA-0777-023

"Philips PW9771 03 Analyzer," consisting of the following components: PW9771/00 03 Monitor with PW9724/00 Disc.-Set; PW9750/00 Supply Cabinet; PW9750/20 Supply Unit operated on a range of 0-0.5 ppm, with or without any of the following accessories: PW9732/00 Sampler Line Heater; PW9750/30 Frame For MTT; PW9750/41 Control Clock 60 Hz; PW9733/00 Sampler; PW9752/00 Air Sampler Manifold. [Federal Register: Vol 42, page 38931, 08/01/77; Vol 42, page 57156, 11/01/77]

Thermo Electron/Thermo Environmental Instruments Models 49, 49C

Automated Equivalent Method: EQOA-0880-047

"Thermo Electron or Thermo Environmental Instruments, Inc. Model 49 U.V. Photometric Ambient O₃ Analyzer" operated on a measurement range of either 0-0.5 or 0-1.0 ppm with or without any of the following options: 49-001 Teflon Particulate Filter; 49-002 19 Inch Rack Mount; 49-100 Internal Ozone Generator for Zero, Precision, and Level 1 Span Check; 49-103 Internal Ozone Generator for Zero, Precision, and Level 1 Span Checks With Remote Activation; 49-488 GPIB (General Purpose Interface Bus) IEEE-488

"Thermo Electron or Thermo Environmental Instruments, Inc. Model 49C U.V. Photometric Ambient O₃ Analyzer" operated on any measurement range between 0-0.05¹ to 1.0 ppm with any time average setting between 10 and 300 seconds, with the temperature and/or pressure compensation on or off, with or without any of the following options: ²

100	Teflon particulate filter	420	Internal Zero Air Scrubber
200	Carrying Handle	610	4-20 mA current output
210	Rack mounts	730	RS-232 Interface
340	Internal Ozonator	780	RS-485 Interface
350	Internal Ozonator with Remote I/O Activation		[Federal Register: Vol 45, page 57168, 08/27/80]

CARBON MONOXIDE

Advanced Pollution Instrumentation, Inc. Model 300 CO Analyzer

Automated Reference Method: RFCA-1093-093

"Advanced Pollution Instrumentation, Inc. Model 300 Gas Filter Correlation Carbon Monoxide Analyzer," operated on any full scale range between 0-10 ppm and 0-50 ppm, at any temperature in the range of 15°C to 35°C, with the dynamic zero and span adjustment set to *Off*, with a 5-micron TFE filter element installed in the filter assembly, and with or without any of the following options: ² Internal Zero/Span (IZS); Rack Mount With Slides; Zero/Span Valves; RS-232 With Status Outputs.

[Federal Register: Vol. 58, page 58166, 10/29/93]

Beckman Model 866 CO Monitoring System

Automated Reference Method: RFCA-0876-012

"Beckman Model 866 Ambient CO Monitoring System," consisting of the following components: Pump/Sample-Handling Module; Gas Control Panel; Model 865-17 Analyzer Unit; Automatic Zero/Span Standardizer; operated with a 0-50 ppm range, a 13 second electronic response time, with or without any of the following options: Current Output Feature; Bench Mounting Kit; Linearizer Circuit.

[Federal Register: Vol. 41, page 36245, 08/27/76]

Bendix/Combustion Engineering Model 8501-5CA CO Analyzer

Automated Reference Method: RFCA-0276-008

"Bendix or Combustion Engineering Model 8501-5CA Infrared CO Analyzer", operated on the 0-50 ppm range and with a time constant setting between 5 and 16 seconds, with or without any of the following options: Rack Mounting With Chassis Slides; Rack Mounting Without Chassis Slides; External Sample Pump.

[Federal Register: Vol. 41, page 7450, 02/18/76]

Dasibi Model 3003 CO Analyzer

Automated Reference Method: RFCA-0381-051

"Dasibi Model 3003 Gas Filter Correlation Dasibi Environmental CO Analyzer," operated on the 0-50 ppm range, with a sample particulate filter installed on the sample inlet line, with or without any of the following options:

3-001 Rack Mount	3-003 BCD Digital Output	3-007 Zero/Span Module Panel
3-002 Remote Zero And Span	3-004 4-20 Milliamp Output	

[Federal Register: Vol. 46, page 20773, 04/07/81]

Dasibi Model 3008 CO Analyzer

Automated Reference Method: RFCA-0488-067

"Dasibi Model 3008 Gas Filter Correlation CO Analyzer," operated on the 0-50 ppm range, with a time constant setting of 60 seconds, a particulate filter installed in the analyzer sample inlet line, with or without use of the auto zero or auto zero/span feature, and with or without any of the following options: N-0056-A RS-232-C Interface; S-0132-A Rack Mounting Slides; Z-0176-S Rack Mounting Brackets.

[Federal Register: Vol. 53, page 12073, 04/12/88]

Environnement S.A. Model CO11M CO Analyzer

Automated Reference Method: RFCA-0995-108

"Environnement S.A. Model CO11M Ambient Carbon Monoxide Analyzer," operated on a full scale range of 0 - 50 ppm, at any temperature in the range of 15 °C to 35 °C, with a 5-micron PTFE sample particulate filter, with the following software settings: Automatic response time ON; Minimum response time set to 40 seconds (RT 13); Automatic ZERO-REF cycle programmed every 24 hours; and with or without any of the following options: ² RS232-422 Serial Interface; Internal Printer.

[Federal Register: Vol. 60, page 54684, 10/25/95]

Horiba Models AQM-10, AQM-11, and AQM12 CO Monitoring Systems

Automated Reference Method: RFCA-1278-033

"Horiba Models AQM-10, AQM-11, and AQM12 Ambient CO Monitoring Systems," operated on the 0-50 ppm range, with a response time setting of 15.5 seconds, with or without any of the following options: AIC-101 Automatic Indication Corrector; V I T - 3 Non-Isolated Current Output; ISO-2 And DCS-3 Isolated Current Output.

[Federal Register: Vol. 43, page 58429, 12/14/78]

Horiba Model APMA-300E CO Monitoring System

Automated Reference Method: RFCA-1180-048

"Horiba Model APMA-300E Ambient Carbon Monoxide Monitoring System," operated on the 0-20 ppm¹, the 0-50 ppm, or the 0-100 ppm range with a time constant switch setting of No. 5. The monitoring system may be operated at temperatures between 10°C and 40°C. (This method was originally designated as "Horiba Model APMA 300E/300SE Ambient Carbon Monoxide Monitoring System".)

[Federal Register: Vol. 45, page 72774, 11/03/80]

Horiba Model APMA-360 CO Monitor

Automated Reference Method: RFCA-0895-106

"Horiba Instruments Incorporated, Model APMA-360 Ambient Carbon Monoxide Monitor," operated on the 0-50 ppm range, with the Line Setting set to "MEASURE", with the Analog Output set to "MOMENTARY VALUE", and with or without the following options:² 1) Rack Mounting Plate and Side Rails 2) RS-232 Com Port.

[Federal Register: Vol. 60, page 39382, 08/02/95]

MASS-CO, Model 1 CO AnalyzerAutomated Reference Method: **RFCA-1280-050**

"MASS-CO, Model 1 Carbon Monoxide Analyzer," operated on a range of 0-50 ppm, with automatic zero and span adjustments at time intervals not to exceed 4 hours, with or without the 100 millivolt and 5 volt output options. The method consists of the following components: (1) Infra-2 (Uras 2) Infrared Analyzer Model 5611-200-35, (2) Automatic Calibrator Model 5869-111, (3) Electric Gas Cooler Model 7865-222 or equivalent with prehumidifier, (4) Diaphragm Pump Model 5861-214 or equivalent, (5) Membrane Filter Model 5862-111 or equivalent, (6) Flow Meter Model SK 1171-U or equivalent, (7) Recorder Model Mini Comp DN 1/192 or equivalent. NOTE: This method is not now commercially available. [Federal Register: Vol. 45, page 81650, 12/11/80]

Monitor Labs Model 8310 CO AnalyzerAutomated Reference Method: **RFCA-0979-041**

"Monitor Labs Model 8310 CO Analyzer," operated on the 0-50 ppm range, with a sample inlet filter, with or without any of the following options:

02A Zero/Span Valves	04B Pump (50 Hz)	07A Zero/Span Valve Power Supply
03A Floor Stand	05A CO Regulator	08A Calibration Valves
04A Pump (60 Hz)	06A CO Cylinder	9A,B,C,D Input Power Transformer

[Federal Register: Vol. 44, page 54545, 09/20/79 and Vol. 45, page 2700, 01/14/80]

Monitor Labs/Lear Siegler Model 8830 CO AnalyzerAutomated Reference Method: **RFCA-0388-066**

"Monitor Labs or Lear Siegler Model 8830 CO Analyzer," operated on the 0-50 ppm range, with a five micron Teflon filter element installed in the rear-panel filter assembly, with or without any of the following options: 2 - Zero/Span Valve Assembly; 3 - Rack Assembly; 4 - Slide Assembly; 7 - 230 VAC, 50/60 Hz. [Federal Register: Vol. 53, page 7233, 03/07/88]

Monitor Labs/Lear Siegler Model ML9830,Automated Reference Method: **RFCA-0992-088****Monitor Labs Model ML9830B, or Wedding & Associates Model 1020 CO Analyzers**

"Lear Siegler Measurement Controls Corporation or Monitor Labs Model ML9830, Monitor Labs Model ML9830B, or Wedding & Associates, Inc. Model 1020 Carbon Monoxide Analyzer," operated on any full scale range between 0-5.0 ppm¹ and 0-100 ppm, at any temperature in the range of 15EC to 35EC, with the service switch on the secondary panel set to the *In* position, with the following menu choices selected: Range: *5.0 ppm* to *100.0 ppm*; Over-ranging: *Enabled* or *Disabled*; Background: *Not Disabled*; Calibration: *Manual* or *Timed*; Diagnostic Mode: *Operate*; Filter Type: *Kalman*; Pres/Temp/Flow Comp: *On*; Span Comp: *Disabled*; and as follows: **Model ML9830:** with a five-micron Teflon® filter element installed internally, with the 50-pin I/O board installed on the rear panel configured at any of the following output range settings: Voltage, 0.1 V, 1 V, 5 V, 10 V; Current, 0-20 mA, 2-20 mA and 4-20 mA; and with or without any of the following options: Valve Assembly for External Zero/Span (EVS); Valve Assembly for Internal Zero/Span (IZS); Rack Mount Assembly; Internal Floppy Disk Drive. **Models ML9830B and 1020:** with either a vendor-supplied or equivalent user-supplied five micron Teflon® filter and exhaust pump, and with or without any of the following options: Valve Assembly for External Zero/Span (EVS); 50-pin I/O board; Rack Mount Assembly; High Pressure Span Valve; hinged, fold-down front panel.

[Federal Register: Vol. 57, page 44565, 09/28/92]

MSA/LIRA Model 202S CO Analyzer SystemAutomated Reference Method: **RFCA-0177-018**

"LIRA Model 202S Air Quality Carbon Monoxide Analyzer System," consisting of a LIRA Model 202S optical bench (P/N 459839), a regenerative dryer (P/N 464084), and rack-mounted sampling system; operated on a 0-50 ppm range, with the slow response amplifier, with or without any of the following options: Remote Meter; Remote Zero And Span Controls; 0-1, 5, 20, Or 50 mA Output; 1-5, 4-20, Or 10-50 mA Output; 0-10 Or 100 mV Output; 0-1, 5, Or 10 Volt Output.

[Federal Register: Vol. 42, page 5748, 01/31/77]

Thermo Electron/Thermo Environmental Instruments Models 48, 48CAutomated Reference Method: **RFCA-0981-054**

"Thermo Electron or Thermo Environmental Instruments, Inc. Model 48 Gas Filter Correlation Ambient CO Analyzer," operated on the 0-50 ppm range, with a time constant setting of 30 seconds, with or without any of the following options:

48-001	Teflon Particulate Filter	48-010	Internal Zero Air Package
48-002	19 Inch Rack Mount	48-488	GPB (General Purpose Interface Bus) EEEE-488
48-003	Internal Zero/Span Valves with Remote Activation		

"Thermo Electron or Thermo Environmental Instruments, Inc. Model 48C Gas Filter Correlation Ambient CO Analyzer," operated on any measurement range between 0-1 ppm¹ and 0-100 ppm, with any time average setting from 10 to 300 seconds, with temperature and/or pressure compensation on or off, operated at temperatures between 20 °C and 30 °C, with or without any of the following

options: ²	100	Teflon particulate filter	410	Internal Zero Air Scrubber
	200	Carrying Handle	610	4-20 mA current output
	210	Rack mounts	720	RS-232 Interface
	320	Internal Zero/Span and Sample/Calibration Solenoid Valves	770	RS-485 Interface
	330	Internal Zero/Span and Sample/ Calibration Solenoid Valves		
		with Remote I/O Activation		

[Federal Register: Vol. 46, page 47002, 09/23/81]

NITROGEN DIOXIDE

Sodium Arsenite Method for NO₂

"Sodium Arsenite Method for the Determination of Nitrogen Dioxide in the Atmosphere"

Manual Equivalent Method: **EQN-1277-026**

[Federal Register: Vol. 42, page 62971, 12/14/77]

Sodium Arsenite Method for NO₂ - Technicon II

"Sodium Arsenite Method for the Determination of Nitrogen Dioxide in the Atmosphere-Technicon II Automated Analysis System"

Manual Equivalent Method: **EQN-1277-027**

[Federal Register: Vol. 42, page 62971, 12/14/77]

TGS-ANSA Method for NO₂

"TGS-ANSA Method for the Determination of Nitrogen Dioxide in the Atmosphere"

Manual Equivalent Method: **EQN-1277-028**

[Federal Register: Vol. 42, page 62971, 12/14/77]

Advanced Pollution Instrumentation, Inc. Model 200 NO₂ AnalyzerAutomated Reference Method: **RFNA-0691-082**

"Advanced Pollution Instrumentation, Inc. Model 200 Nitrogen Oxides Analyzer," operated on a range of either 0-0.5 or 0-1.0 ppm, with a 5-micron TFE filter element installed in the rear-panel filter assembly, with either a user- or vendor-supplied vacuum pump capable of providing 5 inches mercury absolute pressure at 5 slpm, with either a user- or vendor-supplied dry air source capable of providing air at a dew point of 0EC or lower, with the following settings of the adjustable setup variables:

Adaptive Filter = <i>On</i>	PMT Temperature Set Point = <i>15EC</i>	Normal Filter Size = <i>12 samples</i>
Dwell Time = <i>7 seconds</i>	Rate of Change(ROC) Threshold = <i>10%</i>	Dynamic Span = <i>Off</i>
Sample Time = <i>8 seconds</i>	Reaction Cell Temperature = <i>50EC</i>	Dynamic Zero = <i>Off</i>

and with or without any of the following options:

180 Stainless Steel Valves	283 Internal Zero/Span With Valves (IZS)	356 Level One Spares Kit
184 Pump Pack	325 RS-232/Status Output	357 Level Two Spares Kit
280 Rack Mount With Slides	355 Expendables	PE5 Permeation Tube for IZS

[Federal Register: Vol. 56, page 27014, 06/12/91]

Advanced Pollution Instrumentation, Inc. Models 200A/200AU NO₂ AnalyzersAutomated Reference Method: **RFNA-1194-099**

"Advanced Pollution Instrumentation, Inc. Models 200A and 200AU Nitrogen Oxides Analyzers," operated on any full scale range between 0-0.05 ppm and 0-1.0 ppm, with either a 1 or 5-micron TFE filter element installed in the filter assembly, with the following software settings: Dynamic Zero: OFF or ON; Dynamic Span: OFF; Cal-on-NO₂: OFF; Dilution Factor: 1.0; AutoCal: ON or OFF; Independent Range: ON or OFF; AutoRange: ON or OFF; Temp/Pres Compensation: ON; and with or without any of the following options: Rack Mount with Slides, Rack Mount without Slides, Ears Only, Rack Mount for External Pump without Slide Tray, Stainless Steel Zero/Span Valves, 4-20 mA Isolated Outputs, Digital Status Outputs, or RS-232 Outputs. **Model 200A only:** operated at any temperature in the range of 5 EC to 40 EC, with either a user- or vendor-supplied vacuum pump capable of providing an absolute pressure no greater than 10 inches mercury at 1 slpm, Software setting Cal-on-NO₂: OFF, with or without optional Internal Zero/Span with Valves (IZS) and Permeation Tubes for IZS, gold-plated reaction chamber, or sample conditioner. **Model 200AU only:** operated at any temperature in the range of 20 EC to 30 EC, with either a user- or vendor-supplied vacuum pump capable of providing an absolute pressure no greater than 4 inches mercury at 1 slpm.

[Federal Register: Vol. 59, page 61892, 12/02/94]

Beckman Model 952-A NO/NO₂/NO_x AnalyzerAutomated Reference Method: **RFNA-0179-034**

"Beckman Model 952-A NO/NO₂/NO_x Analyzer," operated on the 0-0.5 ppm range with the 5-micron Teflon sample filter (Beckman P/N 861072 supplied with the analyzer) installed on the sample inlet line, with or without the Remote Operation Option (Beckman No. 635539).

[Federal Register: Vol. 44, page 7806, 02/07/79]

Bendix Model 8101-B Oxides of Nitrogen AnalyzerAutomated Reference Method: **RFNA-0479-038**

"Bendix Model 8101-B Oxides of Nitrogen Analyzer," operated on a 0-0.5 ppm range with a Teflon sample filter installed on the sample inlet line and with the following post-manufacture modifications: 1) Ozone generator and reaction chamber input-output tubing modification per Bendix Service Bulletin 8101B-2; 2) The approved converter material; 3) The revised and EPA-approved operation and service manual. These items are mandatory and must be obtained from ABB Process Analytics. The analyzer may be operated with or without any of the following optional modifications: a. Perma Pure dryer/ambient air modification; b. Valve cycle time modification; c. Zero potentiometer centering modification per Bendix Service Bulletin 8101B-1; d. Reaction chamber vacuum gauge modification.

[Federal Register: Vol. 44, page 26792, 05/07/79]

Bendix/Combustion Engineering Model 8101-C Oxides of Nitrogen AnalyzerAutomated Reference Method: **RFNA-0777-022**

"Bendix or Combustion Engineering Model 8101-C Oxides of Nitrogen Analyzer", operated on a 0-0.5 ppm range with a Teflon sample filter (Bendix P/N 007163) installed on the sample inlet line.

[Federal Register: Vol. 42, page 37435, 07/21/77]

Columbia Scientific Industries Models 1600 and 5600 AnalyzersAutomated Reference Method: **RFNA-0977-025**

"CSI Model 1600 Oxides of Nitrogen Analyzer," operated on a 0-0.5 ppm range with a Teflon sample filter (CSI P/N M951-8023) installed on the sample inlet line, with or without any of the following options:

951-0103 Rack Ears	951-0114 Recorder Output, 5 V
951-0104 Rack Mounting Kit (Ears & Slides)	951-0115 External Pump (115 V, 60 Hz)
951-0106 Current Output, 4-20 mA (Non-Insulated)	951-8072 Molybdenum Converter Assembly (Horizontal)
951-0108 Diagnostic Output Option	951-8074 Copper Converter Assembly (Horizontal)
951-0111 Recorder Output, 10 V	951-8079 Copper Converter Assembly (Vertical)
951-0112 Remote Zero/Span Sample Control	951-8085 Molybdenum Converter Assembly (Vertical)

NOTE: The vertical molybdenum converter assembly is standard on all new analyzers as of 1-1-87; however, use of any of the other converter assemblies is optional. Also, the above options reflect new CSI part numbers.

"CSI Model 5600 Oxides of Nitrogen Analyzer," operated on a 0-0.5 ppm range, with any signal integration time in the range of 20 to 99 seconds, with a Teflon sample filter (CSI P/N M951-8023) installed on the sample inlet line, and with or without any of the following options:

954-0121	Status Contacts	964-0126	Printer	954-0131	Rack Mounting Kit (ears and slides)
954-0122	Input Solenoids	954-8024	Cartridge Dryer	964-0012	Single Headed Pump - Gast
954-0125	Current Output, 4-20 mA			951-0115	Single Headed Pump - KNF

[Federal Register: Vol. 42, page 46574, 09/16/77]

Dasibi Model 2108 Oxides of Nitrogen Analyzer

Automated Reference Method: **RFNA-1192-089**

"Dasibi Model 2108 Oxides of Nitrogen Analyzer," operated on the 0-500 ppb range, with software revision 3.6 installed in the analyzer, with the auto thumbwheel switch and the diag thumbwheel switch settings at 0, with the following internal CPU dipswitch settings:

switch	position	function
1	open (down)	Recorder outputs are NO & NO ₂
5	open (down)	3 minute time constant
6	closed (up)	3 minute time constant;

with a 5-micron Teflon filter element installed in the filter holder, and with or without any of the following options:

Built-in Permeation Oven	Rack Mounting	Three-Channel Recorder Output
RS-232 Interface	4-20 mA Output	

[Federal Register: Vol. 57, page 55530, 11/25/92]

DKK Corporation Model GLN-114E Nitrogen Oxides Analyzer

Automated Reference Method: **RFNA-0798-121**

"DKK Corporation Model GLN-114E Nitrogen Oxides Analyzer," operated within a temperature range of 20 to 30 degrees C on any of the following measurement ranges: 0-0.050, 0-0.100, 0-0.200, 0-0.500, and 0-1.000 ppm

[Federal Register: Vol. 63, page 41253, 08/03/98]

Environnement S. A. Model AC31M NO Analyzer

Automated Reference Method: **RFNA-0795-104**

"Environnement S. A. Model AC31M Chemiluminescent Nitrogen Oxide Analyzer," operated with a full scale range of 0 - 500 ppb, at any temperature in the range of 15EC to 35EC, with a 5-micron PTFE sample particulate filter, with the following software settings: Automatic response time ON; Minimum response time set to 60 seconds (RT ÷ 2); and with or without any of the following options: ² Internal Permeation Oven; Connection for Silica Gel Dryer; RS232-422 interface; EV3 valve; Internal Printer.

[Federal Register: Vol. 60, page 38326, 07/26/95]

Horiba Instruments Model APNA-360 NO-NO₂-NO_x Monitor

Automated Reference Method: **RFNA-0196-111**

"Horiba Instruments, Inc. Model APNA-360 Ambient NO-NO₂-NO_x Monitor," operated with a full scale range of 0 - 0.50 or 0 - 1.0 ppm, at any temperature in the range of 10 EC to 40 EC, with a Line Setting of "MEASURE", and an Analog Output of "MOMENTARY VALUE", and with or without the following options:² 1) Rack Mounting Plate and Side Rails 2) RS-232 Communications Port

[Federal Register: Vol. 61, page 11404, 03/20/96]

Meloy Model NA530R Nitrogen Oxides Analyzer

Automated Reference Method: **RFNA-1078-031**

"Meloy Model NA530R Nitrogen Oxides Analyzer," operated on the following ranges and time constant switch positions:

Range, ppm:	0-0.1 ¹	0-0.25 ¹	0-0.5	0-1.0
Time Constant Setting:	4	3 or 4	2,3, or 4	2,3, or 4

Operation of the analyzer requires an external vacuum pump, either Meloy Option N-10 or an equivalent pump capable of maintaining a vacuum of 200 torr (22 inches mercury vacuum) or better at the pump connection at the specified sample and ozone-air flow rates of 1200 and 200 cm³/min, respectively. The analyzer may be operated at temperatures between 10EC and 40EC and at line voltages between 105 and 130 volts, with or without any of the following options: N-1A Automatic Zero And Span; N-2 Vacuum Gauge; N-4 Digital Panel Meter; N-6 Remote Control For Zero And Span; N-6B Remote Zero/Span Control And Status (Pulse); N-6C Remote Zero/Span Control And Status (Timer); N-9 Manual Zero/Span; N-10 Vacuum Pump Assembly (See Alternate Requirement Above); N-11 Auto Ranging; N-14B Line Transmitter; N-18 Rack Mount Conversion; N-18A Rack Mount Conversion

[Federal Register: Vol. 43, page 50733, 10/31/78 and Vol. 44, page 8327, 02/09/79]

Monitor Labs Model 8440E Nitrogen Oxides AnalyzerAutomated Reference Method: **RFNA-0677-021**

"Monitor Labs Model 8440E Nitrogen Oxides Analyzer," operated on a 0-0.5 ppm range (position 2 of range switch) with a ~~time constant~~ setting of 20 seconds, with or without any of the following options:

TF- Sample Particulate Filter DO- Status Outputs 018A- Ozone Dry Air 018B- Ozone Dry Air - No Drierite
With TFE Filter Element R- Rack Mount V- Zero/Span Valves FM- Flow meters

[Federal Register: Vol. 42, page 37434, 07/21/77; Vol. 42, page 46575, 09/16/77; Vol. 46, page 29986, 06/04/81]

Monitor Labs/Lear Siegler Model 8840 Nitrogen Oxides AnalyzerAutomated Reference Method: **RFNA-0280-042**

"Monitor Labs or Lear Siegler Model 8840 Nitrogen Oxides Analyzer," operated on a range of either 0-0.5 or 0-1.0 ppm, with an internal time constant setting of 60 seconds, a TFE sample filter installed on the sample inlet line, with or without any of the following options:

02 Flowmeter	08A Pump Pac Assembly With 09A (115 VAC)	011A Recorder Output 1 Volt
03A Rack Ears	08B Pump Pac Assembly With 09B (100 VAC)	011B Recorder Output 100 mV
03B Slides	08C Pump Pac Assembly With 09C (220/240 VAC)	011C Recorder Output 10 mV
05A Zero/Span Valves	08D Rack Mount Panel Assembly	012A DAS Output 1 Volt
05B Valve/Relay	09A Pump 115 VAC 50/60 Hz	012B DAS Output 100 mV
06 Status	09B Pump 100 VAC 50/60 Hz	012C DAS Output 10 mV
07A Input Power Transformer 100 VAC, 50/60 Hz	09C Pump 220/240 VAC 50 Hz	013A Ozone Dry Air
07B Input Power Transformer 220/240 VAC 50 Hz		013B Ozone Dry Air - No Drierite

[Federal Register: Vol. 45, page 9100, 02/11/80 and Vol. 46, page 29986, 06/04/81]

Monitor Labs/Lear Siegler Model 8841 Nitrogen Oxides AnalyzerAutomated Reference Method: **RFNA-0991-083**

"Monitor Labs or Lear Siegler Model 8841 Nitrogen Oxides Analyzer," operated on the 0-0.05 ppm¹, 0-0.1 ppm¹, 0-0.2 ppm¹, 0 - 0.5 ppm, or 0-1.0 ppm range, with manufacturer-supplied vacuum pump or alternative user-supplied vacuum pump capable of providing 200 torr or better absolute vacuum while operating with the analyzer.

[Federal Register: Vol. 56, page 47473, 9/19/91]

Monitor Labs/Lear Siegler Models ML9841 or ML9841A,Automated Reference Method: **RFNA-1292-090****Monitor Labs Model ML9841B, or Wedding & Associates Model 1030 NO₂ Analyzers**

"Lear Siegler Measurement Controls Corporation or Monitor Labs Models ML9841 or ML9841A, Monitor Labs Model ML9841B, or Wedding & Associates, Inc. Model 1030 Nitrogen Oxides Analyzers," operated on any full scale range between 0-0.05 ppm¹ and 0-1.0 ppm, at any temperature in the range of 15EC to 35EC, with the service switch on the secondary panel set to the *In* position; with the following menu choices selected: Range: *0.05 ppm to 1.0 ppm*; Over-ranging: *Enabled or Disabled*; Calibration: *Manual or Timed*; Diagnostic Mode: *Operate*; Filter Type: *Kalman*; Pres/Temp/Flow Comp: *On*; Span Comp: *Disabled*; and as follows: **Models ML9841 and ML9841A** - with a five-micron Teflon® filter element installed internally, with the 50-pin I/O board installed on the rear panel configured at any of the following output range setting: Voltage, 0.1 V, 1 V, 5 V, 10 V; Current, 0-20 mA, 2-20 mA, 4-20 mA; and with or without any of the following options: Valve Assembly for External Zero/Span (EVS); Internal Zero/Span (IZS) Assembly for; Rack Mount Assembly; Internal Floppy Disk Drive. **Models ML9841B and 1030** - with a vendor-supplied or equivalent user-supplied five-micron Teflon® filter and exhaust pump, and with or without any of the following options: Valve Assembly for External Zero/Span (EVS); 50-pin I/O board; Internal Zero/Span (IZS) Assembly; Rack Mount Assembly; Charcoal exhaust scrubber; hinged, fold-down front panel.

[Federal Register: Vol. 57, page 60198, 12/18/92]

Opsis Model AR 500 and System 300 Open Path Ambient AirAutomated Equivalent Method: **EQNA-0495-102****Monitoring Systems for NO₂**

"Opsis Model AR 500 System" or "System 300" Open Path (long path) Ambient Air Monitoring Systems, configured for measuring NO₂, with one detector and movable grating, operated with a measurement range of 0 to 0.5 ppm, an installed monitoring path length between 50 and 500 meters (or 50 and 1000 meters with the ER 150 option, AR 500 System only), xenon lamp type B (150 watt), fiber optic cable length between 3 and 20 meters; operating within an ambient air temperature range of -50 to +50EC, an analyzer temperature range of 20 to 30EC, a measurement (integrating) time setting between 30 and 120 seconds (0 min:30 sec. to 2 min:00 sec.), and with a complete cycle time of not more than 200 seconds (3 min, 20 sec.). Under this method designation, the Model AR 500 System or System 300 consists of: AR 500 opto-analyzer; emitter EM 110 and receiver RE 110 (together identified as ER 110); optic fibre cable OF60-S; power supply PS 150; OPSIS operational software, version 7.0 or 7.1; and initial on-site installation, setup, and limited operator training.²

Optional components that can be used with the Model AR 500 only, in addition to or as alternative to corresponding components listed above:

AR 503 opto-analyzer configured as Model AR 500 (only the center detector active, sequential monitoring)
Emitter/receiver ER 150 (for monitoring path lengths up to 1 kilometer)

Transceiver ER 130 and Retroreflector RE 090 with:
7 prisms (max. monitoring path length 150 meters) or
12 prisms (max. monitoring path length 250 meters)

Receiver RE 130
Xenon lamp type A (higher short-wavelength UV output)
Optic fibre cable OF60-R (low-loss for short wavelengths)
Multiplexers MX 004 and MX 024
Dataloggers DL 010 and DL 016
Analogue and digital input/output cards AO 008, AI 016, and DI 032
Analogue and digital isolation cards IA 008, ID 008, OA 008, and OD 008,
Window heaters HF 110 and HF 150

Mirror heaters HM 110 and HM 150

Auto calibration unit CU 007

Software packages IO 80 (for the analogue and digital input/output adapters), DL10 and DL16 (for data loggers), ComVision, and STAT 500;

Recommended calibration and accuracy audit components (or equivalent) for either Model AR 500 or System 300:

Wavelength calibration lamp CA 004

Calibration bench CB 100

Receiver unit RE 060 (two required)

Calibration unit CA 150, with same type lamp as used in the monitoring path emitter

Power supply PS 150 for calibration unit CA 150

Calibration cells CC 001-X, where X represents various cell lengths from 1 to 900 mm

Filter GG 400

Special calibration cells CC 110 or CC 150 (for mounting directly on receiver)

Light meter LM 010.

[Federal Register: Vol. 60, page 21518, 05/02/95]

Philips Model PW9762/02 NO/NO₂/NO_x Analyzer

Automated Reference Method: RFNA-0879-040

"Philips Model PW9762/02 NO/NO₂/NO_x Analyzer," consisting of the following components: PW9762/02 Basic Analyzer ; PW97900 Converter Cartridge; PW9731/00 Sampler or PW9731/20 Dust Filter; operated on a range of 0-0.5 ppm, with or without any of the following accessories: PW9752/00 Air Sampler Manifold; PW9732/00 Sample Line Heater; PW9011/00 Remote Control Set.

[Federal Register: Vol. 44, page 51683, 09/04/79]

Thermo Electron/Thermo Environmental Instruments Model 14 B/E

Automated Reference Method: RFNA-0179-035

"Thermo Electron or Thermo Environmental Instruments, Inc. Model 14 B/E Chemiluminescent NO/NO₂/NO_x Analyzer," operated on the 0-0.5 ppm range, with or without any of the following options:

14-001 Teflon Particulate Filter 14-003 Long-Time Signal Integrator

14-005 Sample Flowmeter

14-002 Voltage Divider Card 14-004 Indicating Temperature Controller

14-006 Air Filter

[Federal Register: Vol. 44, page 7805, 02/07/79 and Vol.44, page 54545, 09/20/79]

Thermo Electron/Thermo Environmental Instruments Model 14 D/E

Automated Reference Method: RFNA-0279-037

"Thermo Electron or Thermo Environmental Instruments, Inc. Model 14 D/E Chemiluminescent NO/NO₂/NO_x Analyzer," operated on the 0-0.5 ppm range, with or without any of the following options: 14-001 Teflon Particulate Filter; 14-002 Voltage Divider Card.

[Federal Register: Vol. 44, page 10429, 02/20/79]

Thermo Environmental Instruments Models 42, 42C NO/NO₂/NO_x Analyzer

Automated Reference Method: RFNA-1289-074

"Thermo Environmental Instruments Inc. Model 42 or Model 42C NO-NO₂-NO_x Analyzer," operated on any measurement range between 0-50 ppb¹ and 0-1000 ppb, with any time average setting from 10 to 300 seconds, with temperature and/or pressure compensation on or off, operated at temperatures between 15 EC and 35 EC, with or without any of the following options: ²

42-002 Rack mounts

42-006 Pressure transducer (Model 42 only)

42-003 Internal Zero/span and sample valves with remote activation

42-007 Ozone particulate filter

42-004 Sample/ozone flow meters (Model 42 only)

42-008 RS-232/485 interface

42-005 4-20 mA current output

42-009 Permeation dryer

[Federal Register: Vol. 54, page 50820, 12/11/89]

LEAD

Reference Method for Lead

Manual Reference Method: 40 CFR Part 50, Appendix G

Reference Method for the Determination of Lead in Suspended Particulate Matter Collected from Ambient Air.

[Federal Register: Vol. 43, page 46258, 10/05/78]

Energy-Dispersive X-Ray Fluorescence Spectrometry (TNRCC)

Manual Equivalent Method: EQL-0783-058

"Determination of Lead Concentration in Ambient Particulate Matter by Energy-Dispersive X-Ray Fluorescence Spectrometry (Texas Natural Resource Conservation Commission)" Texas Natural Resource Conservation Commission, P.O. Box 13087, Austin, TX 78711-3087.

[Federal Register: Vol. 48, page 29742, 06/28/83]

Energy-Dispersive X-Ray Fluorescence Spectrometry (NEA, Inc.)

Manual Equivalent Method: EQL-0589-072

"Determination of Lead Concentration in Ambient Particulate Matter by Energy-Dispersive X-Ray Fluorescence Spectrometry (NEA, Inc.)" Nuclear Environmental Analysis, Inc., Suite 260, 10950 SW 5th Street, Beaverton, OR 97005.

[Federal Register: Vol. 54, page 20193, 05/10/89]

Flame Atomic Absorption Spectrometry

Manual Equivalent Method: EQL-0380-043

"Determination of Lead Concentration in Ambient Particulate Matter by Flame Atomic Absorption Spectrometry Following Ultrasonic Extraction with Heated HNO₃-HCl"

Federal Register: Vol. 45, page 14648, 03/06/80]

Flameless Atomic Absorption Spectrometry (EPA/RTP, N.C.)

"Determination of Lead Concentration in Ambient Particulate Matter by Flameless Atomic Absorption Spectrometry (EPA/RTP, N.C.)"

Manual Equivalent Method: **EQL-0380-044**

[Federal Register: Vol. 45, page 14648, 03/06/80]

Flameless (Graphite Furnace) Atomic Absorption (Houston, Texas)

"Determination of Lead Concentration in Ambient Particulate Matter by Flameless (Graphite Furnace) Atomic Absorption (City of Houston, Texas)." Health and Human Services Department, Environmental Chemistry Service, 1115 S. Braeswood, Houston, TX 77030.

Manual Equivalent Method: **EQL-0895-107**

[Federal Register: Vol. 60, page 39383, 08/02/95]

Flameless Atomic Absorption Spectrometry (Omaha)

"Determination of Lead Concentration in Ambient Particulate Matter by Flameless Atomic Absorption Spectrometry (Omaha-Douglas County Health Department)" Omaha-Douglas County Health Department, 1819 Farnam Street, Omaha, NE 68183

Manual Equivalent Method: **EQL-0785-059**

[Federal Register: Vol. 50, page 37909, 09/18/85]

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (Doe Run)

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (Doe Run Co.)" Doe Run Company, Smelting Division, 881 Main Street Herculaneum, MO 63048

Manual Equivalent Method: **EQL-0196-113**

[Federal Register: Vol. 61, page 11404, 03/20/96]

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (EPA/RTP)

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (EPA/RTP, N.C.)"

Manual Equivalent Method: **EQL-0380-045**

[Federal Register: Vol. 45, page 14648, 03/06/80]

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (IL)

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (State of Illinois)." State of Illinois, Environmental Protection Agency, Champaign Inorganic Laboratory, 2120 South First Street, Champaign, IL 61820

Manual Equivalent Method: **EQL-1193-094**

[Federal Register: Vol. 58, page 61902, 11/23/93]

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (Kansas)

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (State of Kansas)" State of Kansas, Department of Health and Environment, Forbes Field, Building 740, Topeka, KS 66620-0001.

Manual Equivalent Method: **EQL-0592-085**

[Federal Register: Vol. 57, page 20823, 05/15/92]

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (Montana)

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (State of Montana)." State of Montana, Department of Health and Environmental Sciences, Cogswell Building, Helena, MT 59620.

Manual Equivalent Method: **EQL-0483-057**

[Federal Register: Vol. 48, page 14748, 04/05/83]

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (NETI)

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (Northern Engineering and Testing, Inc.)" Northern Engineering and Testing, Inc., P.O. Box 30615, Billings, MT 59107.

Manual Equivalent Method: **EQL-1188-069**

[Federal Register: Vol. 53, page 44947, 11/07/88]

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (NH)

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (State of New Hampshire)" State of New Hampshire, Department of Environmental Services, Laboratory Service Unit, 6 Hazen Drive (P.O. Box 95), Concord, NH 03302-0095.

Manual Equivalent Method: **EQL-1290-080**

[Federal Register: Vol. 55, page 49119, 11/26/90]

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (PA)

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (Commonwealth of Pennsylvania)" Commonwealth of Pennsylvania, Department of Environmental Resources, P.O. Box 2357, Harrisburg, PA 17105-2357.

Manual Equivalent Method: **EQL-0592-086**

[Federal Register: Vol. 57, page 20823, 05/15/92]

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (Pima, AZ)

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (Pima County, Arizona)." Pima County, Wastewater Management Department, 201 North Stone Avenue, Tucson, Arizona 85701-1207.

Manual Equivalent Method: **EQL-0995-109**

[Federal Register: Vol. 60, page 54684, 10/25/95]

Inductively Coupled Argon Plasma-Mass Spectrometry (Pima Co., AZ)

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Plasma-Mass Spectrometry (Pima County, Arizona)." Pima County, Wastewater Management Department, 201 North Stone Avenue, Tucson, Arizona 85701-1207.

Manual Equivalent Method: **EQL-0995-110**

[Federal Register: Vol. 60, page 54684, 10/25/95]

LEAD

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (RI)

Manual Equivalent Method: **EQL-0888-068**

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (State of Rhode Island)," State of Rhode Island Department of Health, Air Pollution Laboratory, 50 Orms Street, Providence, RI 02904

[Federal Register: Vol. 53, page 30866, 08/16/88]

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (Silver Valley)

Manual Equivalent Method: **EQL-1288-070**

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (Silver Valley Laboratories)" Silver Valley Laboratories, Inc., P.O. Box 929, Kellogg, ID 83837.

[Federal Register: Vol. 53, page 48974, 12/05/88]

Inductively Coupled Argon Plasma-Optical Emission Spectrometry (WV)

Manual Equivalent Method: **EQL-0694-096**

"Determination of Lead Concentration in Ambient Particulate Matter by Inductively Coupled Argon Plasma-Optical Emission Spectrometry (State of West Virginia)." State of West Virginia, Department of Commerce, Labor and Environmental Resources, Division of Environmental Protection, 1558 Washington Street East, Charleston, WV 25311-2599

[Federal Register: Vol. 59, page 29429, 06/07/94]

Wavelength Dispersive X-Ray Fluorescence Spectrometry (CA)

Manual Equivalent Method: **EQL-0581-052**

"Determination of Lead Concentration in Ambient Particulate Matter by Wavelength Dispersive X-Ray Fluorescence Spectrometry" California Department of Health Services, Air & Industrial Hygiene Laboratory, 2151 Berkeley Way, Berkeley, CA 94704.

[Federal Register: Vol. 46, page 29986, 06/04/81]

NOTES

¹ Users should be aware that designation of this analyzer for operation on ranges less than the range specified in the performance specifications for this analyzer (40 CFR 53, Subpart B) is based on meeting the same absolute performance specifications required for the specified range. Thus, designation of these lower ranges does not imply commensurably better performance than that obtained on the specified range.

² This analyzer is approved for use, with proper factory configuration, on either 50 or 60 Hertz line frequency and nominal power line voltages of 115 Vac and 220 Vac.

Sources or Contacts for Designated Reference and Equivalent Methods

ABB Process Analytics
P.O. Box 831
Lewisburg, WV 24901
(304) 647-4358

Advanced Pollution
Instrumentation, Inc.
6565 Nancy Ridge Drive
San Diego, CA 92121-2251
(619) 657-9800

Andersen Instruments
500 Technology Court
Smyrna, GA 30082-9211
(800) 241-6898

ASARCO Incorporated
3422 South 700 West
Salt Lake City, UT 84119
(801) 262-2459

Beckman Instruments, Inc.
Process Instruments Division
2500 Harbor Blvd.
Fullerton, CA 92634
(714) 871-4848

Bendix
[Refer to ABB Process Analytics]

BGI Incorporated
58 Guinan Street
Waltham, MA 02154

Columbia Scientific Industries
11950 Jollyville Road
Austin, TX 78759
(800) 531-5003

Combustion Engineering
[Refer to ABB Process Analytics]

Dasibi Environmental Corp.
506 Paula Avenue
Glendale, CA 91201
(818) 247-7601

DKK Corporation
4-13-14 Kichijoji Kitamachi,
Musashino-shi
Tokyo, 180, Japan

Environnement S.A
111, bd Robespierre
78300 Poissy, France
Instruments also available from:
Altech/Environnement U.S.A.
2623 Kaneville Court
Geneva, IL 60134
(630) 262- 4400
rbrown@altechusa.com

Envionics, Inc.
69 Industrial Park Rd. E.
Tolland, CT 06084-2805
(203) 429-0077

Graseby GMW
[Refer to Andersen Instruments]

Horiba Instruments Incorporated
17671 Armstrong Avenue
Irvine, CA 92714
(800) 446-7422

Lear Siegler
[Refer to Monitor Labs, Inc.]

Commonwealth of Massachusetts
Department of Environmental
Quality Engineering
Tewksbury, MA 01876

Met One Instruments, Inc.
1600 Washington Blvd.
Grants Pass, OR 97526
(541) 471-7111
metone@metone.com

McMillan
[Refer to Columbia Scientific Industries]

Mine Safety Appliances
600 Penn Center Blvd.
Pittsburgh, PA 15235-5810
(412) 273-5101

Monitor Labs, Inc.
74 Inverness Drive
Englewood, CO 80112-5189
(800) 422-1499

Opsis AB, Furulund, Sweden
Instruments also available from:
Opsis, Inc.
146-148 Sound Beach Avenue
Old Greenwich, CT 06870
(203) 698-1810

State of Oregon
Department of Environmental Quality
Air Quality Division
811 S.W. Sixth Avenue
Portland, OR 97204

PCI Ozone Corp.
One Fairfield Crescent
West Caldwell, NJ 07006
(201) 575-7052

Phillips Electronic Instruments, Inc.
85 McKee Drive
Mahwah, NJ 07430

Rupprecht & Patashnik Co., Inc.
25 Corporate Circle
Albany, NY 12203
(518) 452-0065

Sibata Scientific Technology, Ltd.
1-25, 3-chome
Ikenohata, Taito-ku
Tokyo 110, Japan
81-3(3822)2272
TTani@email.msn.com

Thermo Environmental Instruments,
Inc.
8 West Forge Parkway
Franklin, MA 02038
(508) 520-0430

U.S. EPA
National Exposure Research Laboratory
Human Exposure & Atmospheric
Sciences Division
MD-46
Research Triangle Park, NC 27711
(919) 541- 2622

Wedding and Associates, Inc.
[Refer to Thermo Environmental
Instruments, Inc.]

U.S. EPA REFERENCE & EQUIVALENT METHODS FOR AMBIENT AIR

March 17, 2000

<u>Method</u>	<u>Designation Number</u>	<u>Method Code</u>	<u>Method</u>	<u>Designation Number</u>	<u>Method Code</u>
<u>SO₂ Manual Methods</u>					
Reference method (pararosaniline)	--	097	Horiba APNA-360	RFNA-0196-111	111
Technicon I (pararosaniline)	EQS-0775-001	097	Lear Siegler or Monitor Labs ML9841, ML9841A, Monitor Labs ML9841B, Wedding 1030	RFNA-1292-090	090
Technicon II (pararosaniline)	EQS-0775-002	097	Meloy NA530R Monitor Labs 8440E	RFNA-1078-031	031
				RFNA-0677-021	021
<u>SO₂ Analyzers</u>			Monitor Labs or Lear Siegler 8840	RFNA-0280-042	042
Advanced Pollution Instr. 100	EQSA-0990-077	077	Monitor Labs or Lear Siegler 8841	RFNA-0991-083	083
Advanced Pollution Instr. 100A	EQSA-0495-100	100	Opsis AR 500, System 300 (open path)	EQNA-0495-102	102
Asarco 500	EQSA-0877-024	024	Philips PW9762/02	RFNA-0879-040	040
Beckman 953	EQSA-0678-029	029	Thermo Electron or Thermo Environmental Instruments 14B/E	RFNA-0179-035	035
Bendix 8303	EQSA-1078-030	030	Thermo Electron or Thermo Environmental Instruments 14D/E	RFNA-0279-037	037
Columbia Scientific Industries 5700	EQSA-0494-095	095	Thermo Environmental Instr. 42, 42C	RFNA-1289-074	074
Dasibi 4108	EQSA-1086-061	061			
DKK Corp. Model GFS-32	EQSA-0701-115	115	<u>Pb Manual Methods</u>		
DKK Corp. Model GFS-112E	EQSA-0100-133	133	Reference method (hi-vol/AA spect.)	--	803
Environnement S.A. AF21M	EQSA-0292-084	084	Hi-vol/AA spect. (alt. extr.)	EQL-0380-043	043
Horiba Model APSA-360/APSA-360ACE	EQSA-0197-114	114	Hi-vol/Energy-disp XRF (TX ACB)	EQL-0783-058	058
Lear Siegler AM2020	EQSA-1280-049	049	Hi-vol/Energy-disp XRF (NEA)	EQL-0589-072	072
Lear Siegler SM1000	EQSA-1275-005	005	Hi-vol/Flameless AA (EMSL/EPA)	EQL-0380-044	044
Lear Siegler or Monitor Labs ML9850, Monitor Labs ML9850B, Wedding 1040	EQSA-0193-092	092	Hi-vol/Flameless AA (Houston)	EQL-0895-107	107
Meloy SA185-2A	EQSA-1275-006	006	Hi-vol/Flameless AA (Omaha)	EQL-0785-059	059
Meloy SA285E	EQSA-1078-032	032	Hi-vol/ICAP spect. (Doe Run Co.)	EQL-0196-113	113
Meloy SA700	EQSA-0580-046	046	Hi-vol/ICAP spect. (EMSL/EPA)	EQL-0380-045	045
Monitor Labs 8450	EQSA-0876-013	513	Hi-vol/ICAP spect. (Illinois)	EQL-1193-094	094
Monitor Labs or Lear Siegler 8850	EQSA-0779-039	039	Hi-vol/ICAP spect. (Kansas)	EQL-0592-085	085
Monitor Labs or Lear Siegler 8850S	EQSA-0390-075	075	Hi-vol/ICAP spect. (Montana)	EQL-0483-057	057
Opsis AR 500, System 300 (open path)	EQSA-0495-101	101	Hi-vol/ICAP spect. (NE&T)	EQL-1188-069	069
Philips PW9700	EQSA-0876-011	511	Hi-vol/ICAP spect. (New Hampshire)	EQL-1290-080	080
Philips PW9755	EQSA-0676-010	010	Hi-vol/ICAP spect. (Pennsylvania)	EQL-0592-086	086
Thermo Electron 43	EQSA-0276-009	009	Hi-vol/ICAP spect. (Pima Co., AZ)	EQL-0995-109	109
Thermo Electron 43A or Thermo Environmental Instruments 43B, 43C	EQSA-0486-060	060	Hi-vol/ICAP spect. (Pima Co., AZ)	EQL-0995-110	110
			Hi-vol/ICAP spect. (Rhode Island)	EQL-0888-068	068
<u>O₃ Analyzers</u>			Hi-vol/ICAP spect. (Silver Val. Labs)	EQL-1288-070	070
Advanced Pollution Instr. 400/400A	EQOA-0992-087	087	Hi-vol/ICAP spect. (West Virginia)	EQL-0694-096	096
Beckman 950A	RFOA-0577-020	020	Hi-vol/WL-disp. XRF (CA A&IHL)	EQL-0581-052	052
Bendix 8002	RFOA-0176-007	007			
Columbia Scientific Industries 2000	RFOA-0279-036	036	<u>PM₁₀ Samplers</u>		
Dasibi 1003-AH, -PC, -RS	EQOA-0577-019	019	Andersen Instruments, RAAS10-100	RFPS-0699-130	130
Dasibi 1008-AH	EQOA-0383-056	056	Andersen Instruments, RAAS10-200	RFPS-0699-131	131
DKK Corp. Model GUX-113E	EQOA-0200-134	134	Andersen Instruments, RAAS10-300	RFPS-0699-132	132
Envirotronics 300	EQOA-0990-078	078	BGI Model PQ100	RFPS-1298-124	124
Environnement S.A. O ₃ 41M	EQOA-0895-105	105	BGI Model PQ200	RFPS-1298-125	125
Horiba APOA-360	EQOA-0196-112	112	Oregon DEQ Medium volume sampler	RFPS-0389-071	071
Lear Siegler or Monitor Labs ML9810, Monitor Labs ML9810B, Wedding 1010	EQOA-0193-091	091	Rupprecht & Patashnick Partisol 2000	RFPS-0694-098	098
McMillan 1100-1	RFOA-1076-014	514	R & P Partisol-FRM Model 2000	RFPS-1298-126	126
McMillan 1100-2	RFOA-1076-015	515	R & P Partisol-Plus Model 2025 Seq.	RFPS-1298-127	127
McMillan 1100-3	RFOA-1076-016	016	Sierra-Andersen/GMW 1200	RFPS-1287-063	063
Meloy OA325-2R	RFOA-1075-003	003	Sierra-Andersen/GMW 321-B	RFPS-1287-064	064
Meloy OA350-2R	RFOA-1075-004	004	Sierra-Andersen/GMW 321-C	RFPS-1287-065	065
Monitor Labs 8410E	RFOA-1176-017	017	Sierra-Andersen/GMW 241 Dichot.	RFPS-0789-073	073
Monitor Labs or Lear Siegler 8810	EQOA-0881-053	053	W&A/Thermo Electron Mod 600 HVL	RFPS-1087-062	062
Opsis AR 500, System 300 (open path)	EQOA-0495-103	103			
PCI Ozone Corp. LC-12	EQOA-0382-055	055	<u>PM₁₀ Analyzers</u>		
Philips PW9771	EQOA-0777-023	023	Andersen Instruments Beta FH62I-N	EQPM-0990-076	076
Thermo Electron or Thermo Environmental Instruments 49, 49C	EQOA-0880-047	047	Met One BAM1020, GBAM1020, BAM1020-1, GBAM1020-1	EQPM-0798-122	122
			R & P TEOM 1400, 1400a	EQPM-1090-079	079
			W&A/Thermo Electron 650 Beta Gauge	EQPM-0391-081	081
<u>CO Analyzers</u>					
Advanced Pollution Instr. 300	RFCA-1093-093	093	<u>PM_{2.5} Samplers</u>		
Beckman 866	RFCA-0876-012	012	Andersen Model RAAS2.5-200 Audit	RFPS-0299-128	128
Bendix 8501-5CA	RFCA-0276-008	008	BGI PQ200/200A	RFPS-0498-116	116
Dasibi 3003	RFCA-0381-051	051	Graseby Andersen RAAS2.5-100	RFPS-0598-119	119
Dasibi 3008	RFCA-0488-067	067	Graseby Andersen RAAS2.5-300	RFPS-0598-120	120
Environnement s.a. CO11M	RFCA-0995-108	108	R & P Partisol-FRM 2000	RFPS-0498-117	117
Horiba AQM-10, -11, -12	RFCA-1278-033	033	R & P Partisol-Plus 2025	RFPS-0498-118	118
Horiba 300E/300SE	RFCA-1180-048	048	Thermo Env'r Model 605 CAPS	RFPS-1098-123	123
Horiba APMA-360	RFCA-0895-106	106	R & P Partisol 2000 Audit	RFPS-0499-129	129
Lear Siegler or Monitor Labs ML9830, Monitor Labs ML9830B, Wedding 1020	RFCA-0992-088	088			
MASS - CO 1 (Massachusetts)	RFCA-1280-050	050	<u>TSP Manual Method</u>		
Monitor Labs 8310	RFCA-0979-041	041	Reference method (high-volume)	--	802
Monitor Labs or Lear Siegler 8830	RFCA-0388-066	066			
MSA 202S	RFCA-0177-018	018			
Thermo Electron or Thermo Environmental Instruments 48, 48C	RFCA-0981-054	054			
<u>NO₂ Manual Methods</u>					
Sodium arsenite (orifice)	EQN-1277-026	084			
Sodium arsenite/Technicon II	EQN-1277-027	084			
TGS-ANSA (orifice)	EQN-1277-028	098			
<u>NO₂ Analyzers</u>					
Advanced Pollution Instr. 200	RFNA-0691-082	082			
Advanced Pollution Instr. 200A	RFNA-1194-099	099			
Beckman 952A	RFNA-0179-034	034			
Bendix 8101-B	RFNA-0479-038	038			
Bendix 8101-C	RFNA-0777-022	022			
Columbia Scientific Indust. 1600, 5600	RFNA-0977-025	025			
Dasibi 2108	RFNA-1192-089	089			
DKK Corp GLN-114E	RFNA-0798-121	121			
Environnement S.A. AC31M	RFNA-0795-104	104			