



UNITED STATES ENVIRONMENTAL PROTECTION AGENCY

NATIONAL EXPOSURE RESEARCH LABORATORY

HUMAN EXPOSURE & ATMOSPHERIC SCIENCES DIVISION (MD-D205-03)

Research Triangle Park, NC 27711

919-541-3737

Office of
Research and Development

LIST OF DESIGNATED REFERENCE AND EQUIVALENT METHODS

Issue Date: September 12, 2002

(www.epa.gov/ttn/amtic/criteria.html)

These methods for measuring ambient concentrations of specified air pollutants have been designated as "reference methods" or "equivalent methods" in accordance with Title 40, Part 53 of the Code of Federal Regulations (40 CFR Part 53). Subject to any limitations (e.g., operating range or temperature range) specified in the applicable designation, each method is acceptable for use in state or local air quality surveillance systems under 40 CFR Part 58 unless the applicable designation is subsequently canceled. Automated methods for pollutants other than PM₁₀ are acceptable for use only at shelter temperatures between 20°C and 30°C and line voltages between 105 and 125 volts unless wider limits are specified in the method description.

Prospective users of the methods listed should note (1) that each method must be used in strict accordance with its associated operation or instruction manual and with applicable quality assurance procedures, and (2) that modification of a method by its vendor or user may cause the pertinent designation to be inapplicable to the method as modified. (See Section 2.8 of Appendix C, 40 CFR Part 58 for approval of modifications to any of these methods by users.)

Further information concerning particular designations may be found in the *Federal Register* notice cited for each method or by writing to the National Exposure Research Laboratory, Human Exposure and Atmospheric Sciences Division (MD-46), U.S. Environmental Protection Agency, Research Triangle Park, North Carolina 27711. Technical information concerning the methods should be obtained by contacting the source listed for each method. Source addresses are listed at the end of the listing of methods, except for the addresses for lead method sources, which are given with the method. New analyzers or PM₁₀ samplers sold as reference or equivalent methods must carry a label or sticker identifying them as designated methods. For analyzers or PM₁₀ samplers sold prior to the designation of a method with the same or similar model number, the model number does not necessarily identify an analyzer or sampler as a designated method. Consult the manufacturer or seller to determine if a previously sold analyzer or sampler can be considered a designated method or if it can be upgraded to designation status. Analyzer users who experience operational or other difficulties with a designated analyzer or sampler and are unable to resolve the problem directly with the instrument manufacturer may contact EPA (preferably in writing) at the above address for assistance.

This list will be revised as necessary to reflect any new designations or any cancellation of a designation currently in effect. The most current revision of the list will be available for inspection at EPA's Regional Offices, and copies may be obtained at the Internet site identified above or by writing to the National Exposure Research Laboratory at the address specified above.

Most Recent Designations

Tisch Environmental Model TE-6070 PM ₁₀ High Volume Sampler	April 02, 2002
BGI Models PQ200-VSCC and PQ200A-VSCC PM _{2.5} Sampler	April 02, 2002
R & P Partisol®-FRM Model 2000 PM-2.5 FEM PM _{2.5} Sampler	April 02, 2002
R & P Partisol® Model 2000 PM-2.5 FEM PM _{2.5} Audit Sampler	April 02, 2002
R & P Partisol®-Plus Model 2025 PM-2.5 FEM PM _{2.5} Seq. Sampler	April 02, 2002
Environnement S.A Model AC32M Nitrogen Oxides Analyzer	April 02, 2002
Environnement S.A Model CO12M Carbon Monoxide Analyzer	June 24, 2002
Environnement S.A Model O ₃ 42M Ozone Analyzer	June 24, 2002
Environnement S.A Model AF22M Sulfur Dioxide Analyzer	Sept. 12, 2002
Teledyne - Advanced Pollution Instrumentation Model 400E O ₃ Analyzer	Sept. 12, 2002

NITROGEN DIOXIDE**Sodium Arsenite Method for NO₂***Manual Equivalent Method: EQN-1277-026*

"Sodium Arsenite Method for the Determination of Nitrogen Dioxide in the Atmosphere."

[*Federal Register: Vol. 42, page 62971, 12/14/77*]**Sodium Arsenite Method for NO₂ - Technicon II***Manual Equivalent Method: EQN-1277-027*

"Sodium Arsenite Method for the Determination of Nitrogen Dioxide in the Atmosphere-Technicon II Automated Analysis System."

[*Federal Register: Vol. 42, page 62971, 12/14/77*]**TGS-ANSA Method for NO₂***Manual Equivalent Method: EQN-1277-028*

"TGS-ANSA Method for the Determination of Nitrogen Dioxide in the Atmosphere."

[*Federal Register: Vol. 42, page 62971, 12/14/77*]**Advanced Pollution Instrumentation, Inc. Model 200 NO₂ Analyzer***Automated Reference Method: RFNA-0691-082*

"AdvancedPollutionInstrumentation, Inc. Model 200 Nitrogen Oxides Analyzer,"operated on a range of either 0-0.5 or 0-1.0 ppm, with a 5-micron TFE filter element installed in the rear-panel filter assembly, with either a user- or vendor-supplied vacuum pump capable of providing 5 inches mercury absolute pressure at 5 slpm, with either a user- or vendor-supplied dry air source capable of providing air at a dew point of 0°C or lower, with the following settings of the adjustable setup variables:

Adaptive Filter = *On*

PMT Temperature Set Point = 15°C

Normal Filter Size = 12 samples

Dwell Time = 7 seconds

Rate of Change(ROC) Threshold = 10%

Dynamic Span = Off

Sample Time = 8 seconds

Reaction Cell Temperature = 50°C

Dynamic Zero = Off

and with or without any of the following options:

180 Stainless Steel Valves

283 Internal Zero/Span With Valves (IZS)

356 Level One Spares Kit

184 Pump Pack

325 RS-232/Status Output

357 Level Two Spares Kit

280 Rack Mount With Slides

355 Expendables

PE5 Permeation Tube for IZS

[*Federal Register: Vol. 56, page 27014, 06/12/91*]**Advanced Pollution Instrumentation, Inc. Models 200A/200AU or****Teledyne Analytical Instruments Model 9110A NO₂ Analyzers***Automated Reference Method: RFNA-1194-099*

"AdvancedPollutionInstrumentation, Inc. Models 200A and 200AU or Teledyne Analytical Instruments Model 9110ANitrogenOxides Analyzers,"operated on any full scale range between 0-0.05 ppm and 0-1.0 ppm, withthe either a 1 or 5-micron TFE filter element installed in the filter assembly, withthe following software settings: Dynamic Zero: OFF or ON; Dynamic Span: OFF; Cal-on-NO₂: OFF; Dilution Factor: 1.0; AutoCal: ON or OFF; Independent Range: ON or OFF; AutoRange: ON or OFF; Temp/Pres Compensation: ON; and with or without any of the following options: Rack Mount with Slides, Rack Mount without Slides, Ears Only, Rack Mount for External Pump without Slide Tray, Stainless Steel Zero/Span Valves, 4-20 mA Isolated Outputs, Digital Status Outputs, or RS-232 Outputs. **Model 200A only:** operated at any temperature in the range of 5 °C to 40 °C, with either a user- or vendor-supplied vacuum pump capable of providing an absolute pressure no greater than 10 inches mercury at 1 slpm, Software setting Cal-on-NO₂: OFF, withor without optional Internal Zero/Span with Valves (IZS) and Permeation Tubes for IZS, gold-plated reaction chamber, or sample conditioner. **Model 200AU only:** operated at any temperature in the range of 20 °C to 30 °C, with either a user- or vendor-supplied vacuum pump capable of providing an absolute pressure no greater than 4 inches mercury at 1 slpm.

[*Federal Register: Vol. 59, page 61892,12/02/94*]**Beckman Model 952-A NO/NO₂/NO_x Analyzer***Automated Reference Method: RFNA-0179-034*

"Beckman Model 952-A NO/NO₂/NO_x Analyzer,"operated on the 0-0.5 ppm range with the 5-micron Teflon sample filter (Beckman P/N 861072 supplied with the analyzer) installed on the sample inlet line, with or without the Remote Operation Option (Beckman No. 635539).

[*Federal Register: Vol. 44, page 7806, 02/07/79*]**Bendix Model 8101-B Oxides of Nitrogen Analyzer***Automated Reference Method: RFNA-0479-038*

"Bendix Model 8101-B Oxides of NitrogenAnalyzer,"operated on a 0-0.5 ppm range with a Teflon sample filter installed on the sample inlet line and with the following post-manufacture modifications: 1) Ozone generator and reaction chamber input-output tubing modification per Bendix Service Bulletin 8101B-2; 2) The approved converter material; 3) The revised and EPA-approved operation and service manual. These items are mandatory and must be obtained from ABB Process Analytics. The analyzer may be operated with or without any of the following optional modifications: a. Perma Pure dryer/ambient air modification; b. Valve cycle time

modification; c. Zero potentiometer centering modification per Bendix Service Bulletin 8101B-1; d. Reaction chamber vacuum gauge modification.

[*Federal Register*: Vol. 44, page 26792, 05/07/79]

Bendix/Combustion Engineering Model 8101-C Oxides of Nitrogen Analyzer *Automated Reference Method: RFNA-0777-022*

"Bendix or Combustion Engineering Model 8101-C Oxides of Nitrogen Analyzer," operated on a 0-0.5 ppm range with a Teflon sample filter (Bendix P/N 007163) installed on the sample inlet line.

[*Federal Register*: Vol. 42, page 37435, 07/21/77]

Columbia Scientific Industries Models 1600 and 5600 Analyzers*Automated Reference Method: RFNA-0977-025*

"CSI Model 1600 Oxides of Nitrogen Analyzer," operated on a 0-0.5 ppm range with a Teflon sample filter (CSI P/N M951-8023) installed on the sample inlet line, with or without any of the following options:

951-0103 Rack Ears	951-0114 Recorder Output, 5 V
951-0104 Rack Mounting Kit (Ears & Slides)	951-0115 External Pump (115 V, 60 Hz)
951-0106 Current Output, 4-20 mA (Non-Insulated)	951-8072 Molybdenum Converter Assembly (Horizontal)
951-0108 Diagnostic Output Option	951-8074 Copper Converter Assembly (Horizontal)
951-0111 Recorder Output, 10 V	951-8079 Copper Converter Assembly (Vertical)
951-0112 Remote Zero/Span Sample Control	951-8085 Molybdenum Converter Assembly (Vertical)

NOTE: The vertical molybdenum converter assembly is standard on all new analyzers as of 1-1-87; however, use of any of the other converter assemblies is optional. Also, the above options reflect new CSI part numbers.

"CSI Model 5600 Oxides of Nitrogen Analyzer," operated on a 0-0.5 ppm range, with any signal integration time in the range of 20 to 99 seconds, with a Teflon sample filter (CSI P/N M951-8023) installed on the sample inlet line, and with or without any of the following options:

954-0121 Status Contacts	964-0126 Printer	954-0131 Rack Mounting Kit (ears and slides)
954-0122 Input Solenoids	954-8024 Cartridge Dryer	964-0012 Single Headed Pump - Gast
954-0125 Current Output, 4-20 mA	951-0115 Single Headed Pump - KNF	

[*Federal Register*: Vol. 42, page 46574, 09/16/77]

Dasibi Model 2108 Oxides of Nitrogen Analyzer*Automated Reference Method: RFNA-1192-089*

"Dasibi Model 2108 Oxides of Nitrogen Analyzer," operated on the 0-500 ppb range, with software revision 3.6 installed in the analyzer, with the auto thumbwheel switch and the diag thumbwheel switch settings at 0, with the following internal CPU dipswitch settings:

<u>switch</u>	<u>position</u>	<u>function</u>
1	open (down)	Recorder outputs are NO & NO ₂
5	open (down)	3 minute time constant
6	closed (up)	3 minute time constant;

with a 5-micron Teflon filter element installed in the filter holder, and with or without any of the following options:

Built-in Permeation Oven	Rack Mounting	Three-Channel Recorder Output
RS-232 Interface	4-20 mA Output	

[*Federal Register*: Vol. 57, page 55530, 11/25/92]

DKK-TOA Corporation Model GLN-114E Nitrogen Oxides Analyzer*Automated Reference Method: RFNA-0798-121*

"DKK-TOA Corporation Model GLN-114E Nitrogen Oxides Analyzer," operated within a temperature range of 20 to 30 degrees C, on any of the following measurement ranges: 0-0.050¹, 0-0.100¹, 0-0.200¹, 0-0.500, and 0-1.000 ppm, and with or without the optional Internal zero air supply and permeation tube oven.²

[*Federal Register*: Vol. 63, page 41253, 08/03/98]

Environnement S. A. Model AC31M NO₂ Analyzer*Automated Reference Method: RFNA-0795-104*

"Environnement S. A. Model AC31M Chemiluminescent Nitrogen Oxide Analyzer," operated with a full scale range of 0 - 500 ppb, at any temperature in the range of 15°C to 35°C, with a 5-micron PTFE sample particulate filter, with the following software settings: Automatic response time ON; Minimum response time set to 60 seconds (RT ÷ 2); and with or without any of the following options:² Internal Permeation Oven; Connection for Silica Gel Dryer; RS232-422 interface; EV3 valve; Internal Printer.

[*Federal Register*: Vol. 60, page 38326, 07/26/95]

Environnement S. A. Model AC32M NO₂ Analyzer*Automated Reference Method: RFNA-0202-146*

"Environnement S. A. Model AC32M Chemiluminescent Nitrogen Oxides Analyzer," operated with a full scale range of 0 - 500 ppb, at any temperature in the range of 10°C to 35°C, with a 5-micron PTFE sample particulate filter, with response time setting 11 (automatic response time), and with or without the following option: Internal permeation oven.

[*Federal Register*: Vol. 67, page 15567, 04/02/02]

Environnement S.A. SANOA Multigas Longpath Monitoring System*Automated Reference Method: EQNA-0400-139*

"Environnement S.A. Model SANOA Multigas Longpath Air Quality Monitoring System," consisting of a receiver, one or more projectors, interface unit, a user-provided control unit computer running the SANOA VisionAIR software, and associated incidental equipment; configured for measuring NO₂, with the temperature control and internal calibration cell options installed, operated with

a measurement range of 0 to 0.5 ppm, over an installed monitoring path length of between 27 and 500 meters, within an ambient air temperature range of -30 to +45°C, with a measurement (integrating) time of 180 seconds, and with or without external temperature and barometric pressure sensors or any of the following options: external (meteo) input connection, series 1M bus connection, OGR type projector, analog outputs.

[Federal Register: Vol 65, page 26603, 05/08/00]

Horiba Instruments Model APNA-360 NO-NO₂-NO_x Monitor

Automated Reference Method: RFNA-0196-111

"Horiba Instruments, Inc. Model APNA-360 Ambient NO-NO₂-NO_x Monitor," operated with a full scale range of 0 - 0.50 or 0 - 1.0 ppm, at any temperature in the range of 10 °C to 40 °C, with a Line Setting of "MEASURE", and an Analog Output of "MOMENTARY VALUE", and with or without the following options:² 1) Rack Mounting Plate and Side Rails 2) RS-232 Communications Port.

[Federal Register: Vol. 61, page 11404, 03/20/96]

Meloy Model NA530R Nitrogen Oxides Analyzer

Automated Reference Method: RFNA-1078-031

"Meloy Model NA530R Nitrogen Oxides Analyzer," operated on the following ranges and time constant switch positions:

Range, ppm:	<u>0-0.1¹</u>	<u>0-0.25¹</u>	<u>0-0.5</u>	<u>0-1.0</u>
Time Constant Setting:	4	3 or 4	2,3, or 4	2,3, or 4

Operation of the analyzer requires an external vacuum pump, either Meloy Option N-10 or an equivalent pump capable of maintaining a vacuum of 200 torr (22 inches mercury vacuum) or better at the pump connection at the specified sample and ozone-air flowrates of 1200 and 200 cm³/min, respectively. The analyzer may be operated at temperatures between 10°C and 40°C and at line voltages between 105 and 130 volts, with or without any of the following options: N-1A Automatic Zero And Span; N-2 Vacuum Gauge; N-4 Digital Panel Meter; N-6 Remote Control For Zero And Span; N-6B Remote Zero/Span Control And Status (Pulse); N-6C Remote Zero/Span Control And Status (Timer); N-9 Manual Zero/Span; N-10 Vacuum Pump Assembly (See Alternate Requirement Above); N-11 Auto Ranging; N-14B Line Transmitter; N-18 Rack Mount Conversion; N-18A Rack Mount Conversion.

[Federal Register: Vol. 43, page 50733, 10/31/78 and Vol. 44, page 8327, 02/09/79]

Monitor Labs Model 8440E Nitrogen Oxides Analyzer

Automated Reference Method: RFNA-0677-021

"Monitor Labs Model 8440E Nitrogen Oxides Analyzer," operated on a 0-0.5 ppm range (position 2 of range switch) with a time constant setting of 20 seconds, with or without any of the following options:

TF- Sample Particulate Filter With TFE Filter Element	DO- Status Outputs R- Rack Mount	018A- Ozone Dry Air V- Zero/Span Valves	O18B- Ozone Dry Air - No Drierite FM- Flow meters
--	-------------------------------------	--	--

[Federal Register: Vol. 42, page 37434, 07/21/77; Vol. 42, page 46575, 09/16/77; Vol. 46, page 29986, 06/04/81]

Monitor Labs/Lear Siegler Model 8840 Nitrogen Oxides Analyzer

Automated Reference Method: RFNA-0280-042

"Monitor Labs or Lear Siegler Model 8840 Nitrogen Oxides Analyzer," operated on a range of either 0-0.5 or 0-1.0 ppm, with an internal time constant setting of 60 seconds, a TFE sample filter installed on the sample inlet line, with or without any of the following options:

02 Flowmeter	08A Pump Pac Assembly With 09A (115 VAC)	011A Recorder Output 1 Volt
03A Rack Ears	08B Pump Pac Assembly With 09B (100 VAC)	011B Recorder Output 100 mV
03B Slides	08C Pump Pac Assembly With 09C (220/240 VAC)	011C Recorder Output 10 mV
05A Zero/Span Valves	08D Rack Mount Panel Assembly	012A DAS Output 1 Volt
05B Valve/Relay	09A Pump 115 VAC 50/60 Hz	012B DAS Output 100 mV
06 Status09B Pump	100 VAC 50/60 Hz	012C DAS Output 10 mV
07A Input Power Transformer	100 VAC, 50/60 Hz09C Pump 220/240 VAC 50 Hz	013A Ozone Dry Air
07B Input Power Transformer	220/240 VAC 50 Hz	013B Ozone Dry Air - No Drierite

[Federal Register: Vol. 45, page 9100, 02/11/80 and Vol. 46, page 29986, 06/04/81]

Monitor Labs/Lear Siegler Model 8841 Nitrogen Oxides Analyzer

Automated Reference Method: RFNA-0991-083

"Monitor Labs or Lear Siegler Model 8841 Nitrogen Oxides Analyzer," operated on the 0-0.05 ppm¹, 0-0.1 ppm¹, 0-0.2 ppm¹, 0 - 0.5 ppm, or 0-1.0 ppm range, with manufacturer-supplied vacuum pump or alternative user-supplied vacuum pump capable of providing 200 torr or better absolute vacuum while operating with the analyzer.

[Federal Register: Vol. 56, page 47473, 9/19/91]

Monitor Labs/Lear Siegler Models ML9841 or ML9841A,

Automated Reference Method: RFNA-1292-090

Monitor Labs Model ML9841B, or Wedding & Associates Model 1030 NO₂ Analyzers

"Lear Siegler Measurement Controls Corporation or Monitor Labs Models ML9841 or ML9841A, Monitor Labs Model ML9841B, or Wedding & Associates, Inc. Model 1030 Nitrogen Oxides Analyzers," operated on any full scale range between 0-0.05 ppm¹ and 0-1.0 ppm, at any temperature in the range of 15°C to 35°C, with the service switch on the secondary panel set to the *In* position; with the following menu choices selected: Range:0.05 ppm to 1.0 ppm; Over-ranging: Enabled or Disabled; Calibration: Manual or Timed; Diagnostic Mode: Operate; Filter Type: Kalman; Pres/Temp/FlowComp: On; SpanComp: Disabled; and as follows: **Models ML9841 and ML9841A** - with a five-micron Teflon® filter element installed internally, with the 50-pin I/O board installed on the rear panel configured at any of the following output range setting: Voltage, 0.1 V, 1 V, 5 V, 10 V; Current, 0-20 mA, 2-20 mA, 4-20 mA; and with

or without any of the following options: Valve Assembly for External Zero/Span (EZS); Internal Zero/Span (IZS) Assembly for; Rack Mount Assembly; Internal Floppy Disk Drive. **Models ML9841B and 1030** - with a vendor-supplied or equivalent user-supplied five-micron Teflon® filter and exhaust pump, and with or without any of the following options: Valve Assembly for External Zero/Span (EZS); 50-pin I/O board; Internal Zero/Span (IZS) Assembly; Rack Mount Assembly; Charcoal exhaust scrubber; hinged, fold-down front panel.

Opsis Model AR 500 and System 300 Open Path Ambient Air Monitoring Systems for NO₂

"Opsis Model AR 500 System" or "System 300" OpenPath (long path) Ambient Air Monitoring Systems, configured for measuring NO₂, with one detector and movable grating, operated with a measurement range of 0 to 0.5 ppm, an installed monitoring path length between 50 and 500 meters (or 50 and 1000 meters with the ER 150 option, AR 500 System only), xenon lamp type B (150 watt), fiber optic cable length between 3 and 20 meters; operating within an ambient air temperature range of -50 to +50°C, an analyzer temperature range of 20 to 30°C, a measurement (integrating) time setting between 30 and 120 seconds (0 min:30 sec. to 2 min:00 sec.), and with a complete cycle time of not more than 200 seconds (3 min, 20 sec.). Under this method designation, the Model AR 500 System or System 300 consists of: AR 500 opto-analyser; emitter EM 110 and receiver RE 110 (together identified as ER 110); optic fibre cable OF60-S; power supply PS 150; OPSIS operational software, version 7.0 or 7.1; and initial on-site installation, setup, and limited operator training.²

Optional components that can be used with the Model AR

500 only, in addition to or as alternative to corresponding components listed above:

AR 503 opto-analyzer configured as Model AR 500 (only the center detector active, sequential monitoring)

Emitter/receiver ER 150 (for monitoring path lengths up to 1 kilometer)

Transceiver ER 130 and Retroreflector RE 090 with:

7 prisms (max. monitoring path length 150 meters) or
12 prisms (max. monitoring path length 250 meters)

Receiver RE 130

Xenon lamp type A (higher short-wavelength UV output)

Optic fibre cable OF60-R (low-loss for short wavelengths)

Multiplexers MX 004 and MX 024

Dataloggers DL 010 and DL 016

Analogue and digital input/output cards AO 008, AI 016, and DI 032

Analogue and digital isolation cards IA 008, ID 008, OA 008, and OD 008,

Window heaters HF 110 and HF 150

Mirror heaters HM 110 and HM 150

[*Federal Register*: Vol. 57, page 60198, 12/18/92]

Automated Equivalent Method: EQNA-0495-102

Auto calibration unit CU 007

Software packages IO 80 (for the analogue and digital input/output adapters), DL10 and DL16 (for data loggers), ComVision, and STAT 500;

Recommended calibration and accuracy audit components (or equivalent) for either Model AR 500 or System 300:

Wavelength calibration lamp CA 004

Calibration bench CB 100

Receiver unit RE 060 (two required)

Calibration unit CA 150, with same type lamp as used in the monitoring path emitter

Power supply PS 150 for calibration unit CA 150

Calibration cells CC 001-X, where X represents various cell lengths from 1 to 900 mm

Filter GG 400

Special calibration cells CC 110 or CC 150 (for mounting directly on receiver)

Light meter LM 010.

[*Federal Register*: Vol. 60, page 21518, 05/02/95]

Philips Model PW9762/02 NO/NO₂/NO_x Analyzer

"Philips Model PW9762/02 NO/NO₂/NO_x Analyzer," consisting of the following components: PW9762/02 Basic Analyzer; PW9729/00 Converter Cartridge; PW9731/00 Sampler or PW9731/20 Dust Filter; operated on a range of 0-0.5 ppm, with or without any of the following accessories: PW9752/00 Air Sampler Manifold; PW9732/00 Sample Line Heater; PW9011/00 Remote Control Set.

[*Federal Register*: Vol. 44, page 51683, 09/04/79]

Thermo Electron/Thermo Environmental Instruments Model 14 B/E*Automated Reference Method: RFNA-0179-035*

"Thermo Electron or Thermo Environmental Instruments, Inc. Model 14 B/E Chemiluminescent NO/NO₂/NO_x Analyzer," operated on the 0-0.5 ppm range, with or without any of the following options:

14-001 Teflon Particulate Filter	14-003 Long-Time Signal Integrator	14-005 Sample Flowmeter
14-002 Voltage Divider Card	14-004 Indicating Temperature Controller	14-006 Air Filter

[*Federal Register*: Vol. 44, page 7805, 02/07/79 and Vol. 44, page 54545, 09/20/79]

Thermo Electron/Thermo Environmental Instruments Model 14 D/E*Automated Reference Method: RFNA-0279-037*

"Thermo Electron or Thermo Environmental Instruments, Inc. Model 14 D/E Chemiluminescent NO/NO₂/NO_x Analyzer," operated on the 0-0.5 ppm range, with or without any of the following options: 14-001 Teflon Particulate Filter; 14-002 Voltage Divider Card.

[*Federal Register*: Vol. 44, page 10429, 02/20/79]

Thermo Environmental Instruments Models 42, 42C NO/NO₂/NO_x Analyzer *Automated Reference Method: RFNA-1289-074*

"Thermo Environmental Instruments Inc. Model 42 or Model 42CNO-NO₂-NO_x Analyzer," operated on any measurement range between 0-50 ppb¹ and 0-1000 ppb, with any time average setting from 10 to 300 seconds, with temperature and/or pressure compensation on or off, operated at temperatures between 15 °C and 35 °C, with or without any of the following options:²

42-002 Rack mounts	42-006 Pressure transducer (Model 42 only)
42-003 Internal Zero/span and sample valves with remote activation	42-007 Ozone particulate filter
42-004 Sample/ozone flow meters (Model 42 only)	42-008 RS-232/485 interface
42-005 4-20 mA current output	42-009 Permeation dryer

[*Federal Register*: Vol. 54, page 50820, 12/11/89]

[*Federal Register*: Vol. 46, page 29986, 06/04/81]

NOTES

¹ Users should be aware that designation of this analyzer for operation on ranges less than the range specified in the performance specifications for this analyzer (40 CFR 53, Subpart B) is based on meeting the same absolute performance specifications required for the specified range. Thus, designation of these lower ranges does not imply commensurably better performance than that obtained on the specified range.

² This analyzer is approved for use, with proper factory configuration, on either 50 or 60 Hertz line frequency and nominal power line voltages of 115 Vac and 230 Vac.

Sources or Contacts for Designated Reference and Equivalent Methods

ABB Process Analytics P.O. Box 831 Lewisburg, WV 24901 (304) 647-4358	Environics, Inc. 69 Industrial Park Rd. E. Tolland, CT 06084-2805 (203) 429-0077 www.environics.com	Rupprecht & Patashnick Co., Inc. 25 Corporate Circle Albany, NY 12203 (518) 452-0065 www.rpcocom
Advanced Pollution Instrumentation, Inc. [Refer to Teledyne - Advanced Pollution Instrumentation, Inc.]	Graseby GMW [Refer to Andersen Instruments]	Sibata Scientific Technology, Ltd. 1-25, 3-chome Ikenohata, Taito-ku Tokyo 110, Japan 81-3(3822)2272 TTani@email.msn.com
Andersen Instruments 500 Technology Court Smyrna, GA 30082-9211 (800) 241-6898 www.anderseninstruments.com	Horiba Instruments Incorporated 17671 Armstrong Avenue Irvine, CA 92714 (800) 446-7422 www.horiba.com	Teledyne - Advanced Pollution Instrumentation, Inc. 6565 Nancy Ridge Drive San Diego, CA 92121-2251 (619) 657-9800 www.teledyne-api.com
ASARCO Incorporated 3422 South 700 West Salt Lake City, UT 84119 (801) 262-2459	Lear Siegler [Refer to Monitor Labs, Inc.]	Teledyne Analytical Instruments 16830 Chestnut Street City of Industry, CA 91748 (626) 934-1622
Beckman Instruments, Inc. Process Instruments Division 2500 Harbor Blvd. Fullerton, CA 92634 (714) 871-4848	Commonwealth of Massachusetts Department of Environmental Quality Engineering Tewksbury, MA 01876	Thermo Environmental Instruments, Inc. 8 West Forge Parkway Franklin, MA 02038 (508) 520-0430 www.thermoei.com
Bendix [Refer to ABB Process Analytics]	Met One Instruments, Inc. 1600 Washington Blvd. Grants Pass, OR 97526 (541) 471-7111 www.metone.com (metone@metone.com)	Tisch Environmental, Inc. 145 S. Miami Avenue Village of Cleves, OH 45002 (513) 467-9000 www.tisch-env.com
BGI Incorporated 58 Guinan Street Waltham, MA 02451 (781) 891-9380 www.bgiusa.com (bgiinc@attglobal.net)	McMillan [Refer to Columbia Scientific Industries]	URG Corporation 116 Merritt Mill Road Chapel Hill, NC 27516 (919) 942-2753
Columbia Scientific Industries 11950 Jollyville Road Austin, TX 78759 (800) 531-5003	Mine Safety Appliances 600 Penn Center Blvd. Pittsburgh, PA 15235-5810 (412) 273-5101	U.S. EPA National Exposure Research Laboratory Human Exposure & Atmospheric Sciences Division (MD-46) Research Triangle Park, NC 27711 (919) 541-2622 www.epa.gov/heasd
Combustion Engineering [Refer to ABB Process Analytics]	Monitor Labs, Inc. 74 Inverness Drive Englewood, CO 80112-5189 (800) 422-1499 www.monitorlabs.com	Wedding and Associates, Inc. [Refer to Thermo Environmental Instruments, Inc.]
Dasibi Environmental Corp. 506 Paula Avenue Glendale, CA 91201 (818) 247-7601 www.dasibi.com	Opsis AB, Furulund, Sweden Instruments also available from: Opsis, Inc. 146-148 Sound Beach Avenue Old Greenwich, CT 06870 (203) 698-1810 www.opsis.se	
DKK-TOA Corporation 29-10, 1-Chome, Takadanobaba, Shinjuku-ku Tokyo 169-8648, Japan www.toadkk.co.jp	State of Oregon Department of Environmental Quality Air Quality Division 811 S.W. Sixth Avenue Portland, OR 97204	
Environnement S.A 111, bd Robespierre 78300 Poissy, France www.environnement-sa.com Instruments also available from: Altech/Environnement U.S.A. 2623 Kaneville Court Geneva, IL 60134 (630) 262-4400 rbrown@altechusa.com	PCI Ozone Corp. One Fairfield Crescent West Caldwell, NJ 07006 (201) 575-7052 www pci-wedeco.com	Phillips Electronic Instruments, Inc. 85 McKee Drive Mahwah, NJ 07430

U.S. EPA REFERENCE & EQUIVALENT METHODS FOR AMBIENT AIR

<u>Method</u>	<u>Designation Number</u>	<u>Method Code</u>	<u>Method</u>	<u>Designation Number</u>	<u>Method Code</u>
<u>SO₂ Manual Methods</u>					
Reference method (pararosaniline)	--	097	Beckman 866	RFCA-0876-012	012
Technicon I (pararosaniline)	EQS-0775-001	097	Bendix 8501-5CA	RFCA-0276-008	008
Technicon II (pararosaniline)	EQS-0775-002	097	Dasibi 3003	RFCA-0381-051	051
<u>SO₂ Analyzers</u>					
Advanced Pollution Instr. 100	EQSA-0990-077	077	Dasibi 3008	RFCA-0488-067	067
Advanced Pollution Instr. 100A/100AS	EQSA-0495-100	100	Environnement S.A CO11M	RFCA-0995-108	108
Asarco 500	EQSA-0877-024	024	Environnement S.A CO12M	FRCA-0206-147	147
Beckman 953	EQSA-0678-029	029	Horiba AQM-10, -11, -12	RFCA-1278-033	033
Bendix 8303	EQSA-1078-030	030	Horiba 300E/300SE	RFCA-1180-048	048
Columbia Scientific Industries 5700	EQSA-0494-095	095	Horiba APMA-360	RFCA-0895-106	106
Dasibi 4108	EQSA-1086-061	061	Lear Siegler or Monitor Labs ML9830, Monitor Labs ML9830B, Wedding 1020	RFCA-0992-088	088
DKK-TOA Corp. Model GFS-32	EQSA-0701-115	115	MASS - CO 1 (Massachusetts)	RFCA-1280-050	050
DKK-TOA Corp. Model GFS-112E	EQSA-0100-133	133	Monitor Labs 8310	RFCA-0979-041	041
Environnement S.A AF21M	EQSA-0292-084	084	Monitor Labs or Lear Siegler 8830	RFCA-0388-066	066
Environnement S.A AF22M	EQSA-0802-149	149	Monitor Labs ML9830/9830B, Wedding 1020	RFCA-0992-088	088
Environnement S.A. SANOA	EQSA-0400-138	138	MSA 202S	RFCA-0177-018	018
Horiba Model APSA-360/APSA-360ACE	EQSA-0197-114	114	Teledyne Advanced Pollution Instr. 300 or 300E	RFCA-1093-093	093
Lear Siegler AM2020	EQSA-1280-049	049	Thermo Electron or Thermo		
Lear Siegler SM1000	EQSA-1275-005	005	Environmental Instruments 48, 48C	RFCA-0981-054	054
Lear Siegler or Monitor Labs ML9850, Monitor Labs ML9850B, Wedding 1040	EQSA-0193-092	092			
Meloy SA185-2A	EQSA-1275-006	006			
Meloy SA285E	EQSA-1078-032	032			
Meloy SA700	EQSA-0580-046	046			
Monitor Labs 8450	EQSA-0876-013	513			
Monitor Labs or Lear Siegler 8850	EQSA-0779-039	039			
Monitor Labs or Lear Siegler 8850S	EQSA-0390-075	075			
Monitor Labs ML9850/9850B, Wedding 1040	EQSA-0193-092	092			
Opsis AR 500, System 300 (open path)	EQSA-0495-101	101			
Philips PW9700	EQSA-0876-011	511			
Philips PW9755	EQSA-0676-010	010			
Teledyne Analytical Instruments 6400A	EQSA-0495-100	100			
Thermo Electron 43	EQSA-0276-009	009			
Thermo Electron 43A or Thermo Environmental Instruments 43B, 43C	EQSA-0486-060	060			
<u>O₃ Analyzers</u>					
Advanced Pollution Instr. 400/400A/400E	EQOA-0992-087	087			
Beckman 950A	RFOA-0577-020	020			
Bendix 8002	RFOA-0176-007	007			
Columbia Scientific Industries 2000	RFOA-0279-036	036			
Dasibi 1003-AH, -PC, -RS	EQOA-0577-019	019			
Dasibi 1008-AH, -PC, -RS	EQOA-0383-056	056			
DKK-TOA Corp. Model GUX-113E	EQOA-0200-134	134			
Envirronics 300	EQOA-0990-078	078			
Environnement S.A O ₃ 41M	EQOA-0895-105	105			
Environnement S.A O ₃ 42M	EQOA-0206-148	148			
Environnement S.A SANOA	EQOA-0400-137	137			
Horiba APOA-360	EQOA-0196-112	112			
Lear Siegler or Monitor Labs ML9810, Monitor Labs ML9810B, Wedding 1010	EQOA-0193-091	091			
McMillan 1100-1	RFOA-1076-014	514			
McMillan 1100-2	RFOA-1076-015	515			
McMillan 1100-3	RFOA-1076-016	016			
Meloy OA325-2R	RFOA-1075-003	003			
Meloy OA350-2R	RFOA-1075-004	004			
Monitor Labs 8410E	RFOA-1176-017	017			
Monitor Labs or Lear Siegler 8810	EQOA-0881-053	053			
Monitor Labs ML9810/9810B, Wedding 1010	EQOA-0193-091	091			
Opsis AR 500, System 300 (open path)	EQOA-0495-103	103			
PCI Ozone Corp. LC-12	EQOA-0382-055	055			
Philips PW9771	EQOA-0777-023	023			
Teledyne - Advanced Pollution Instr. 400E	EQOA-0992-087	087			
Thermo Electron or Thermo Environmental Instruments 49, 49C	EQOA-0880-047	047			
<u>Pb Manual Methods</u>					
Reference method (hi-vol/AA spect.)	--				803
Hi-vol/AA spect. (alt. extr.)	EQL-0380-043				043
Hi-vol/Energy-disp XRF (TX ACB)	EQL-0783-058				058
Hi-vol/Energy-disp XRF (NEA)	EQL-0589-072				072
Hi-vol/Flameless AA (EMSL/EPA)	EQL-0380-044				044
Hi-vol/Flameless AA (Houston)	EQL-0895-107				107
Hi-vol/Flameless AA (Omaha)	EQL-0785-059				059
Hi-vol/ICAP spect. (Doe Run Co.)	EQL-0196-113				113
Hi-vol/ICAP spect. (EMSL/EPA)	EQL-0380-045				045
Hi-vol/ICAP spect. (Illinois)	EQL-1193-094				094
Hi-vol/ICAP spect. (Kansas)	EQL-0592-085				085

U.S. EPA REFERENCE & EQUIVALENT METHODS FOR AMBIENT AIR

<u>Method</u>	<u>Designation Number</u>	<u>Method Code</u>	<u>Method</u>	<u>Designation Number</u>	<u>Method Code</u>
Hi-vol/ICAP spect. (Montana)	EQL-0483-057	057			
Hi-vol/ICAP spect. (NE&T)	EQL-1188-069	069			
Hi-vol/ICAP spect. (New Hampshire)	EQL-1290-080	080			
Hi-vol/ICAP spect. (Pennsylvania)	EQL-0592-086	086			
Hi-vol/ICAP spect. (Pima Co.,AZ)	EQL-0995-109	109			
Hi-vol/ICAP spect. (Pima Co.,AZ)	EQL-0995-110	110			
Hi-vol/ICAP spect. (Rhode Island)	EQL-0888-068	068			
Hi-vol/ICAP spect. (Silver Val. Labs)	EQL-1288-070	070			
Hi-vol/ICAP spect. (TNRCC)	EQL-0400-140	140			
Hi-vol/ICAP spect. (West Virginia)	EQL-0694-096	096			
Hi-vol/WL-disp. XRF (CA A&IHL)	EQL-0581-052	052			
<u>PM₁₀ Samplers</u>					
Andersen Instruments RAAS10-100	RFPS-0699-130	130			
Andersen Instruments RAAS10-200	RFPS-0699-131	131			
Andersen Instruments RAAS10-300	RFPS-0699-132	132			
BGI Model PQ100	RFPS-1298-124	124			
BGI Model PQ200	RFPS-1298-125	125			
Oregon DEQ Medium volume sampler	RFPS-0389-071	071			
Rupprecht & Patashnick Partisol 2000	RFPS-0694-098	098			
R & P Partisol-FRM Model 2000	RFPS-1298-126	126			
R & P Partisol-Plus Model 2025 Seq.	RFPS-1298-127	127			
<u>PM₁₀ Samplers (continued)</u>					
Sierra-Andersen/GMW 1200	RFPS-1287-063	063			
Sierra-Andersen/GMW 321-B	RFPS-1287-064	064			
Sierra-Andersen/GMW 321-C	RFPS-1287-065	065			
Sierra-Andersen/GMW 241 Dichot.	RFPS-0789-073	073			
Tisch Environmental Model TE-6070	RFPS-0202-141	141			
W&A/Thermo Electron Mod 600 HVL	RFPS-1087-062	062			
<u>PM₁₀ Analyzers</u>					
Andersen Instruments Beta FH62I-N	EQPM-0990-076	076			
Met One BAM1020, GBAM1020, BAM1020-1, GBAM1020-1	EQPM-0798-122	122			
R & P TEOM 1400, 1400a	EQPM-1090-079	079			
W&A/Thermo Electron 650 Beta Gauge	EQPM-0391-081	081			
<u>PM_{2.5} Samplers</u>					
Andersen Model RAAS2.5-200 Audit	RFPS-0299-128	128			
BGI PQ200/200A	RFPS-0498-116	116			
BGI PQ200-VSCC or PQ200A-VSCC	EQPM-0202-142	142			
Graseby Andersen RAAS2.5-100	RFPS-0598-119	119			
Graseby Andersen RAAS2.5-300	RFPS-0598-120	120			
R & P Partisol-FRM 2000 PM-2.5	RFPS-0498-117	117			
R & P Partisol-FRM 2000 PM-2.5 FEM	EQPM-0202-143	143			
R & P Partisol 2000 PM-2.5 Audit	RFPS-0499-129	129			
R & P Partisol 2000 PM-2.5 FEM Audit	EQPM-0202-144	144			
R & P Partisol-Plus 2025 PM-2.5 Seq.	RFPS-0498-118	118			
R & P Partisol-Plus 2025 PM-2.5 FEM Seq.	EQPM-0202-145	145			
Thermo Environmental Model 605 CAPS	RFPS-1098-123	123			
URG-MASS100	RFPS-0400-135	135			
URG-MASS300	RFPS-0400-136	136			
<u>TSP Manual Method</u>					
Reference method (high-volume)	--		802		