Section 9. Monitoring Methods Guidance and Support

Despite a substantial allocation of resources in overall PM monitoring implementation, very little methods development work has been performed in the area of $PM_{2.5}$ continuous monitors. This lack of development combined with requirements for lengthy field testing in multiple sites and high statistical correlations for designation as a $PM_{2.5}$ Federal Equivalent Method (FEM) have resulted in no applications for designation of continuous $PM_{2.5}$ monitors as FEM.

Introduction:

During the planning stages of the PM_{2.5} monitoring program there was little emphasis on development of PM continuous methods by EPA. There were no nationally coordinated field testing programs to assess the usefulness of continuous methods over a variety of locations and aerosols. A guidance Document was written in 1998 compiling the available field testing on PM continuous methods to date; however, this document offered little insight on planning a long term strategy of using PM_{2.5} continuous methods for regulatory purposes. Additionally, EPA never actually proposed or promulgated Class III equivalency criteria that would provide the testing requirements for PM_{2.5} continuous methods. Since no criteria have ever been proposed there has never been an opportunity for the various stakeholders in the monitoring community to provide comments on the usefulness of the Class III equivalency testing criteria. There is an expectation that the equivalency criteria for Class III designations would be at least as strict as the Class II criteria. But since these criteria have never been published by EPA there is no clear path for acceptance of PM_{2.5} continuous methods. Without EPA directly involved in developing PM continuous methods, vendors have been left to pursue improvements on their own. While some vendors have been successful at improving their methods by working directly with the States, these methods have not been appropriately tested on a national scale. For instance, the California Air Resources Board (CARB) has been working with the Met One Beta Attenuation Monitor over the last few years, yet very little data exists on this method collocated with FRMs in any east coast States. Also, Rupprecht & Patashnick Company have commercialized the Sample Equilibration System (SES) as an add on to the TEOM PM continuous monitor to allow for operation of this instrument at lower temperatures; however, little information is known about the longterm usefulness of the SES. The result of all of this is that there are no designated equivalent methods for PM_{2.5} continuous monitors. Also, little information is available in the form of peer reviewed field studies over a variety of methods and locations. Despite all these issues there is still a great deal of information to glean from monitoring agencies and vendors on how these methods may be best suited for implementation in routine regulatory networks. This section attempts to summarize a number of points in how to best set-up and operate PM_{2.5} continuous monitors. Many of these suggestions have already been incorporated into commercially available monitors. None of the suggestions should be considered as "required" since ultimately the best measures of success are performance of the PM_{2.5} continuous monitor with respect to its ability to reproduce itself (measurement precision) and comparison to a FRM (bias).

Recommendations for Design and Operation of PM_{2.5} Continuous Methods

In order to design an appropriate configuration for a $PM_{2.5}$ continuous monitor many issues need to be addressed. This section attempts to provide the general specifications for $PM_{2.5}$ continuous methods. A detailed accounting comparing the FRM design and performance specifications with applicability to a generic $PM_{2.5}$ continuous monitor follows.

Comparing FRM and Continuous Methods for Design and Performance Criteria

The Federal Reference Method is based upon both design and performance criteria as identified in 40 CFR, Part 50, Appendix L. Design criteria are applicable to components of the reference method such as the inlet and second stage separation device. Performance criteria are applicable to things such as the control of flow rate and maximum allowable temperature difference between the filter and the ambient temperature. For any potential continuous method to be used in the routine regulatory network only performance criteria with respect to the comparison of collocated FRM and continuous data are to be used. However, the performance of a continuous method may be expected to be optimized by adhering to as much of the reference method as practical. In reality, many aspects of the design and performance of the FRM will not be included in a continuous methods operation due to the measurement principle of the instrument or other factors. For instance, much of the laboratory FRM criteria are not practical since there is not expected to be any pre or post-sampling gravimetric analyses in the traditional sense. This section discusses the current understanding of the FRM design and performance criteria that may be applicable to a potential continuous method for use in a regulatory network. Also, where applicable, alternatives to the design and performance criteria of the FRM are included as may be appropriate for use with continuous methods. This section is intended to provide information on how a continuous method might best be designed so that resulting data mimic that of the FRM. Due to the inherent operation of any one continuous method, many of the FRM design and performance criteria may not be suitable for inclusion in its design; therefore, none of the FRM criteria are required. Also, improvements to a design or performance criteria of the FRM are encouraged where appropriate in order for resulting PM continuous data to match that of the FRM.

General Specifications

There are many specifications listed in the FRM as detailed in 40 CFR, Part 50, Appendix L. Among the general specifications, a number of items may be applicable to PM continuous monitoring. This section details those general provisions of the FRM that should be included in the design of a PM continuous method:

- *Pollutant* Fine particulate matter having an aerodynamic diameter less than or equal to a nominal 2.5 micrometers in the ambient air. Surrogates of this are possible if they result in meeting the necessary performance standards identified in section 6 of this document.
- *Units* Provide for data to be reported in units of micrograms per cubic meter. This may be calculated directly or indirectly through use of other inputs.
- *PM*_{2.5} measurement range Provide for a lower and upper concentration limits that allow for meaningful comparison to the FRM. While the FRM is estimated to have a lower concentration limit of at least 2 ug/m³ and upper concentration limit of at least 200 ug/m³, continuous methods may be able to operate over an even wider range of concentrations. Most importantly, PM continuous methods need to provide concentration values in the environments they operate in. For instance, in an extremely dirty environment, a continuous method may be able to operate above 200ug/m³, if designed appropriately. Similarly, when a continuous method is operated at a very clean site the performance of the instrument should be able to discern changes in ambient PM_{2.5} even over very low concentrations.
- Sample Period Provide for a sample period that can be used to calculate the midnight to midnight 24-hour average PM_{2.5} concentration. For all other criteria pollutant continuous data the reported averaging period is usually 1-hour. Depending on the precision of the PM continuous instrument shorter or longer averaging periods may be necessary in order to have a meaningful averaging period. Therefore, 1-hour averages should be capable of being reported; however shorter or longer averaging periods may be necessary depending on the measurement precision of the instrument.
- Accuracy and Precision Because of the size and volatility of the particles making up ambient PM vary over a wide range and the mass concentration of particles varies with particle size it is difficult to define the accuracy of PM_{2.5} measurements in an absolute sense. The accuracy of PM_{2.5} measurements is therefore defined in a relative sense, referenced to measurements provide by the FRM. Section 6 defines the performance standards for PM_{2.5} continuous methods.

Design Criteria

Design criteria for the FRM are largely associated with the inlet and separation device to obtain the desired size selection of aerosol in the sample stream. Many of these criteria can be applied to a potential continuous method. Most of the commercial vendors of PM continuous methods have already incorporated these design criteria into their instruments. The table below describes the various design criteria for the FRM and their applicability to PM continuous methods. Also, where appropriate, alternatives to the FRM design criteria are offered:

Design Areas	Section of Appendix L	FRM specification	Applicability to Continuous Methods
Inlet Assembly	7.3.2	PM ₁₀ head with dimensions as described in figures L-2 through L-18	This should be applicable to most PM continuous methods
Downtube	7.3.3	With dimensions as described in figure L-19	This may or may not be applicable to a PM continuous method. A downtube may not be needed if there is sufficient clearance for the PM 10 head above the monitor. Also, there needs to be a provision for a leak check adapter to be attached at the point where the PM 10 heads attaches if the downtube is not utilized.
Impactor	7.3.4	WINS with dimensions as described in Figures L-20 through L-24.	The WINS may be used or alternatively the Sharp Cut Cyclone (SCC) or newer generation of SCC or other cyclone providing an appropriate PM _{2.5} separation may be used. The SCC is expected to maintain an appropriate separation of coarse and fine particulate over a longer period of time than the WINS making it more suitable for use with PM _{2.5} continuous monitors.
Filter Holder Assembly	7.3.5	Many specifications as described in the text and with dimensions as detailed in Figures L-25 through L-29.	Most of the filter holder assembly design specifications will not be applicable to PM continuous monitors. Some of the important areas to strive for in the design of a PM continuous method include: - providing for a uniform face velocity of the sample stream during sample collection preclude significant exposure of the filter (or surrogate collection device) to possible contamination.
Flow Rate Measurement Adapter	7.3.6	As described with the dimensions in Figure L-	Ideally, this would be the same so that flow rate adapters would be interchangeable between FRMs and continuous methods.

Surface Finish	7.3.7	Anodized aluminum for all internal surfaces exposed to sample air prior to the filter.	Ideally continuous methods will also have anodized aluminum for all internal surfaces exposed to sample air prior to the filter or surrogate collection device. This is especially important to note for the Sharp Cut Cyclone; if used, since it is not part of the FRM.
Sampling Height	7.3.8	2 meters ± 0.2 meters	Ideally, the sample inlet on a continuous method would meet this.

Performance Specifications

Performance specifications for the FRM are largely associated with maintaining the flow rate within an acceptable range and the operational conditions for which the instrument should be capable of operating in. Most of the flow rate performance specifications for the FRM should be applicable to continuous methods; however, the operational conditions for which an instrument should be capable of operating in may or may not be applicable to any one continuous method. Many of these performance criteria can be applied to a potential continuous method. Most of the commercial vendors of PM continuous methods have already incorporated these performance criteria into their instruments. The table below describes the various performance specifications for the FRM and their applicability to PM continuous methods. Also, where appropriate, alternatives to the FRM performance specifications are offered:

Performance Specification Area	Section of Appendix L	FRM specification	Applicability to Continuous Methods
Sample Flow Rate	7.4.1	16.67 L/min measured as actual volumetric flow rate at the temperature and pressure of the sample air entering the inlet.	Generally applicable with the exception of any potential use of nephelometers. This flow rate is necessary if a PM 10 size selective inlet is used as well as for most second stage separators.
Leak Test Capability	7.4.6	Provide for an convenient external leak test capability	Generally applicable.
Range of Operational Conditions	7.4.7	Ambient Temperature - 30 to +45 C Ambient Relative Humidity 0 to 100 percent Barometric Pressure 600 to 800 mm Hg	Generally applicable as a starting point for design of an instrument; however, some continuous instruments may need to be located in an environmentally controlled shelter in order to have operate correctly. Some instruments may not meet all of these specifications which may limit their use geographically.
Ambient Temperature and Barometric Pressure Sensors:	7.4.8 and 7.4.9	Capable of operating over the range of operating conditions	Applicable for the operation of the continuous instruments in the range of environmental conditions they will encounter.
Filter Temperature Control	7.4.10	The sampler shall provide a means to limit the temperature rise of the sample filter from isolation and other sources to no more than 5C above the temperature of the ambient air surrounding the sampler.	It is desirable to minimize the temperature difference between the ambient air and the location where sample are collected and analyzed in a continuous method to provide for minimal volatilization of PM; however, in some cases heating may be necessary due to moisture interference or other reasons. Each potential continuous method should be designed to optimize this temperature difference with respect to avoiding moisture interference, PM volatilization, and stable measurement readings.

Filter Temperature Sensor	7.4.11	Capable of operating over the range of operating conditions	Generally applicable. However, may not always be required depending on the measurement principle of the continuous method.
Clock/timer system	7.4.12	Capable of maintaining local time and date including year, month, day of month, hour, minute, and second to an accuracy of \pm 1.0 minute per month.	Generally applicable.
Outdoor Environmental Enclosure	7.4.14	Suitable to protect the instrument	Generally applicable for those instruments intended to be located outside. Not necessarily applicable to those instruments intended to be located in a station trailer or other environmentally controlled housing
Electrical Power Supply	7.4.15	105 to 125 volts AC (RMS) at a frequency of 59 to 61 Hz.	Generally applicable.
Data Output Port Requirements	7.4.17	Standard RS-232C	The Standard RS-232C data output connection can be utilized. Additionally, it is strongly encouraged to have a provision for an analog output that can be conveniently connected to a typical data logger utilized by ambient air monitoring agencies. For example, 0 - 10mV, 0-100mV, 0-1V, 0-5V, or 0-10V.