

The PM Fine Database and Associated Visualization Tool

Steve Boone, E.H. Pechan & Associates, Inc.

BACKGROUND

1997 Presidential Directive establishes the PM_{2.5} Network to:

- Identify problem areas
- Define diurnal patterns
- Determine spatial scale of high concentration areas
- Characterize PM_{2.5} compositions

BACKGROUND

- The speciation database is a product of new regulatory initiatives for PM_{2.5}, ozone and regional haze
- Previously the PM sites and guidelines were for PM₁₀

BACKGROUND

- More than 50 PM speciation sites established since 1999 in rural and urban areas
- PM Speciation sampling usually consists of one 24 hour sample every three days (although some operate daily)

BACKGROUND

Chemical analysis of PM speciation samples:

- Improve understanding of emissions and dynamic atmospheric processes that influence particle formation and distribution
- Determine the sources of pollutants that contribute to elevated PM concentrations

BACKGROUND

Chemical analysis of PM speciation samples (*continued*):

- Develop useful methods for decision makers in formulating and comparing candidate control strategies
- Provide a reliable means for estimating the impacts of control strategy options developed for PM

DATABASES

- Interagency Monitoring Of Protected Visual Environments (IMPROVE)
 - Rural
 - *vista.cira.colostate.edu/improve*
- Speciation Trends Network (STN)
 - Urban
 - Contained in EPA's Air Quality System (AQS)

DATA VALIDATION

Ratings

- Valid
- Valid, but suspect
- Invalid

DATA VALIDATION

Levels

- I Performed in laboratory
 - Flagging suspect data
 - Validating data entry
 - Elimination of readings from malfunctioning equipment
 - Incorporation of data from backup monitors
 - Adjustment of measurements of quantifiable calibration or interference

DATA VALIDATION

Levels (*continued*)

- II Performed on database
 - Sum of parts must be less than or equal to the whole
 - Size segregated particle concentrations must be less than total particle concentrations
 - Sum of the major species must be less than 75% of measured mass
 - Analysis of same species by different methodologies should yield compatible results

DATA VALIDATION


Both IMPROVE and STN are assumed to
be at Data Validation Level II



PRIMARY FUNCTIONALITY

- Combined database
- Temporal selection
- Geographical selection
- Data and graphs
- Base data updates

COMBINED DATABASE



TEMPORAL SELECTION



- Begin date
- End date
- By month
- Entire period


- State
- County
- Metropolitan Statistical Area (MSA)
- Health Effects Institute (HEI) Region



DATA AND GRAPHS

- Raw Data
- Minimum
- Maximum
- Average
- Number of Data Points
- Stacked Bar Graphs
- Pie Charts

BASE DATA UPDATES




DESIGN PARAMETERS

- Database
 - Visual FoxPro (.DBF)
 - Graph Generator
 - Graphics Server
 - Application
 - Visual BASIC
-
- ```
graph TD; DB[Database - Visual FoxPro (.DBF)] -- ODBC --> GG[Graph Generator - Graphics Server]; GG -- ODBC --> App[Application - Visual BASIC];
```
- ODBC

## PROGRAM FLOW

Two main tools



## SITE INFORMATION TOOL SELECTION SCREEN

Select Sites to Graph

| Site Type                                                                                                           | Start Date                                                                | End Date                                                                  | HEI                                                                                                                | State                                                                                                        |
|---------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|---------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------|
| <input checked="" type="radio"/> STN (Trends)<br><input type="radio"/> STN (Other)<br><input type="radio"/> IMPROVE | 02/2000<br>03/2000<br>04/2000<br>05/2000<br>06/2000<br>07/2000<br>08/2000 | 09/2001<br>10/2001<br>11/2001<br>12/2001<br>01/2002<br>02/2002<br>03/2002 | Industrial Midwest<br>North East<br>North West<br>South East<br>South West<br>Southern California<br>Upper Midwest | 01 - Alabama<br>04 - Arizona<br>06 - California<br>08 - Colorado<br>10 - Delaware<br>11 - DC<br>12 - Florida |

| MSA                                                                                                                                                                                               | County             | Sites                                      |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------|--------------------------------------------|
| 0680 - Bakersfield, CA<br>2840 - Fresno, CA<br>6780 - Los Angeles-Riverside<br>6920 - Sacramento-Yolo, CA<br>7320 - San Diego, CA<br>7400 - San Francisco-Oakland<br>8735 - Los Angeles-Riverside | 073 - San Diego Co | 06073-0003-5 - 1155 Redwood Ave., El Cajon |

| Period                                                                                | Species                                                                                                                                                                                                                                                                                             |                                  |
|---------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------|
| <input checked="" type="checkbox"/> Entire Period<br><input type="checkbox"/> Monthly | <input type="checkbox"/> Al - Aluminium<br><input type="checkbox"/> Ca - Calcium<br><input checked="" type="checkbox"/> Crustal<br><input checked="" type="checkbox"/> EC - Elemental Carbon<br><input checked="" type="checkbox"/> Fe - Iron<br><input checked="" type="checkbox"/> NH4 - Ammonium | Table<br>Stats<br>Graph<br>Close |


Select All      Unselect All

## SITE INFORMATION TOOL DATA TABLE


| Site 06073-0003-5 Data |     |           |         |          |           |     |            |       |       |         |       |       |
|------------------------|-----|-----------|---------|----------|-----------|-----|------------|-------|-------|---------|-------|-------|
| Site ID                | POC | Site Type | Sampler | Latitude | Longitude | Lab | Date       | Al    | Ca    | Crustal | EC    | Fe    |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/05/13 | 0.069 | 1.129 | 0.260   | 0.105 | 1.010 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/05/19 | 0.022 | 0.272 | 0.290   | 0.036 | 1.370 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/05/25 | 0.024 | 0.380 | 0.580   | 0.053 | 3.360 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/05/31 | 0.028 | 0.566 | 0.820   | 0.087 | 5.060 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/06/06 | 0.061 | 0.637 | 0.610   | 0.082 | 4.620 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/06/12 | 0.055 | 0.440 | 0.410   | 0.042 | 1.120 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/06/18 | 0.063 | 0.700 | 0.590   | 0.098 | 1.010 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/06/24 | 0.049 | 0.389 | 0.320   | 0.045 | 1.030 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/06/30 | 0.043 | 0.428 | 0.560   | 0.064 | 2.020 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/07/06 | 0.034 | 0.310 | 0.460   | 0.034 | 0.980 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/07/12 | 0.025 | 0.370 | 0.310   | 0.054 | 0.720 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/07/24 | 0.058 | 0.707 | 0.474   | 0.093 | 1.670 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/07/30 | 0.065 | 0.584 | 0.460   | 0.068 | 1.480 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/08/05 | 0.066 | 0.949 | 0.462   | 0.127 | 2.200 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/08/11 | 0.061 | 0.540 | 0.440   | 0.078 | 2.700 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/08/17 | 0.099 | 1.167 | 0.657   | 0.153 | 3.450 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/08/23 | 0.071 | 1.152 | 0.529   | 0.128 | 1.770 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/08/29 | 0.069 | 0.826 | 0.355   | 0.092 | 2.840 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/09/04 | 0.063 | 0.986 | 0.519   | 0.125 | 1.160 |
| 06073-0003-5           | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI | 2001/09/10 | 0.002 | 0.047 | 0.308   | 0.003 | 1.940 |

[illegible]

## SITE INFORMATION TOOL STACKED BAR GRAPH



## SITE INFORMATION TOOL PIE CHART





## SITE COMPARISON TOOL SELECTION SCREEN

Start Date

03/2001  
04/2001  
05/2001  
06/2001  
07/2001  
08/2001  
09/2001

End Date

08/2001  
09/2001  
10/2001  
11/2001  
12/2001  
01/2002  
02/2002

STN Sites

06029-0014-5 - 5558 California Ave, Bakersfield  
06029-0014-6 - 5558 California Ave, Bakersfield  
06065-8001-5 - 5888 Mission Blvd., Rubidoux  
06065-8001-6 - 5888 Mission Blvd., Rubidoux  
06067-0006-5 - Del Paso-2701 Avalon Dr, Sacramento  
06073-0003-5 - 1155 Redwood Ave., El Cajon  
06085-0004-5 - 120b N 4th St, San Jose

Filter IMPROVE Sites

☒ Closest  
☐ County  
☐ State  
☐ HEI Region  
☐ All

IMPROVE Sites

AGT11 - Agua Tibia

Period

☒ Entire Period  
☐ Monthly

Species

☐ NH4\_NO3 - Ammonium Nitrate  
☐ NH4\_S - Ammonium Sulfate  
☐ NO3 - Nitrate Ion  
☒ OC - Organic Carbon  
☐ OCM - Organic Carbon Mass  
☒ Si - Silicon

Select All

Unselect All

Table

Stats

Graph


Close

## SITE COMPARISON TOOL DATA TABLE

| Site 06073-0003-5, AGT11 Comparison Data |     |           |         |          |           |       |            |       |       |         |       |       |
|------------------------------------------|-----|-----------|---------|----------|-----------|-------|------------|-------|-------|---------|-------|-------|
| Site ID                                  | POC | Site Type | Sampler | Latitude | Longitude | Lab   | Date       | Al    | Ca    | Crustal | EC    | Fe    |
| 06073-0003-5                             | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI   | 2002/01/29 | 0.009 | 0.182 | 0.880   | 0.035 | 0.180 |
| 06073-0003-5                             | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI   | 2002/02/01 | 0.067 | 1.132 | 2.760   | 0.203 | 1.050 |
| 06073-0003-5                             | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI   | 2002/02/07 | 0.090 | 1.183 | 1.500   | 0.210 | 4.750 |
| 06073-0003-5                             | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI   | 2002/02/10 | 0.118 | 1.722 | 0.910   | 0.177 | 0.130 |
| 06073-0003-5                             | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI   | 2002/02/13 | 0.113 | 1.817 | 1.150   | 0.245 | 2.350 |
| 06073-0003-5                             | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI   | 2002/02/16 | 0.037 | 0.613 | 0.570   | 0.085 | 5.090 |
| 06073-0003-5                             | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI   | 2002/02/22 | 0.109 | 1.774 | 1.170   | 0.290 | 0.080 |
| 06073-0003-5                             | 5   | TRENDS    | SASS    | 32.7914  | -116.942  | RTI   | 2002/02/28 | 0.061 | 0.842 | 0.800   | 0.093 | 4.650 |
| AGT11                                    | -99 | IMPROVE   | IMPROVE | 33.4636  | -116.971  | IM... | 2001/03/02 | 0.014 | 0.165 | 0.559   | 0.029 | 0.000 |
| AGT11                                    | -99 | IMPROVE   | IMPROVE | 33.4636  | -116.971  | IM... | 2001/03/05 | 0.016 | 0.149 | 0.493   | 0.019 | 0.000 |
| AGT11                                    | -99 | IMPROVE   | IMPROVE | 33.4636  | -116.971  | IM... | 2001/03/08 | 0.012 | 0.151 | 0.619   | 0.028 | 0.000 |
| AGT11                                    | -99 | IMPROVE   | IMPROVE | 33.4636  | -116.971  | IM... | 2001/03/11 | 0.030 | 0.131 | 0.124   | 0.010 | 0.000 |
| AGT11                                    | -99 | IMPROVE   | IMPROVE | 33.4636  | -116.971  | IM... | 2001/03/14 | 0.000 | 0.000 | 0.000   | 0.000 | 0.000 |
| AGT11                                    | -99 | IMPROVE   | IMPROVE | 33.4636  | -116.971  | IM... | 2001/03/17 | 0.000 | 0.000 | 0.000   | 0.000 | 0.000 |
| AGT11                                    | -99 | IMPROVE   | IMPROVE | 33.4636  | -116.971  | IM... | 2001/03/20 | 0.000 | 0.000 | 0.000   | 0.000 | 0.000 |
| AGT11                                    | -99 | IMPROVE   | IMPROVE | 33.4636  | -116.971  | IM... | 2001/03/23 | 0.000 | 0.000 | 0.761   | 0.000 | 0.000 |
| AGT11                                    | -99 | IMPROVE   | IMPROVE | 33.4636  | -116.971  | IM    | 2001/03/26 | 0.024 | 0.252 | 0.497   | 0.031 | 0.000 |

[illegible]

## SITE COMPARISON TOOL STACKED BAR GRAPH





## ***NEXT STEPS***

- Initial release imminent
- Possible enhancements
  - Allow increased user control on graphics
  - Prove preset species combinations
  - Incorporating additional graph types
  - Allowing for multiple temporal periods in single analysis
  - Adding a GIS front end for geographical selections and on the back end to display analysis results
  - Web enable

***PM FINE DATABASE AND  
ASSOCIATED  
VISUALIZATION TOOL***

End of presentation