## Reduced Nitrogen Measurements at CSN/IMPROVE

Joann Rice, Xi (Doris) Chen (EPA/OAQPS)

Melissa Puchalski (EPA/OAP)

John Walker, Ralph Baumgardner (EPA/ORD/AEMD)

Chris Rogers, Kevin Mishoe, Kathy Barry, Marcus Stewart (Wood)

Bret Schichtel (NPS)

# Southeastern U.S. CSN/IMPROVE NHx Pilot Study

- Follow on to IMPROVE NHx pilot study in the West/Midwest (Chen et al., 2014)
- Operated IMPROVE and CSN PM samplers with acid-coated filters May – October 2017



Duke Forest NHx study site

#### URG denuder/filter pack


- Separates NH<sub>3</sub> and NH<sub>4</sub><sup>+</sup>
  - Acid coated denuder (NH<sub>3</sub>)
  - Nylon filter (NH<sub>4</sub>+)
  - Backup denuder (volatile NH<sub>3</sub>)
- Duplicates
- PM<sub>2.5</sub> inlet @ 10 Lpm


#### **CSN**

- One module collecting NH<sub>4</sub><sup>+</sup> on nylon filter
- 2<sup>nd</sup> module collecting total NHx on acid impregnated cellulose filter
- PM<sub>2.5</sub> inlet at 6.7 Lpm

#### **IMPROVE**

- Acid impregnated cellulose filter to capture total NHx
- PM<sub>2.5</sub> inlet @ 22.8 Lpm






- Laboratory and field blanks were low for 3 sampling methods
- Duplicate denuders showed good precision
- Negative bias in CSN NHx concentration
- IMPROVE NHx biased high at Duke Forest and low at Gainesville
- ADS results showed a large fraction of NH<sub>4</sub><sup>+</sup> on the backup acid denuder
- Additional testing in RTP showed ADS capturing NHx completely with backup denuder – loss of NH<sub>4</sub><sup>+</sup> from nylon filter

### Results

- Wood analyzed extracts for NO<sub>3</sub><sup>-</sup> and SO<sub>4</sub><sup>2-</sup> from CSN and ADS nylon filters
- CASTNET uses Teflon for NH<sub>4</sub><sup>+</sup>, SO<sub>4</sub><sup>2-</sup>, NO<sub>3</sub><sup>-</sup>
- CSN uses nylon filter for NH<sub>4</sub><sup>+</sup>, SO<sub>4</sub><sup>2-</sup>, NO<sub>3</sub><sup>-</sup>
  - comparison with CASTNET and ADS showed no loss of  $SO_4^{2-}$  from nylon filter
  - CSN loss of NH<sub>4</sub><sup>+</sup> resulted in NH<sub>4</sub>/SO<sub>4</sub> ratio of about ½ of what was measured with ADS and CASTNET filterpack

#### Ratio NH4/SO4 Duke Forest



## Next Steps

- Determine why CSN acid coated filters were biased low
  - IMPROVE: type 40 cellulose filters with higher particle capture efficiency
  - CSN: type 41 with lower capture efficiency for smaller particles
- Results to date included in summary report
- Interpret Gainesville and Duke Forest meteorology with NHx results
- Resolve NH<sub>4</sub><sup>+</sup> loss from nylon filters