

Greenhouse Gas Inventory Guidance
Direct Fugitive Emissions from
Refrigeration, Air Conditioning, Fire
Suppression, and Industrial Gases



December 2023

The U.S. EPA Center for Corporate Climate Leadership's (The Center) GHG guidance is based on The Greenhouse Gas Protocol: A Corporate Accounting and Reporting Standard (GHG Protocol) developed by the World Resources Institute (WRI) and the World Business Council for Sustainable Development (WBCSD). The Center's GHG guidance is meant to extend upon the GHG Protocol to align more closely with EPA-specific GHG calculation methodologies and emission factors, and to support the Center's GHG management tools.

For more information regarding the Center for Corporate Climate Leadership, visit www.epa.gov/climateleadership.

Table of Contents

Sectio	n 1:	Intro	oduction	1					
1.	1	Greenhouse Gases Included							
1.	2	Mar	nufacturing vs. Use Phase Emissions	2					
Sectio	n 2:	Met	hods for Calculating Emissions	3					
2.	1	Scre	ening Method	4					
	2.2	1.1	Refrigeration and Air Conditioning Equipment Screening	4					
	2.2	1.2	Fire Suppression Equipment Screening	5					
2.	2	Met	hod for Purchased Gases	5					
2.	3	Mat	erial Balance Method	6					
2.	4	Sim	plified Material Balance Method	8					
Sectio	Section 3: Choice of Activity and Emission Factors10								
3.	1	Scre	ening Method1	0					
3.	2	Met	hod for Purchased Gases1	1					
3.	3	Mat	erial Balance Method1	2					
3.	4	Sim	plified Material Balance Method1	2					
Sectio	n 4:	Com	pleteness1	4					
Sectio	n 5:	Unce	ertainty Assessment1	5					
Sectio	n 6:	Docu	umentation1	6					
Sectio	n 7:	Inve	ntory Quality Assurance and Quality Control (QA/QC)1	7					

Section 1: Introduction

An important category of scope 1 direct greenhouse gas (GHG) are fugitive emissions, which result from the direct release to the atmosphere of GHG compounds from various types of equipment and processes. This guidance document focuses on several fugitive emissions sources that are common for organizations in many sectors: refrigeration and air conditioning systems, fire suppression systems, and the purchase and release of industrial gases.

Historically, air conditioning and refrigeration equipment utilized various Ozone Depleting Substances (ODSs), primarily chlorofluorocarbons (CFCs) and hydrochlorofluorocarbons (HCFCs). However, in accordance with the Clean Air Act Amendments of 1990 (Title VI) and the Montreal Protocol, these ODSs are being phased out of manufacture and use in the United States.

Hydrofluorocarbons (HFCs) and, to a lesser extent, perfluorocarbons (PFCs) are used as substitutes for the regulated ODSs. In addition, some air conditioning and refrigeration systems use non-halogenated refrigerants such as ammonia, carbon dioxide (CO_2), propane, or isobutane. Also, some fire suppression equipment, which historically used ozone-depleting halons, use carbon dioxide (CO_2), inert gases, and other substances.

Emissions from the refrigeration and air conditioning sector result from the manufacturing process, from leakage and service over the operational life of the equipment, and from disposal at the end of the useful life of the equipment. These gases' global warming potential (GWP) is typically greater than 1,000 times that of CO₂, so their potential impact on climate change can be significant. By the same token, any reductions of these gases can have a large potential benefit.

This guidance document addresses the following emissions from owned or leased sources that are within an organization's inventory boundary:

- Emissions from users of refrigeration and air conditioning equipment including household refrigeration, domestic air conditioning and heat pumps, mobile air conditioning, chillers, retail food refrigeration, cold storage warehouses, refrigerated transport, industrial process refrigeration, and commercial unitary air conditioning systems.
- Emissions from fixed and portable fire suppression equipment.
- Direct emissions from purchased industrial gases. These gases can be used in processes such as manufacturing, testing, or laboratory applications.

This document does not address fugitive emissions within the supply chain (e.g., refrigerated shipping vessels), or emissions from aerosols, solvent cleaning, foam blowing, or other applications.

1.1 Greenhouse Gases Included

The emissions sources addressed by this guidance document could result in emissions of any GHG compound.

Ozone depleting substances include numerous compounds such as CFCs, HCFCs, and halons, all of which are GHGs. As mentioned, these ODSs are being phased out of production due to their ozone depleting properties. However, some entities may still use these substances directly or in blends within refrigeration, air conditioning, or fire suppression equipment.

It is customary to exclude CFCs, HCFCs, and halons from GHG inventories because they are regulated and are being phased out by the Clean Air Act. These substances are also excluded from GHG inventories because their global warming impact is complicated by the fact that they deplete stratospheric ozone, which is a GHG. The GHG Protocol allows for reporting of these ODSs as separate memo items on an organization's GHG inventory. They are reported as total release of gases, but no GWP values are applied, and they do not contribute to an organization's total CO_2 -equivalent emissions inventory. Therefore, organizations that currently use ODSs and switch to HFCs or PFCs may show an increase in their overall GHG emissions inventory. Documenting the use of these ODSs will help communicate the reasons for this increase.

1.2 Manufacturing vs. Use Phase Emissions

This document only applies to scope 1 GHG emissions resulting from operations at the reporting organization's facilities. For refrigeration, air conditioning, and fire suppression equipment, these emissions may take place during installation, use, or disposal. Refrigerants and fire suppressants may be released from equipment leaks during normal operation or from catastrophic leaks. Also, when equipment is installed, repaired, or removed, refrigerants and fire suppressants may be released if proper recovery processes are not used. Fire suppressants are also emitted to extinguish fires. Emissions that occur during the manufacturing or disposal of equipment or purchased gases are scope 3 indirect emissions and are not included in an organization's scope 1 emissions.

Section 2: Methods for Calculating Emissions

Most organizations will have emissions from refrigeration and air conditioning equipment in one form or another. However, the potential emissions sources and level of data available may differ greatly. For instance, a supermarket chain with large refrigeration systems may have on-site storage of refrigerants and track detailed data concerning refrigerant use, while an industrial organization may simply use air conditioning in its office space and not track detailed data on refrigerant use. Often organizations whose core business does not include the use of this type of equipment exclude the associated GHG emissions from their GHG inventory as not material. However, the materiality of a source can only be established after it has been assessed. This does not necessarily require a rigorous quantification of all sources, but at a minimum, an estimate based on available data should be developed for all sources of emissions.¹

Four methods with varying levels of accuracy and required data collection are outlined in this guidance to calculate GHG emissions. Organizations may calculate fugitive GHG emissions from refrigeration and air conditioning equipment, fire suppression systems, or purchased industrial gases with one of the following methods.

Section 2.1 describes a preliminary Screening Method to estimate emissions from refrigeration, air conditioning, and fire suppression equipment based on the type of equipment used and emission factors. This method requires the least actual data collection and is not applicable for quantifying emissions from purchased gases. It is recommended that this method be used only as a screening tool because the emissions factors used in the approach are highly uncertain. Emission factors vary between individual pieces of equipment and vary over time. Even if the amount of refrigerant added to a piece of equipment has been tracked carefully, allowing the previous leak rate of that equipment to be established, that leak rate can change after a leak is repaired or as the equipment ages. If emissions from this equipment are determined to be significant when compared to an organization's other emission sources (e.g., stationary combustion, mobile sources), then one of the other methods should be applied to calculate emissions more accurately.

Section 2.2 describes a Method for Purchased Gases which applies to an organization that purchases, uses, and releases industrial gases. If an organization maintains an inventory of industrial gases or uses equipment that contains a charge of an industrial gas, similar to a charge of refrigerant in air conditioning equipment, it is recommended that one of the material balance methods be used.

Section 2.3 describes a Material Balance Method of calculating emissions from the installation, operation, and disposal of refrigeration and air conditioning equipment. This method is recommended for organizations that maintain their own equipment and requires available data on the total inventory of refrigerants at the beginning and end of the reporting period, purchases during the reporting period, and changes in total equipment refrigerant capacity. This material balance method can also be used to calculate emissions from fire suppression equipment.

Section 2.4 describes a Simplified Material Balance Method that is appropriate for entities that do not maintain and track a stock of refrigerants, and that have not retrofitted equipment to use a different refrigerant during the reporting period. This method is recommended for organizations that have contractors service their refrigerant-containing equipment. This method tracks emissions from equipment installation, operation, and disposal. The method requires data on the quantity of refrigerant: (a) used to fill new equipment during installation, (b) used to service equipment, and (c) recovered from

¹ See Chapter 1 of the GHG Protocol for more on materiality and significance of emissions sources.

retiring equipment, as well as the total refrigerant capacities of new and retiring equipment. If notified in advance of the need for this information, the service contractor should be able to provide it.

2.1 Screening Method

The method relies on the use of emission factors which are equipment specific. Therefore, this document provides two different methods, one for refrigeration and air conditioning equipment and a second for fire suppression equipment. This method is not applicable for quantifying emissions from purchased gases.

2.1.1 Refrigeration and Air Conditioning Equipment Screening

Under this approach, an organization multiplies the amount of refrigerant in the equipment by an emission factor for the specific type of equipment and emission event. The disadvantage to using this approach is that emission factors are highly uncertain. Therefore, this method is proposed as a screening test only. Consequently, if an organization determines that emissions from refrigeration and air conditioning equipment may be significant, it is recommended that one of the other methods then be used. Estimating emissions with the Screening Method requires the following steps:

Step 1: Perform an inventory of equipment.

Determine the number and types of refrigeration and air conditioning equipment (by equipment category, see Section 3.1) including the types of refrigerants used and the total refrigerant capacity of each piece of equipment.

Step 2: Determine installation emissions.

Identify any new equipment that was installed during the reporting period and was charged on-site. Emissions from equipment that was charged at the manufacturer are not the responsibility of the reporting organization for equipment use (see Section 1.2). For each new piece of equipment, use Equation 1 to estimate installation emissions.

Step 3: Determine operating emissions.

This step estimates losses from equipment leaks and service losses over the life of the equipment. For all pieces of equipment, use Equation 2 to estimate operating emissions.

Equation 1: Estimating Emissions from Installation

Emissions from Installation = $C_N \times (k/100)$

where:

C_N = amount of refrigerant charged into the new piece of equipment

k = assembly losses in percent of amount charged

Equation 2: Estimating Emissions from Operation

Emissions from Operation = $C \times (x/100) \times T$

where:

- C = refrigerant capacity of the piece of equipment
- x = annual leak rate in percent of capacity
- T = time in years used during the reporting period (e.g., 0.5 if used only during half of the reporting period and then disposed)

Step 4: Determine disposal emissions.

Identify any pieces of equipment that were disposed of during the reporting period. For each piece of disposed equipment, use Equation 3 to estimate disposal emissions.

Step 5: Determine total emissions.

Add the emissions from each piece of equipment for each type of emission (installation, operation, and disposal) to get total emissions. Calculate separate totals for each type of refrigerant used. Multiply the emissions of each refrigerant by the refrigerant's GWP to calculate CO₂ equivalent emissions. GWP values are available in EPA's GHG Emission Factors Hub. Section 3.1 provides default emission factors and

Equation 3: Estimating Emissions from Disposal

Emissions from Disposal =

 $CD \times (y/100) \times (1 - z/100)$

where:

CD = refrigerant capacity of the piece of equipment being disposed of

y = percent of the capacity remaining at disposal

z = percent of refrigerant recovered

describes the different categories of equipment for which there are default factors.

2.1.2 Fire Suppression Equipment Screening

Fire suppression equipment can be divided into two broad categories, fixed and portable equipment. This Screening Method provides an emission factor for each type of equipment. Under this approach, the organization multiplies the capacity of the equipment by an emission factor for fixed or portable equipment. If an organization determines that emissions from fire suppression equipment may be significant, it is recommended that one of the other methods then be used. Estimating emissions with the Screening Method requires the following steps:

Step 1: Perform an inventory of equipment.

Determine the number and types of fire suppression equipment, by gas type, and the fire suppressant capacity of each piece of equipment.

Step 2: Determine total emissions.

Add the capacities of each portable unit for each gas and of each fixed unit for each gas and multiply the total capacity by the appropriate emission factor. Emissions from fixed systems are assumed to be 2.5 percent (0.025) of the total capacity of the units for each gas. Emissions from portable equipment are assumed to be 3.5 percent (0.035) of the total capacity of the units for each gas. The emission factors provided for this Screening Method are as provided in the Inventory of U.S. Greenhouse Gas Emissions and Sinks. Multiply the emissions of each fire suppressant by its GWP from the GHG Emission Factors Hub to calculate CO₂ equivalent emissions.

2.2 Method for Purchased Gases

Industrial gases are sometimes used in processes such as manufacturing, testing, or laboratory uses. For example, CO_2 gas is often used in welding operations. These gases are typically released to the atmosphere after use. Any use and release of the seven major GHGs (CO_2 , CH_4 , N_2O , PFCs, HFCs, SF_6 , and NF_3) is required to be included in the GHG inventory. This method is not recommended if the organization maintains an inventory of industrial gases or uses equipment that contains a charge of an industrial gas, similar to a charge of refrigerant in air conditioning equipment. In these situations, it is recommended that one of the material balance methods be used.

Step 1: Determine purchases of industrial gases.

Determine whether any GHGs are used in processes such as those mentioned above. If so, collect the mass of each gas purchased. If data are not available in mass units, the organization may need to convert from volume to mass using the density of the specific gas. This method assumes that all gas purchased in the reporting period is used and released during

the reporting period. If the organization makes a bulk purchase and plans on using the gas over multiple years, divide the bulk amount by the expected years of usage and consider that to be the purchase amount for the current reporting period, as well as the applicable future reporting periods.

Step 2: Calculate emissions.

Sum the amount of gas purchased for each gas type. Multiply the total by the appropriate GWP from the GHG Emission Factors Hub to calculate CO₂ equivalent emissions.

2.3 Material Balance Method

The Material Balance Method tracks emissions of refrigerants² from equipment through a mass balance analysis. Releases of refrigerants can be calculated based on the inventory (in storage, not in operating equipment), purchases and sales of refrigerants, as well as changes in total refrigerant capacity of equipment during the emissions reporting period.

The inventory should be tracked at the facility level by type of refrigerant. Equation 4 shows the basic principles involved in this approach.

Equation 4 can be rewritten to calculate emissions more easily as shown in Equation 5.

Equation 5 should be applied to each type of refrigerant used. Calculating emissions with the Material Balance Method requires the following steps for each type of refrigerant:

Step 1: Calculate the change in inventory ($I_B - I_E$).

Subtract the amount of refrigerant in inventory at the end of the reporting period from the inventory at the beginning of the reporting period to calculate the change

Equation 4: Material Balance of Refrigerant

 $I_B + P + C_B = I_E + S + C_E + Emissions$ where:

 I_B = refrigerant in inventory (in storage, not in operating equipment) at the beginning of reporting period

P = refrigerant purchased or otherwise acquired during the reporting period

C_B = total refrigerant capacity of equipment at the beginning of the reporting period

I_E=refrigerant in inventory (in storage, not in operating equipment) at the end of reporting period

S= refrigerant sold or otherwise disposed of during the reporting period

 C_E = total refrigerant capacity of equipment at the end of the reporting period

Equation 5: Calculating Refrigerant Emissions with the Material Balance Method

Emissions = $(I_B - I_E) + P - S + (C_B - C_E)$

in inventory. The inventory of refrigerants is defined as the total stored on site in cylinders or other storage. This does not include refrigerants contained within equipment.

Step 2: Determine purchases and other acquisitions (P).

Purchases and other acquisitions may include refrigerant: (a) purchased from producers or distributors, (b) provided by manufacturers with or inside equipment, (c) added to equipment by contractors or other service personnel (but not if that refrigerant is from the organization's inventory), and (d) returned after off-site recycling or reclamation.

Step 3: Determine sales and disbursements (S).

² The term "refrigerant" is used in this section, but this method can also apply to fire suppressants or industrial gases.

Sales and disbursements may include refrigerant: (a) in containers or left in equipment that is sold or disposed of, (b) returned to suppliers, and (c) sent off-site for recycling, reclamation, or destruction. The amount of refrigerant left in equipment should be the actual amount, which may be less than the total capacity.

Step 4: Calculate the change in capacity $(C_B - C_E)$.

The change in capacity is the net change to the total equipment volume for a given refrigerant during the reporting period. Note that "total capacity" refers to the full and proper charge of the equipment rather than the actual charge, which may reflect leakage. Because the material balance is performed for each refrigerant individually, retrofitting of equipment to use a different refrigerant will represent a change in capacity for the old and the new refrigerant. If the beginning and ending total capacity values are not known, the change in capacity can be assumed to equal the capacity of retired units minus the capacity of new units installed. If an organization only installs equipment during the reporting period, C_E will be greater than C_B . The reverse is true for an organization that only disposes of equipment during the reporting period.

Step 5: Calculate emissions.

Once the previous four steps have been completed, GHG emissions for each type of refrigerant and blend may be quantified using Equation 5. Multiply the emissions of each refrigerant by the refrigerant's GWP from the GHG Emission Factors Hub to calculate CO₂ equivalent emissions.

Section 3.3 describes in more detail the type of data that is used in determining emissions.

It may be illustrative to describe how the installation or disposal of equipment impacts the Material Balance Method's calculation. If equipment is installed, the refrigerant capacity of that equipment is included in both term P as an acquisition and in term C_E as capacity at the end of the year. As a result, the installation has no net impact on emissions.

If equipment is disposed, the refrigerant capacity of that equipment is included in term C_B , as capacity at the beginning of the year, and the actual amount of refrigerant contained in the equipment upon disposal is included in term S as a disposition. If the amount of refrigerant contained in the equipment upon disposal equals its refrigerant capacity, the disposal will have no net impact on emissions. If the actual amount is less than the capacity, the difference is assumed to represent emissions.

2.4 Simplified Material Balance Method

The Simplified Material Balance Method is a simplified version of the Material Balance Method described above. In the simplified method, there are fewer flows of refrigerant³ to consider. This method is appropriate for entities that do not maintain and track a stock of refrigerants, and that have not retrofitted equipment to use a different refrigerant during the reporting period. This method requires information on the quantity of refrigerant:

(a) used to fill any new equipment installed during the reporting period, (b) used to service equipment, and (c) recovered from any equipment retired during the reporting period. It also requires information on the total refrigerant capacity of installed and retired equipment. This method can be summarized by Equation 6.

Equation 6: Calculating Refrigerant Emissions with the Simplified Material Balance Method

Emissions = $(P_N - C_N) + P_S + (C_D - R_D)$ where:

P_N = purchases of refrigerant used to charge new equipment (omitted if the equipment has been pre-charged by the manufacturer)

C_N = total refrigerant capacity of the new equipment (omitted if the equipment has been pre-charged by the manufacturer)

P_S = purchases of refrigerant used to service equipment

C_D = total refrigerant capacity of retiring equipment

 R_D = refrigerant recovered from retiring

Equation 6 should be applied to each type of refrigerant used. Calculating emissions with the Simplified Material Balance Method requires the following steps for each type of refrigerant:

Step 1: Calculate installation emissions ($P_N - C_N$).

This step is only necessary if the reporting entity installed any new equipment during the reporting period that was not pre-charged by the equipment supplier. Emissions are calculated by taking the difference between the amount of refrigerant used to charge the equipment and the total capacity of the equipment. The difference is assumed to represent emissions.

Step 2: Determine operating emissions (P_S).

Operating emissions result from equipment leaks and service losses. It is assumed that the amount of refrigerant purchased to service equipment is replacing the same amount that was emitted during operation.

Step 3: Calculate disposal emissions (C_D - R_D).

This step is only necessary if the organization disposed of equipment during the reporting period. Emissions are calculated by taking the difference between the total capacity of the equipment disposed and the amount of refrigerant recovered. The difference is assumed to represent emissions.

Step 4: Calculate emissions.

Emissions for each type of refrigerant and blend are calculated by summing the results of the first three steps. Multiply the emissions of each refrigerant by the refrigerant's GWP from the <u>GHG Emission Factors Hub</u> to calculate CO_2 equivalent emissions.

³ The term "refrigerant" is used in this section, but this method can also apply to fire suppressants or industrial gases.

Section 3.4 describes in more detail the type of data that is used in determining emissions.

Section 3: Choice of Activity and Emission Factors

Required data for all emission estimation methods can come from inventory records, purchase records, repair reports, service records, and disposal records.

3.1 Screening Method

The Screening Method requires organizations to determine the following information:

- Type of Equipment
- Number of Units
- Refrigerant or Fire Suppressant Used
- Total Refrigerant or Fire Suppressant Charge for the Equipment (lb.)

For refrigeration and air conditioning equipment, additional information is required:

- Assembly Emission Factor (%)
- Annual Leakage Rate (%)
- Percent of Capacity Remaining at Disposal (%)
- Recovery Efficiency (%)

The Screening Method is based on the Tier 2 approach from the 2006 Intergovernmental Panel on Climate Change (IPCC) Guidelines for National Greenhouse Gas Inventories.

The IPCC guidelines also include a table of emission factors for the different phases of the equipment's life by equipment type. The IPCC table provides ranges of values for the different emission factors, the percent remaining at disposal, and the recovery efficiency. However, since this method is intended as a screening approach, it is recommended that the upper end of the ranges be used. These values are provided in Table 1. The ranges in capacity are provided only for reference; organizations should use the actual capacity of their equipment.

Table 1: Default Emission Factors for Refrigeration/Air Conditioning Equipment Type of Equipment

Type of Equipment	Capacity (kg)	Installation Emission Factor K (% of capacity)	Operating Emissions X (% of capacity/yr.)	Refrigerant Remaining at Disposal y (% of capacity)	Recovery Efficiency z (% of remaining)
Domestic Refrigeration	0.05-0.5	1	0.5	80	70
Stand-alone Commercial Applications	0.2–6	3	15	80	70
Medium & Large Commercial Refrigeration	50–2,000	3	35	100	70
Transport Refrigeration	3–8	1	50	50	70
Industrial Refrigeration including Food Processing and Cold Storage	10–10,000	3	25	100	90
Chillers	10-2,000	1	15	100	95
Residential and Commercial A/C including Heat Pumps	0.5-100	1	10	80	80
Mobile Air Conditioning - Maritime	5-6,500	0.5	40	50	50
Mobile Air Conditioning - Railway	10-30	0.5	20	50	50
Mobile Air Conditioning - Buses	4-18	0.5	20	50	50
Mobile Air Conditioning - Other	0.5-2	0.5	20	50	50

Source: 2019 Refinement to the 2006 IPCC Guidelines for National Greenhouse Gas Inventories, Chapter 7: Emissions of Fluorinated Substitutes for Ozone Depleting Substances, Table 7.9, Default Estimates for Charge, Lifetime, and Emission Factors for Refrigeration and Air-Conditioning Systems.

3.2 Method for Purchased Gases

For quantifying emissions from purchased gases, this method requires data that should be available from purchase records. The Method for Purchased Gases requires organizations to collect the following data:

- Type of gas purchased
- Amount of gas purchased
- Purpose for the gas

3.3 Material Balance Method

The recommended approach for organizations that maintain their own refrigerant-containing equipment is to calculate emissions based on the Material Balance Method. This method requires data that should be available from purchase and service records. The Material Balance Method requires organizations to collect the following data:

- Refrigerant inventory (in storage, not in operating equipment) at beginning of year
- Refrigerant inventory (in storage, not in operating equipment) at end of year
- Refrigerant purchased from producers or distributors in bulk
- Refrigerant provided by manufacturers with or inside of equipment
- Refrigerant added to equipment by contractors
- Refrigerant returned after off-site recycling or reclamation
- Sales of bulk refrigerant to other entities
- Refrigerant left in equipment that is sold to other entities or disposed of
- Refrigerant returned to suppliers
- Refrigerant sent off-site for recycling or reclamation
- Refrigerant sent off-site for destruction
- Refrigerant capacity at beginning of year (in operating equipment, not storage)
- Refrigerant capacity at end of year (in operating equipment, not storage)

If beginning and ending capacity values are not known, the following information can be used:

- Refrigerant capacity of new equipment using this refrigerant
- Refrigerant capacity of equipment that is retrofitted to use this refrigerant
- Refrigerant capacity of retiring or sold equipment that used this refrigerant
- Refrigerant capacity of equipment that is retrofitted away from this refrigerant to a different refrigerant

Note: "Refrigerant capacity" refers to the full and proper charge of the equipment rather than to the actual charge, which may reflect leakage.

3.4 Simplified Material Balance Method

The Simplified Material Balance Method is the recommended approach for equipment users who have contractors service their equipment. If notified in advance of the need for this information, the contractor should be able to provide it. This method requires organizations to collect the following data:

- Refrigerant used to fill new equipment
- Refrigerant purchased to charge new equipment

- Refrigerant capacity of new equipment using this refrigerant
- Refrigerant purchased to service equipment
- Refrigerant capacity of retiring equipment
- Refrigerant recovered from retiring equipment

Note: "Refrigerant capacity" refers to the full and proper charge of the equipment rather than to the actual charge, which may reflect leakage.

Section 4: Completeness

Forr an organization's GHG inventory to be complete, it must include all emission sources within the organization's inventory boundaries. See Chapter 3 of the GHG Protocol for detailed guidance on setting organizational boundaries and Chapter 4 of the GHG Protocol for detailed guidance on setting operational boundaries of the inventory.

On an organizational level, an organization's inventory should include emissions from all applicable facilities or fleets of vehicles. Completeness of organization-wide emissions can be checked by comparing the list of sources included in the GHG emissions inventory with those included in other emission's inventories, environmental reporting, financial reporting, etc.

At the operational level, an organization should include all GHG emissions from the sources included in their GHG inventory. Possible GHG emission sources are stationary fuel combustion, combustion of fuels in mobile sources, purchases of electricity, and process or fugitive emissions. Organizations may refer to this guidance document for calculating fugitive GHG emissions from air conditioning and refrigeration equipment, as well as fire suppression equipment and industrial gases, and to the Center's Guidance documents for calculating emissions from other sources.

When calculating emissions from this equipment use, organizations should include all applicable sources of refrigerant emissions. If a third party is used for any component of refrigerant tracking, the third party should provide any necessary information. For the Screening Method, all pieces of equipment of all different types need to be accounted for. For the Material Balance Methods, all activities and different types of refrigerants or blends should be tracked.

As described in Chapter 1 of the GHG Protocol there is no materiality threshold set for reporting emissions. The materiality of a source can only be established after it has been assessed. This does not necessarily require a rigorous quantification of all sources, but at a minimum, an estimate based on available data should be developed for all sources.

Section 5: Uncertainty Assessment

There is some level of uncertainty associated with all methods of calculating GHG emissions. It is recommended that organizations attempt to identify the areas of highest uncertainty in their emissions calculations and consider options for improving the quality of this data in the future.

The Screening Method for estimating emissions is highly uncertain. Factors vary between individual pieces of equipment and over time. Even if the amount of refrigerant added to a particular piece of equipment has been tracked carefully, allowing the previous leak rate of that equipment to be established, that leak rate can change after the leak is repaired or as the equipment ages.

The major uncertainty introduced in the material balance approaches occurs with recently installed equipment. Equipment can leak for two or more years before needing a recharge, so emissions over this period are not detected until after they occur. Despite this minor drawback, the material balance approaches provide a highly accurate estimate of emissions.

Section 6: Documentation

To ensure that emissions calculations are transparent and verifiable, the documentation sources listed in Table 2 should be maintained. These documentation sources should be collected to ensure accuracy and transparency, and should also be included in the organization's Inventory Management Plan (IMP).

Table 2: Documentation Sources					
Data	Documentation Source				
Inventory at Beginning and End of Year	Stock inventory documentation				
Purchases	Purchase receipts; delivery receipts; contract				
Nameplate Capacity of equipment	Delivery receipts of equipment; records of physical inspection of nameplates; shipping or disposal records of equipment				
Amounts Charged to Equipment	Repair records; repair invoices; daily reports				
Amounts Recovered from Equipment	Repair records; repair invoices; daily reports; disposal records				

Section 7: Inventory Quality Assurance and Quality Control (QA/QC)

Chapter 7 of the GHG Protocol provides general guidelines for implementing a QA/QC process for all emissions calculations. For the use of refrigeration and air conditioning equipment, the following items must be addressed:

- Care should be taken that releases are not double counted (e.g., from reporting both refrigerant blend and individual blend component use).
- Verify that your inventory is complete. Because the GWP values of fluorinated compounds are so large (particularly when compared to carbon dioxide and methane), failure to account for even relatively small releases of fluorinated compounds can introduce significant errors. Also, tracking specific GHGs separately is important, because of the differing GWP values.