

Facility Name	Santa Rosa	
NPDES Permit Number	NM0024988	
Proposed Critical Dilution*	19	%

***Critical Dilution in draft permit, do not use % sign.**

Test Data

Count	5	5	8	6
Mean	3.400	3.497	3.625	4.348
Std. Dev.	1.342	1.411	1.061	2.615
CV	0.6	0.6	0.6	0.6

2.3	2.3
-----	-----

1.9	2.1
-----	-----

5.263	Reasonable Potential Acceptance Criteria
-------	--

Vertebrate Lethal	1.748	No Reasonable Potential exists. Permit requires WET monitoring, but no WET limit.
-------------------	-------	---

Vertebrate Sublethal	1.960	No Reasonable Potential exists. Permit requires WET monitoring, but no WET limit.
----------------------	-------	---

Invertebrate Lethal	1.444	No Reasonable Potential exists. Permit requires WET monitoring, but no WET limit.
---------------------	-------	---

Invertebrate Sublethal	#DIV/0!	#DIV/0!
------------------------	---------	---------

Reasonable Potential Analyzer

Determining "Reasonable Potential" for Excursions Above Ambient Criteria Using Effluent Data Only

EPA recommends finding that a permittee has “reasonable potential” to exceed a receiving water quality standard if it cannot be demonstrated with a high confidence level that the upper bound of the lognormal distribution of effluent concentrations is below the receiving water criteria at specified low-flow conditions.

Step 1 Determine the number of total observations (“n”) for a particular set of effluent data (concentration or toxic units [TUs]), and determine the highest value from that data set.

Step 2 Determine the coefficient of variation for the data set. For a data set where $n < 10$, the coefficient of variation (CV) is estimated to equal 0.6, or the CV is calculated from data obtained from a discharger. For a data set where $n > 10$, the CV is calculated as standard deviation/mean. For less than 10 items of data, the uncertainty in the CV is too large to calculate a standard deviation or mean with sufficient confidence.

Step 3 Determine the appropriate ratio from the table below.

Step 4 Multiply the highest value from a data set by the value from the table below. Use this value with the appropriate dilution to project a maximum receiving water concentration (RWC).

Step 5 Compare the projected maximum RWC to the applicable standard (criteria maximum concentration, criteria continuous concentration [CCC], or reference ambient concentration). EPA recommends that permitting authorities find reasonable potential when the projected RWC is greater than an ambient criterion.